



Section 1 INTRODUCTION

1.1 Background and Purpose

The Clean Water Act (CWA) was passed in 1972 to help protect and restore the waters in our Nation's streams, rivers, and lakes. In the early 1990s, Phase I of the National Pollutant Discharge Elimination System (NPDES), under authority of the CWA, was passed to regulate stormwater management in large urban areas. Phase II regulations were developed and passed near the turn of the century requiring medium size cities meeting a certain population density and other criteria to develop stormwater initiatives to address pollution associated with urban runoff. In March of 2003, the City of Madisonville, and numerous other "Phase II Cities and Counties" submitted permit applications to the Kentucky Division of Water outlining a 5 year plan for addressing the Phase II requirements.

The thought behind the Phase II program is that urban runoff is a chief cause of stream impairment, and that urban runoff can be managed in large part by effectively addressing a few key areas; educating and involving the public on the impacts of urban runoff and how the public can help, managing the storm sewer infrastructure and addressing illicit discharges (discharge of pollution / polluted runoff), implementation of local regulatory authority, development of best management practices (BMPs) for construction and post-construction, and environmentally sensitive and responsible municipal operations. This BMP manual was developed to support Phase II efforts in addressing Construction Site Runoff as required by the Phase II permit for Madisonville and numerous other Phase II communities. Additionally, a number of the BMPs address municipal operations, and residential issues and can be used for sharing information with the public.

The manual presents a brief introduction to stormwater Best Management Practices (BMPs). The following types of BMPs are addressed: Site Planning and Design Practices (SPD); Erosion Prevention Practices (EPP); Sediment Management Practices (SMP); Good Housekeeping Practices (GHP); and BMPs for Residential and Homeowners (RHP). The manual describes how BMPs can be selected, and contains a series of fact sheets for each type of BMP to be used in the area.

The intent of the Stormwater Best Management Practices Manual is to provide guidance on BMP selection, design, and implementation to plan submitters, reviewers, construction site operators, and site inspectors. There is special emphasis on Erosion Prevention and Sedimentation Control (EPSC) during construction and recommendations to homeowners to help provide and extend benefits beyond construction. There are also guidance materials for activities at commercial and industrial facilities.



The fact sheets are categorized, focused, and concise so that they may be used as quick references for design, inspection, and maintenance guidance. In this way, the fact sheets are designed to be stand-alone documents that may be distributed to facilitate discussion about design and/or implementation of the management practice. Many of the practices are considered structural practices in that they involve construction. However, several of the BMPs cover non-structural practices where normal activities are performed in a different manner with stormwater quality in mind.

1.2 List of Definitions, Abbreviations and Acronyms

1.2.1 Definitions

Best Management Practice (BMP)	A measure that is implemented to protect water quality and reduce the potential for pollution associated with storm water runoff.
Blue Line Streams	Streams that are represented on the United States Department of the Interior Geological Survey 1:24,000 quadrangle maps.
Certified Contractor	A person who has received EPSC training and is licensed by the City of Madisonville to install, inspect and maintain erosion and sediment control practices.
Channel	A natural or constructed/manmade watercourse with definite bed and banks to confine and conduct continuously or periodically flowing water. Channel flow is that water which is flowing within the limits of the defined channel.
Clearing	Any activity that removes vegetative surface cover.
Clean Water Act (CWA)	Federal Regulation that prohibits the discharge of pollutants to Waters of the United States unless said discharge is in accordance with an NPDES permit.
Critical Area	A site difficult to stabilize due to exposed subsoil, steep slope, extent of exposure, or other conditions.
Critical Watershed	A watershed that has a FEMA Zone “A”, “AE”, or “X” within the site or a location of historical flooding of roads or structures.
Detention	The temporary delay of storm runoff prior to discharge into receiving waters.



Developer	Any individual, firm, corporation, association, partnership, or trust involved in commencing proceedings to affect development of land for developers or others.
Drainage Basin	A part of the surface of the earth that is occupied by and provides surface water runoff into a storm water management system, which consists of a surface stream or a body of impounded surface water together with all tributary surface streams and bodies of impounded surface water.
Drainage Way	Any channel that conveys surface runoff throughout the site.
Drainage/Dry Well	A bored, drilled, driven, dug, or naturally occurring shaft or hole with a depth greater than the largest surface dimension; used to drain surface fluid, primarily storm water runoff, into a subsurface formation.
Ephemeral Stream	A stream or part of a stream that flows only in direct response to precipitation or snowmelt. Its channel is above the water table at all times.
Erosion	The wearing away of land surface by the action of wind, water, gravity, ice, or any combination of those forces.
Erosion Prevention Sediment Control Plan (EPSC)	A set of plans prepared by or under the direction of a licensed professional engineer detailing the specific measures and sequencing to be used to control sediment and erosion on a development site during and after construction.
Excavation	Any portion of land surface or area from which earth has been removed or will be removed; the depth below original ground surface to remaining surface.
Existing Grade	The slope or elevation of existing ground surface prior to cutting or filling.
Fill	Portion of land surface or area to which soil, rock, or other materials have been or will be added; height above original ground surface after the material has been or will be added.
Finished Grade	The final slope or elevation of the ground surface after cutting or filling.



Flood Plain	The relatively flat or lowland area adjoining a river, stream, watercourse, lake, or other body of standing water which has been or may be covered temporarily by floodwater. For purposes of this ordinance, the flood plain is defined as the area encompassed by a 100-year storm having a one percent chance of being equaled or exceeded in any given year.
Grading	Any stripping, cutting, filling, or stockpiling of earth or land, including the land in its cut or filled condition, to create new grades.
Impervious Surface	A term applied to any ground or structural surface that water cannot penetrate or through which water penetrates with great difficulty.
KYDOW General Permit (KGP)	An agreement between the regulating authority and the Permittee which specifies conservation practices that shall be implemented in the construction of activities specified in the terms and conditions of the general permit.
Land Disturbance	The purposeful act of clearing, grubbing, excavating, or grading; disrupting ground surface by or for construction activities, including construction access/roads, staging, and storage sites producing significant areas of exposed soil and soil piles.
National Pollutant Discharge Elimination System (NPDES)	EPA's program to control the discharge of pollutants to waters of the United States. NPDES is a part of the Federal CWA, which requires point and non-point source dischargers to obtain permits. These permits are referred to as NPDES permits.
Notice of Intent (NOI)	A formal notice to the EPA or a state agency having delegated NPDES authority that a construction project seeking coverage under a General Permit is about to begin.
Notice of Termination (NOT)	A formal notice KYDOW having delegated NPDES authority that construction project is complete and seeking release for the EPSC and the State General Permit.
Perimeter Control	A barrier that prevents sediment from leaving a site by filtering sediment-laden runoff or diverting it to a sediment trap or basin.
Permit Phasing	Clearing a parcel of land in distinct phases, with the stabilization of each phase completed before the clearing of the next commences.
Permittee	Shall mean the "Person Responsible for the Land Disturbing Activity".



Public Storm Drain	Drain system provided by and maintained by the City of Madisonville, that is designed to help maintain storm water runoff; it also provides inlets for water to travel to holding areas attempting to remove excessive water from streets and other areas.
Sediment	Solid material, both mineral and organic, that in suspension is being transported or has been moved from its site of origin by air, water, or gravity as a product of erosion.
Sediment Control	Measures that prevent eroded sediment from leaving the site.
Site	A parcel of land or a contiguous combination thereof, where grading work is performed as a single unified operation subject to erosion of sedimentation as a result of cutting, filling, grading, or other disturbance of the soil.
Site Development	A permit issued by the City of Madisonville for the construction or Permit alteration of ground improvements and structures for the control of erosion, runoff, and grading.
Stabilization	The use of practices that prevent exposed soil from eroding.
Start of Construction	The first land-disturbing activity associated with a development, including land preparation such as clearing, grading, and filling; installation of streets and walkways; excavation for basements, footings, piers, or foundations; erection of temporary forms; and installation of accessory buildings such as garages.
Storm Water	A plan which is based on hydrologic and hydraulic calculations to Management Plan determine flood stage and required improvement to minimize impacts (SWMP) by development.
Storm Water Pollution Prevention Plan (SWPPP)	A plan required by storm water regulations or permits that includes site map(s), an identification of construction/ contractor activities that (SWPPP) could cause pollutants in the storm water, and a description of measures or practices to control these pollutants. The SWPPP is part of the “BMP Plan” used in the KYDOW General Permit.
Temporary Protection	Short-term stabilization of erosive or sediment producing areas.
Utility General Permit	Agreement between the MS4 Municipality and the local Utilities, stating that Phase II regulations shall be applied and implemented.



Vegetative Protection	Stabilization of erosive or sediment producing areas by covering the soil with any of the following materials: permanent seeding for long-term vegetative cover, short-term seeding for temporary vegetative cover, sodding, producing areas covered with a turf of perennial sod-forming grass, tree planting, or other planting.
Watercourse	Any body of water including, but not limited to lakes, ponds, rivers, streams, and bodies of water delineated by the City of Madisonville.
Waterway	A channel that directs surface runoff to a watercourse or to the public storm drain.

1.2.2 Abbreviations and Acronyms

ADT	Average Daily Traffic
ARAP	Aquatic Resource Alteration Permit
BFM	Bonded Fiber Matrix
BMP	Best Management Practice
BOD	Biochemical Oxygen Demand
BS	Bank Stabilization
BZ	Buffer Zones
CB	Continuous Berms
CD	Check Dams
CL	Channel Lining
COS	Chemical Oxygen Demand
CRS	Construction Road Stabilization
DB	Detention Basin
DO	Dissolved Oxygen
EPA	Environmental Protection Agency
EPP	Erosion Prevention Practices
EPSC	Erosion Prevention and Sediment Control
G	Geotextiles
GHP	Good Housekeeping Practices
HAZWOPER	Hazardous Waste Operations and Emergency Response
KDOW	Kentucky Division of Water
KDWM	Kentucky Division of Waste Management
KUB	Kentucky Utilities Board
M	Mulching
MS4	Municipal Separate Storm Sewer System
MSD	Marine Sanitation Device
MSDS	Material Safety Data Sheet
N and M	Nets and Mats
NPDES	National Pollution Discharge Elimination System
OSDS	On-Site Disposal System
OSHA	Occupational Safety and Health Administration



PCB	Polychlorinated Biphenyl
PE	Professional Engineer
PPE	Personal Protective Equipment
PS	Permanent Seeding
RH	Residential Homeowners
RR	Rip-rap
SBCCI	Southern Building Code Congress International, Inc.
SCE	Stabilized Construction Entrance
SEDCAD	Software for Design of Stormwater, Erosion, and Sediment Control Systems
SF	Silt Fence
SF-LD	Light Duty Silt Fence
SF-HD	Heavy Duty Silt Fence
SMP	Sediment Management Practices
SO	Sodding
SPCC	Spill Prevention Control and Countermeasure
SPD	Site Planning and Design Practices
SR	Surface Roughening
ST	Sediment Traps
SWPPP	Storm Water Pollution Prevention Plan
T	Terracing
TIP	Temporary Inlet Protection
TMDL	Total Maximum Daily Load
TOP	Temporary Outlet Protection
TS	Temporary Seeding
TS	Top Soiling
TW	Tire Washing
USACE	United States Army Corps of Engineers

1.3 Construction Site Management for Stormwater Quality

1.3.1 Erosion and Sediment Control Regulations

Short-term stormwater quality management predominately focuses on erosion prevention and sedimentation control (EPSC) for construction sites. However, for some fully developed sites EPSC can also be a concern. Soil erosion is the process by which soil particles are removed from land surfaces by wind, water or gravity. Natural erosion generally occurs at slow rates. However, the rate of erosion increases when land is cleared or altered and left disturbed. Erosion rates will increase when flow rates and velocities discharged from a site exceed the erosive range.

Clearing and grubbing activities during construction remove vegetation and disrupt the structure of the soil surface, leaving the soil susceptible to rainfall erosion, stream and channel erosion, and wind erosion if left untreated. Ultimately, the material suspended by erosion settles during



sedimentation in downstream reaches. This can lead to increased maintenance needs and flooding problems.

1.3.1.1 Water Erosion

The rainfall erosion process begins when raindrops impact the soil surface and dislodge minute soil particles. These soil particles then become suspended in the water droplet. The sediment laden water droplets accumulate on the soil surface until a sufficient quantity has developed to begin flowing under the forces of gravity.

The initial flow of sediment-laden water generally consists of a thin, slow-moving sheet, known as sheet flow. While sheet flow is generally not highly erosive on its own, it does begin the transport of previously suspended sediment. Due to irregularities in the soil surface and uneven topography, sheet flow will usually begin to concentrate into rivulets, where the flow picks up velocity, and erosive energy increases as a result of gravitational forces.

The increasing erosive energy of water flowing in rivulets will cut small grooves, or rills, in the soil surface. Rill erosion of the soil surface tends to concentrate more flows, which then flow faster and gain erosive energy as a result of gravitational forces. In turn, the rills become deeper and larger, and join adjacent rills. Typically, rills run parallel with the slope and each other, are small enough to be stepped across, and are generally enlarged by direct erosion of the rill's sides and bottom by the action of flowing water.

The communion of several adjacent rills, or sufficient enlargement of a single rill, begins gully erosion. Gully erosion of the soil surface tends to concentrate more flows, which then flow faster and gain erosive energy as a result of gravity. Typically, gullies run parallel with the slope, may have one or more lateral branches, and are enlarged by four key actions. First, gullies often have a "head cut" at the upstream end which progresses its way upstream as water flowing into the gully erodes the lip of the head. This mechanism is similar to a waterfall working its way upstream. Second, the flow in a gully tends to under cut the banks. Once sufficiently under cut, the banks collapse into the gully where the loosened soil is then washed away. Third, when banks collapse into the gully, flowing water is diverted around the temporary blockage of soil. This temporary blockage increases velocities along one or both banks, which results in increased bank erosion. Fourth, the concentration of flows in the gully can result in scour of the gully floor until a stable slope is obtained.

1.3.1.2 Stream and Channel Erosion

One or more of the following factors that disrupt the delicate balance required for stable streams and channels generally precipitate erosion within streams and channels.



1. Disturbing the banks of streams and channels is often required during construction. Once vegetation or other bank protection measures are disturbed, flows may begin to erode the unprotected soil.
2. Disturbing the flow within a stream or channel is often necessary to facilitate construction activities. However, this should only be allowed when traversing banks such as temporary stream crossing, culvert installation, bridge construction, etc. By diverting flows within the channel, velocities are increased in some areas to compensate for decreases in other areas. The increases in velocity may exceed those normally experienced by the channel, resulting in bank erosion and bottom scour.
3. Increasing the quantity and rate of flow to streams and channels often results from construction activities and construction of facilities that increase the quantity and rate of runoff as well as how runoff is conveyed to the discharge point. The increased quantity and rate of flow can cause bank erosion and bottom scour.

1.3.1.3 Wind Erosion

Dust is defined as solid particles or particulate matter small enough to remain suspended in the air for a period of time and large enough to eventually settle out of the air. Dust from a construction site originates as inorganic particulate matter from rock and soil surfaces and material storage piles. The majority of dust generated and emitted into the air at a construction site is related to earth moving, demolition, construction traffic on unpaved surfaces, and wind over disturbed soil surfaces.

1.3.1.4 Factors Influencing Erosion

There are five primary factors that influence erosion: soil characteristics, vegetative cover, topography, climate, and rainfall.

1. Soil characteristics that determine the erodibility of the soil include particle size, particle gradation, organic content, soil structure, and soil permeability. Soil characteristics affect soil stability and infiltration capacity. The less permeable the soil, the higher the likelihood for increased runoff and erosion. Soils with a high percentage of silt and clays are generally the most erodible.

The soil characteristics play a different role for channel flow. The tractive-force or shear stresses developed by flowing water over the channel banks and bottom can cause the soil particles to move and become suspended into the runoff. The “permissible shear” stress indicates the stress that the channel banks and bottom can sustain without compromising stability. Protecting the channel bottom and banks with a variety of “soft/green” or “hard” armoring increases the permissible shear stress in the channel.



2. Vegetative cover plays an important role in controlling erosion by shielding the soil surface from the impacts of falling rain, and slowing the velocity of runoff. This permits greater infiltration, maintains the soil's capacity to absorb water, and holds soil particles in place. Vegetative root structures create a favorable soil structure, improving its stability and permeability.
3. Topography, including slope length and steepness are key elements in determining the volume and velocity of runoff. As slope length, and /or steepness increases, so do the rate of runoff and the erosion potential.
4. Climate is a key factor that influences erosion. High rainfall areas and areas with freeze/thaw cycles have significant effects on soil stability and structure.
5. Wet weather frequency, intensity, and duration are fundamental factors in determining the amounts of erosion produced. When storms are frequent, intense, or of long duration, erosion risks are high. In Kentucky, the erosion risk period is typically highest in the wet season (typically December through May) which coincides with the period of minimal vegetative cover.

1.3.2 Other Stormwater Pollutants and Impacts

Sediment from erosion is the pollutant most frequently associated with construction activities. However, other pollutants of concern include nutrients, metals, pesticides, oil and grease, fuels, other toxic chemicals, and miscellaneous wastes. These pollutants originate from a variety of activities including paving operations, demolition, materials storage, equipment fueling, and other daily activities necessary for project construction or site (commercial or industrial) management. By taking an activities inventory, the contractor/operator can identify potential pollutant sources and then select appropriate BMPs to address these sources. Appropriate BMPs are usually specific to the construction activity or site (commercial or industrial) management activity.

1.3.2.1 Nutrients

Phosphorous and nitrogen from fertilizers, pesticides, construction chemicals, and solid waste are often generated by site activities. These nutrients can result in excessive or accelerated growth of vegetation or algae resulting in impaired use of water in lakes and other sources of water supply through taste and odor problems. Excess algae can also deplete dissolved oxygen levels resulting in fish kills. Collectively, the problems associated with excessive levels of nutrients in a receiving water are referred to as *eutrophication* impacts.



1.3.2.2 Oxygen Demanding Substances

Lower dissolved oxygen (DO) levels are often the cause of fish kills in streams and reservoirs. The degree of DO depletion is measured by the biochemical oxygen demand (BOD) test that expresses the amount of easily oxidized organic matter present in water. The chemical oxygen demand (COD) test measures all the oxidizable matter present in urban runoff. BOD is caused by the decomposition of organic matter in stormwater that depletes DO. Other non-organic materials in the water can intensify DO depletion.

1.3.2.3 Metals

Many artificial surfaces (e.g., galvanized metal, paint, or preserved wood) contain metals that can enter stormwater as the surfaces corrode, flake, dissolve, decay, or leach. However, significant portions of metals in urban runoff are from cars and trucks. Over half the trace metal load carried in stormwater is associated with sediments to which these eroded metals attach. Heavy metals are of concern because they are toxic to aquatic organisms, can be bioaccumulative, and have the potential to contaminate drinking water supplies.

1.3.2.4 Pesticides

Herbicides, insecticides and rodenticides (collectively termed *pesticides*), are commonly used on construction sites, lawns, parks, golf courses, etc. Unnecessary, excessive, or improper application of these pesticides may result in direct water contamination, indirect water pollution by aerosol drift, or erosion of treated soil and subsequent transport into surface waters.

1.3.2.5 Oil, Grease and Fuels

These products are widely used and can be spilled/leaked/dumped on the ground where they can wash into waterways. Sources include leakage during normal vehicle use, hydraulic line failure, spills during fueling, and inappropriate disposal of drained fluids. These products can cause harm to plant and animal life.

1.3.2.6 Other Toxic Chemicals

Often synthetic organic compounds (adhesives, cleaners, sealants, solvents, etc.) are widely applied and may be improperly stored and disposed. Accidental spills and leakage or deliberate dumping of these chemicals onto the ground or into storm drains causes environmental harm in receiving waters.

1.3.2.7 Miscellaneous Wastes

Miscellaneous wastes include wash water from concrete mixers, paints and painting equipment cleaning activities, solid organic wastes resulting from trees and shrubs removed during land



clearing, wood and paper materials derived from packaging of building products, food containers, such as paper, aluminum, and metal cans, industrial or heavy commercial process wash/cooling water, vehicle washing, other commercial or industrial wastes and sanitary wastes. The discharge of these wastes can lead to unsightly and polluted receiving waters.

1.4 BMP Selection Process

1.4.1 BMP Objectives

Each construction project is unique. Therefore, an understanding of the pollution risks of the construction activity is essential for selecting and implementing BMPs. Defining these risks requires review of the characteristics of the site and the nature of the construction, information which should be assembled for the construction plans. Once these pollution risks are defined, BMP objectives are developed, and BMPs selected. The BMP objectives for construction projects are as follows:

1. Practice Good Housekeeping: Perform activities in a manner which keeps potential pollutants from either draining or being transported off-site by managing pollutant sources and modifying construction activities.
2. Contain Waste: Dispose of all construction waste in designated areas, and keep stormwater from flowing on to or off of these areas.
3. Minimize Disturbed Areas: Only clear land which will be actively under construction in the near term (e.g., within the next 3-4 months), minimize new land disturbance during the rainy season, and do not clear or disturb sensitive areas (e.g., steep slopes, buffers and natural watercourses) and other areas where site improvements will not be constructed.
4. Stabilize Disturbed Areas: Provide temporary stabilization of disturbed soils whenever active construction is not occurring on a portion of the site. Provide permanent stabilization during finish grade and landscape the site.
5. Protect Slopes and Channels: Outside of approved grading plan area, avoid disturbing steep or unstable slopes. Safely convey runoff from the top of the slope, and stabilize disturbed slopes as quickly as possible. Avoid disturbing natural channels. Stabilize temporary and permanent channel crossings as quickly as possible, and ensure that increases in runoff velocity caused by the project do not erode the channel.
6. Control Site Perimeter: Upstream runoff should be diverted around or safely conveyed through the construction project. Such diversions must not cause downstream property damage. Runoff from the project site should be free of excessive sediment and other constituents.



7. Control Internal Erosion: Detain sediment laden waters from disturbed, active areas within the site to minimize the risk that sediment will have the opportunity to leave the site.

Site characteristics and contractor activities affect both the potential for erosion and contamination by other constituents used on the construction site. Before defining BMP objectives, you should carefully consider:

1. Site conditions that affect erosion and sedimentation including:
 - a. Soil type, including underlying soil strata that are likely to be exposed to stormwater.
 - b. Natural terrain and slope.
 - c. Final slopes and grades.
 - d. Location of concentrated flows, storm drains, and streams.
 - e. Existing vegetation and ground cover.
2. Climatic factors, which include:
 - a. Seasonal rainfall patterns.
 - b. Appropriate design storm
 - i. quantity of rainfall
 - ii. intensity of rainfall
 - iii. duration of rainfall
3. Type of construction activity.
4. Construction schedules, construction sequencing and phasing of construction.
5. Size of construction project and area to be graded.
6. Location of the construction activity relative to adjacent uses and public improvements.
7. Cost-effectiveness considerations.
8. Types of construction materials and potential pollutants present or that will be brought on-site.
9. Floodplain, Floodway, and buffer requirements.

1.4.2 BMP Categories

Once the BMP objectives are defined, it is necessary to identify the category of BMPs that is best suited to meet each objective.

To determine where to place categories of BMPs, a map of the project site can be prepared with sufficient topographic detail to show existing and proposed drainage patterns and existing and proposed permanent stormwater control structures. The project site map should identify the following:



1. Locations where stormwater enters and exits the site. Include both sheet and channel flow for the existing and final grading contours.
2. Identify locations subject to high rates of erosion such as steep slopes and unlined channels. Long, steep slopes over 100 feet in length are considered as areas of moderate to high erosion potential.
3. Categorize slopes as:
 - a. Low Erosion Potential (0 to 5 percent slope)
 - b. Moderate Erosion Potential (5 to 10 percent slope)
 - c. High Erosion Potential (slope greater than 10 percent)
4. Identify wetlands, springs, sinkholes, floodplains, floodways, sensitive areas or buffers which must not be disturbed, as well as other areas where site improvements will not be constructed. Establish clearing limits around these areas to prevent disturbance by the construction activity.
5. Identify the boundaries of tributary areas for each outfall location. Then calculate the approximate area of each tributary area.
6. Define areas where various contractor activities have a likely risk of causing a runoff or pollutant discharge.

With this site map in hand, categories of BMPs can be selected and located. It is more cost-effective to prevent erosion/pollution than to remove sediment/pollutants, and erosion prevention is achieved most cost-effectively by planning before construction begins and phasing construction activities.

BMPs that can achieve more than one BMP objective should be taken into account when selecting BMPs to achieve maximum cost-effectiveness. For instance, it is not always necessary to install extensive sediment trapping controls during construction. In fact, sediment trapping should be used only as a short-term measure for active construction areas, and replaced by permanent stabilization measures as soon as possible. However, it should be noted that perimeter/outfall control in the form of permanent detention ponds should be built first and used as temporary sediment control by placing a filter on the outlet. After construction is complete and tributary area is stabilized, the permanent outlet configuration can be reestablished.

1.4.3 Selecting BMPs for Construction Site Management (Sections SPD, EPP, SMP)

Certain contractor activities may cause pollution if not properly managed. Not all of the BMPs will apply to every construction site. However, all of the suggested BMPs should be considered,



and those which are appropriate for the project at hand should be selected. Considerations for selecting BMPs for contractor activities include the following:

1. Is it expected to rain? BMPs may be different on rainy days vs. dry days, winter vs. summer, etc. For instance, a material storage area may be covered with a tarp during the rainy season, but not in the summer. However, it should be noted that plans should be made for some amount of rain even if it is not expected to generate a flooding event.
2. How much material is used? Less intensive BMP implementation may be necessary if a “small” amount of pollutant containing material is used (however, remember that different materials pollute in different amounts).
3. How much water is used? The more water used and wastewater generated, the more likely that pollutants transported by this water will reach the stormwater system or be transported off-site. Washing out one concrete truck on a flat area of the site may be sufficient (as long as the concrete is safely removed later), but a pit should be constructed if a number of trucks will be washed out at the same site.
4. What are the site conditions? BMPs selected will differ depending on whether the activity is conducted on a slope or flat ground, near a stormwater structure or watercourse, etc. Anticipating problems and conducting activities away from certain sensitive areas will reduce the cost and inconvenience of performing BMPs.
5. What about accidents? Pre-establishing a BMP for each conceivable pollutant discharge may be very costly and significantly disrupt construction. As a rule of thumb, establish controls for common (daily or weekly) activities and be prepared to respond quickly to accidents. Define the difference, not everything can be called an accident and maybe classified as negligent disregard of proper practices.

Therefore, keep in mind that the BMPs for contractor activities are suggested practices which may or may not apply in every case. Construction personnel should be instructed to develop additional or alternative BMPs which are more cost-effective for a particular project. The best BMP is a construction work force aware of the pollution potential of their activities and committed to a clean worksite.

Effective EPSC management first minimizes erosion by keeping the soil protected (e.g. minimize disturbed areas) as long as possible by erosion prevention (EP) and second, directs runoff from disturbed areas to locations where suspended soil materials can be removed prior to discharge from the site by sediment control (SC). The use of source control BMPs to control erosion before its starts is the preferred method of long-term sediment control. However, on active construction areas, there may not be sufficient time for EP BMPs to become established to the point at which they are fully effective before the onset of erosive events. In these situations, SC BMPs can provide a more immediate level of protection by removing suspended sediment from



flows before being transported. However, the best protection on active construction sites is generally obtained through simultaneous application of both EP BMPs and SC BMPs. This combination of controls is effective because it prevents most erosion before it starts and has the ability to capture sediments that become suspended before the transporting flows leave the construction site.

BMPs for erosion prevention and sediment control are selected to meet the BMP objectives based on specific site conditions, construction activities, and cost-effectiveness. Different BMPs may be needed at different times during construction since construction activities are constantly changing site conditions.

The following general items are provided to aid in preparing the project plans and choosing appropriate erosion and sediment control BMPs.

Minimize Disturbed Areas

The first step for selecting BMPs is to compare the project layout and schedule with on-site management measures that, where appropriate, can limit the exposure of the project site to erosion and sedimentation. Scheduling and planning considerations are the least expensive way to limit the need for EPSC controls. Consider the following BMPs:

1. Do not disturb any portion of the site unless an improvement is to be constructed there.
2. The staging and timing of construction can minimize the size of exposed areas and the length of time the areas are exposed and subject to erosion.
3. The staging of grading operations should limit the amount of areas exposed to erosion at any one time. Only the areas that are actively involved in cut and fill operations or are otherwise being graded should be exposed. Exposed areas should be stabilized as soon as grading is complete in that area.
4. Retain existing vegetation and ground cover where feasible, especially along watercourses and along the downstream perimeter of the site.
5. Do not clear any portion of the site until active construction begins.
6. Construct outfall detention or perimeter sedimentation control (with filter weirs/berms and temporary sedimentation control barriers first).
7. Quickly complete construction on each portion of the site.
8. Install cover landscaping and other improvements that permanently stabilize each part of the site immediately after the land has been graded to its final contour.



9. Minimize the amount of denuded areas and any new grading activities during the wet months of December through May.
10. Construct permanent stormwater control facilities (e.g., detention basins) early in the project and use for sediment trapping, slope stabilization, velocity reduction, etc. during the construction period.

Stabilize Disturbed Areas

The purpose of site stabilization BMPs is to prevent erosion by covering disturbed soil. This covering may be vegetative, chemical, or physical. Any exposed soil is subject to erosion—either by rainfall striking the ground, runoff flowing over the soil, wind blowing across the soil, and vehicles driving on the soil. Thus all exposed soils should be stabilized except where active construction is in progress. Locations on a construction site which are particularly subject to erosion and should be stabilized as soon as possible include:

1. Slopes
2. Highly erosive soils
3. Construction entrances
4. Stream channels
5. Soil stockpiles

1.4.3.1 Site Perimeter

1. Disturbed areas or slopes that drain toward adjacent properties, storm drain inlets or receiving waters, should be protected with temporary linear barriers (continuous berms, silt fences, sand bags, rolls, etc.) to reduce or prevent sediment discharge while construction in the area is active. In addition, the contractor should be prepared to stabilize those soils with EP measures prior to the onset of rain.
2. When grading has been completed, the areas should be protected with EP controls such as mulching, seeding, planting, or emulsifiers. The combination of EP measures and SC measures should remain in place until the area is permanently stabilized.
3. Significant offsite flows (especially concentrated flows) that drain onto disturbed areas or slopes should be controlled through use of continuous berms, earth dikes, drainage swales, and lined ditches that will allow for controlled passage or containment of flows.
4. Concentrated flows that are discharged off of the site should be controlled through outlet protection and velocity dissipation devices in order to prevent erosion of downstream areas.



5. Perimeter controls should be placed everywhere runoff enters or leaves the site. They are usually installed just before clearing, grubbing and rough grading begin. Perimeter controls for all but the smallest projects will become overloaded by both runoff and sediment. Additional controls within the interior of the construction site should supplement perimeter controls once rough grading is complete.

1.4.3.2 Internal Swales and Ditches

1. More often, flows are directed toward internal swales, curbs, and ditches. Until the permanent facilities are constructed, temporary stormwater facilities will be subjected to erosion from concentrated flows.
2. These facilities should be stabilized through temporary check dams, geotextile mats, and under extreme erosive conditions by lining with concrete.
3. Long or steep slopes should be terraced at regular intervals. Terraces will slow down the runoff and provide a place for small amounts of sediment to settle out.
4. Slope benches may be constructed with either ditches along them or back-sloped at a gentle angle toward the hill. These benches and ditches intercept runoff before it can reach an erosive velocity and divert it to a stable outlet.
5. Overland flow velocities can be reduced by creating a rough surface for runoff to cross (e.g. tall grass).

1.4.3.3 Internal Erosion

Once all other erosion and sediment control BMPs have been exhausted, excessive sediment should be removed from the stormwater both within and along the perimeter of the project site. The appropriate controls work on the same principle: the velocity of sediment-laden runoff is slowed by temporary barriers or traps which pond the stormwater to allow sediments to settle out. Appropriate strategies for implementing sedimentation controls include:

1. Direct sediment-laden stormwater to temporary sediment traps.
2. Locate sediment basins and traps at low points below disturbed areas.
3. Protect all existing or newly-installed storm drainage structures from sediment clogging by providing inlet protection for area drains and curb inlets.
4. Construct temporary sediment traps or ponds at the stormwater outfall(s) for the site.



5. Excavate permanent stormwater detention ponds early in the project, use them as sedimentation ponds during construction, remove accumulated sediment, and landscape the ponds when the upstream drainage area is stabilized.
6. Temporary sediment barriers such as:
 - a. Continuous Berms
 - b. Silt Fences
 - c. Sand Bag Barriers
 - d. Brush or Rock Filter

These barriers should only be used in areas where sheet flow runoff occurs. They are less effective or ineffective if the runoff is concentrated into rill or gully flow.

1.4.3.4 Stormwater Inlets and Outfalls

1. Stormwater inlets, including drop inlets, and pipe inlets, should be protected from sediment intrusion if the area draining to the inlet has been disturbed.
2. Stormwater inlet protection can utilize sand bags, sediment traps, or other similar devices.
3. Internal outfalls must also be protected to reduce scour from high velocity flows leaving pipes or other drainage facilities.

1.4.4 BMPs for Good House Keeping (Section GHP)

Most permanent BMPs will be proposed by the developer early in the planning stage of a project. For most projects, there will be no single BMP which addresses all the long-term stormwater quality problems. Instead, a multi-level strategy will be worked out with the Hopkins County, which incorporates source controls, a series of on-site treatment controls, and community-wide treatment controls.

In most cases permanent BMPs can be implemented most effectively when they can be integrated into other aspects of the project design. This requires that conceptual planning consider stormwater controls rather than as an afterthought to site design. The following should be considered early in the design process.

1. Is a detention/retention facility required for flood control? Often, facilities are required to maintain peak runoff at predevelopment levels to reduce downstream conveyance system damage and other costs associated with flooding. Most permanent BMPs can be incorporated into flood control detention/retention facilities with modest design refinements and limited increases in land area and cost.



2. Planned open space which will be relatively flat (e.g., final grade slopes less than 5 percent) may be merged with stormwater quality/quantity facilities. Such integrated, multi-use areas may achieve several objectives at a modest cost.
3. Infiltration BMPs may serve as groundwater recharge facilities, detention/retention areas may be created in landscaped areas of the project, and vegetated swales/filters may be used as roadside/median or parking lot median vegetated areas.

1.4.5 BMPs for Residential and Homeowners (Section RHP)

Citizens of Madisonville, also hold a stake in the maintenance and improvement of water quality in the community. If residents and property owners would take measures to minimize their impact in their surrounding environment, pollution can be greatly reduced.





Residential and Homeowner BMPs describe methods that individuals can use and employ throughout their community to make ditches, streams and receiving waters safe. The pollutants that they discharge (most of the time unknowingly) can be reduced simply through education. Information on “do’s and don’ts” on chemical treatments (fertilizers, herbicides, insecticides, etc.) and disposal of other hazardous wastes (use of detergents into streams, or dumping petroleum based products into stormwater appurtenances such as catch basins) are just two examples on how to improve the water quality in a community. Madisonville should raise awareness of these BMPs to homeowners and residents via billings or community outreach programs and schools.

1.5 How to Use this Manual













On the opposite page, please find a sample BMP Fact Sheet. This sample helps illustrate and explain the components that make up a fact sheet. Please note that some of the metrics used for the EPP and SMP section were not applicable to other sections and as such are not included.

On the pages following the example please find a summary of the BMPs described in this manual. The summary tables should make it easy for the reader to quickly reference information such as symbols, cost and pollutants targeted by these BMPs.



 <p>1</p>	<p>Madisonville, KY Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)</p>	<p>3 SMP-01</p>	<p>Legend</p> <ol style="list-style-type: none"> 1. Logo of City or Agency 2. BMP Activity Title 3. BMP Activity Number 4. Planning Considerations: <ul style="list-style-type: none"> • Design Life – a quantitative measurement of the BMP's effective life given that proper maintenance procedures are followed • Estimated Unit Cost – general costs are categorized by Low, Medium, High • Monthly Maintenance – approximate frequency of maintenance 5. Typical Photo – photos are included as examples only, and are not meant for use in structural design 6. Suggested BMP symbol to place on ESPC drawings or design plans 7. Suggested BMP planning symbol to place on conceptual drawings or illustrations 8. Target Pollutants Table – likely pollutants to be removed by BMP practice 														
<p>4</p> <p>PLANNING CONSIDERATIONS:</p> <p>Design Life:</p> <p>Acreage Needed: Minimal</p> <p>Estimated Unit Cost: Low</p> <p>Monthly Maintenance:</p>		<p>6</p> 															
	<p>7</p> 																
	<p>Target Pollutants 8</p>																
	<table border="0"> <tr> <td>Significant ♦</td> <td>Partial ♦</td> <td>Low or Unknown ♦</td> </tr> <tr> <td>Sediment ♦</td> <td>Heavy Metals ♦</td> <td>Nutrients ♦</td> </tr> <tr> <td>Oil & Grease ♦</td> <td>Bacteria & Viruses ♦</td> <td>Oxygen Demanding Substances ♦</td> </tr> <tr> <td></td> <td>Floatable Materials ♦</td> <td>Toxic Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ♦</td> </tr> </table>			Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oil & Grease ♦	Bacteria & Viruses ♦	Oxygen Demanding Substances ♦		Floatable Materials ♦	Toxic Materials ♦		
Significant ♦	Partial ♦	Low or Unknown ♦															
Sediment ♦	Heavy Metals ♦	Nutrients ♦															
Oil & Grease ♦	Bacteria & Viruses ♦	Oxygen Demanding Substances ♦															
	Floatable Materials ♦	Toxic Materials ♦															
		Construction Waste ♦															
<p>Description</p> <p>Suitable Applications</p> <p>Approach</p> <p>Installation Procedures</p> <p>Maintenance</p> <p>Inspection Checklist</p>	<p>This section provides a general overview of the BMP activity and introduces common niches where it can be applied.</p> <p>Suitable applications direct the user to the general design limitations and site compatibility for the BMP activity. This section targets situations where the BMP activity could be most effective, and points out situations where the activity should not be implemented.</p> <p>The approach is a suggested plan of action for implementing the BMP activity. This includes specific planning considerations respective to the type of materials, construction planning, and suggests BMPs to install in series in order to maximize benefits.</p> <p>This section provides guidance to design considerations when constructing the BMP, and often references a sample drawing.</p> <p>Although maintenance is often needed after a significant rain event, this section gives detailed guidance to users for the frequency of maintenance specific to each BMP design. Here, the user can find recommended maintenance techniques, frequency of in-active inspection checks, and key areas to maintain in order to maximize the design life of the BMP.</p> <p>The inspection checklist includes key areas for inspectors to check in order to maintain the BMP throughout its design life. This may include design parameters, structural check-ups, or structural inspection after significant rain events.</p>																



Section 3: Construction Site Management Practices for Stormwater Quality Symbology			
BMP	Manual Description	Symbology	
3.2 Erosion Prevention Practices - Fact Sheets			
EPP-01	Tire Washing Facility		TW
EPP-02	Construction Road Stabilization		CRS
EPP-03	Stabilized Construction Entrance		SCE
EPP-04	Buffer Zones		BZ
EPP-05	Temporary Seeding		TS
EPP-06	Permanent Seeding		PS
EPP-07	Sodding		SO
EPP-08	Surface Roughening		SR
EPP-09	Top Soiling		TS
EPP-10	Mulching		M
EPP-11	Nets and Mats		N M
EPP-12	Geotextiles		G



Section 3: Construction Site Management Practices for Stormwater Quality Symbology			
BMP	Manual Description	Symbology	
EPP-13	Terracing		
EPP-14	Soil Binders		
3.3 Sediment Management Practices - Fact Sheets			
SMP-01	Check Dams		
SMP-02	Silt Fence		
SMP-03	Brush or Rock Filters and Continuous Berms		
SMP-04	Sediment Traps		
SMP-05	Temporary Sediment / Detention Basin		
SMP-06	Bank Stabilization		
SMP-07	Rip-rap		
SMP-08	Channel Linings		
SMP-09	Temporary Diversions, Drains, and Swales		
SMP-10	Filter Strips		
SMP-11	Temporary Inlet Protection		
SMP-12	Temporary Outlet Protection		
SMP-13	Slope Drains		



Section 3: Construction Site Management Practices for Stormwater Quality Estimated Unit Costs		
BMP	Manual Description	Cost
3.1 Site Planning and Design Practices - Fact Sheets		
SPD-01 Protecting Sensitive Features		
SPD-01.1	Stream Corridor (Instream Activities)	High
SPD-01.2	Wetlands (Conservation/Permitting)	High
SPD-01.3	Steep Slopes and Highly Erodible Lands	Medium
SPD-01.4	Karst (Avoid; Prohibit Infiltration BMPs)	Medium
SPD-02 Minimizing Impervious Surfaces		
SPD-02.1	Parking Lot Design	Low
SPD-02.2	Street Design	Low
SPD-02.3	Cul-de-sac Design	Low
SPD-02.4	Permeable Pavements	Low
SPD-02.5	Open-Space Preservation	Low
SPD-02.6	Construction Phasing	Low
SPD-03 Vegetative Practices		
SPD-03.1	Vegetative Buffers	Low
SPD-03.2	Disturbed Area Stabilization (Temporary Seeding)	Low
SPD-03.3	Disturbed Area Stabilization (Permanent Seeding)	Low
SPD-03.4	Disturbed Area Stabilization (Mulch)	Low
SPD-03.5	Disturbed Area Stabilization (Sodding)	Low
SPD-03.6	Erosion Control Mats/Blankets	Medium
SPD-04 Land Use Practices		
SPD-04.1	Covenants	High
SPD-04.2	Setbacks and Buffers	High
SPD-04.3	Conservation Easements	High
3.2 Erosion Prevention Practices - Fact Sheets		
EPP-01	Tire Washing Facility	Medium
EPP-02	Construction Road Stabilization	Medium
EPP-03	Stabilized Construction Entrance	Low
EPP-04	Buffer Zones	Low
EPP-05	Temporary Seeding	Low
EPP-06	Permanent Seeding	Low
EPP-07	Sodding	Low
EPP-08	Surface Roughening	Medium
EPP-09	Top Soiling	Medium
EPP-10	Mulching	Low
EPP-11	Nets and Mats	Low
EPP-12	Geotextiles	Low
EPP-13	Terracing	Medium
EPP-14	Soil Binders	



Section 3: Construction Site Management Practices for Stormwater Quality Estimated Unit Costs		
BMP	Manual Description	Cost
3.3 Sediment Management Practices - Fact Sheets		
SMP-01	Check Dams	Low
SMP-02	Silt Fence	Low
SMP-03	Brush or Rock Filters and Continuous Berms	Medium
SMP-04	Sediment Traps	Low
SMP-05	Temporary Sediment / Detention Basin	Medium
SMP-06	Bank Stabilization	Medium
SMP-07	Rip-rap	Medium
SMP-08	Channel Linings	Medium
SMP-09	Temporary Diversions, Drains, and Swales	Medium
SMP-10	Filter Strips	Low
SMP-11	Temporary Inlet Protection	Low
SMP-12	Temporary Outlet Protection	Low
3.4 Good Housekeeping Practices - Fact Sheets		
GHP-01	Dewatering Operations	Medium
GHP-02	Paving Operations	Low
GHP-03	Structure Construction and Painting	Low
GHP-04	Material Delivery, Storage and Use	Low
GHP-05	Spill Prevention and Control	Low
GHP-06	Solid Waste Management	Low
GHP-07	Hazardous Waste Management	Low
GHP-08	Contaminated Soil Management	High
GHP-09	Concrete Waste Management	Low
GHP-10	Sanitary/Septic Waste Management	Low
GHP-11	Vehicle and Equipment Cleaning	Low
GHP-12	Vehicle and Equipment Fueling	Low
GHP-13	Vehicle and Equipment Maintenance	Low
GHP-14	Employee/Subcontractor Training	Low
GHP-15	Pesticides, Herbicides and Fertilizer Use	Low
GHP-16	Dust Control and Tracking	Low
GHP-17	Maintenance of Collection Facilities and Appurtenances	Low
GHP-18	Preservation and Maintenance of Existing Vegetation	Low
GHP-19	System Flushing	Low
3.5 Residential and Homeowners - Fact Sheets		
RH-01	Non-Storm Water Discharge to Storm Drains	Medium
RH-02	Vehicle Washing	Low
RH-03	Vehicle Maintenance and Repairs	Low
RH-04	Landscape Irrigation and Lawn Watering	Low
RH-05	Pesticides and Fertilizers	Low
RH-06	Household Hazardous Waste	Low



Section 3: Construction Site Management Practices for Stormwater Quality Estimated Unit Costs		
BMP	Manual Description	Cost
RH-07	Sanitary Sewer Laterals and Septic Tanks	Low
RH-08	Pet and Animal Waste	Low
RH-09	Slope and Streambank Stabilization	Low
RH-10	Swimming Pools and Spas	Low
RH-11	Boats	Low
RH-12	Tips for Wet Basements and Crawl Spaces	Low



**Section 2: Construction Site Management Practices for Stormwater Quality
Target Pollutant Removal Efficiencies**

BMP	Manual Description	Significant ♦		Partial ◇		Low or Unknown ◇		Oxygen Demanding Substances - Fact Sheets								
		Sediment	Heavy Metals	Nutrients	Toxics	Grease	Bacteria / Viruses	Floatable Materials	Construction Waste							
3.1 Site Planning and Design Practices - Fact Sheets																
SPD-01 Protecting Sensitive Features																
SPD-01.1	Stream Corridor (Instream Activities)	♦	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-01.2	Wetlands (Conservation/Permitting)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-01.3	Steep Slopes and Highly Erodible Lands	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-01.4	Karst (Avoid; Prohibit Infiltration BMPs)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02 Minimizing Impervious Surfaces																
SPD-02.1	Parking Lot Design	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02.2	Street Design	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02.3	Cul-de-sac Design	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02.4	Permeable Pavements	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02.5	Open-Space Preservation	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-02.6	Construction Phasing	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03 Vegetative Practices																
SPD-03.1	Vegetative Buffers	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03.2	Disturbed Area Stabilization (Temporary Seeding)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03.3	Disturbed Area Stabilization (Permanent Seeding)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03.4	Disturbed Area Stabilization (Mulch)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03.5	Disturbed Area Stabilization (Sodding)	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			
SPD-03.6	Erosion Control Mats/Blankets	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇			



**Section 2: Construction Site Management Practices for Stormwater Quality
Target Pollutant Removal Efficiencies**

BMP	Manual Description	SPD-04 Land Use Practices											
		Significant ♦	Partial ♦	Low or Unknown ◇	Sediment	Heavy Metals	Nutrients	Oxygen Demanding Substances	Toxics	Grease	Bacteria / Viruses	Floatable Materials	Construction Waste
SPD-04.1	Covenants	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
SPD-04.2	Setbacks and Buffers	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
SPD-04.3	Conservation Easements	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
3.2 Erosion Prevention Practices - Fact Sheets													
EPP-01	Tire Washing Facility	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-02	Construction Road Stabilization	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-03	Stabilized Construction Entrance	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-04	Buffer Zones	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
EPP-05	Temporary Seeding	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-06	Permanent Seeding	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-07	Sodding	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-08	Surface Roughening	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-09	Top Soiling	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
EPP-10	Mulching	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-11	Nets and Mats	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-12	Geotextiles	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-13	Terracing	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
EPP-14	Soil Binders	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
3.3 Sediment Management Practices - Fact Sheets													
SMP-01	Check Dams	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-02	Silt Fence	♦	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇



Section 2: Construction Site Management Practices for Stormwater Quality Target Pollutant Removal Efficiencies											
BMP	Manual Description	Heavy Metals			Oxygen Demanding Substances			Toxics			Construction Waste
		Sediment	Nutrients	Substances	Toxics	Grease	Viruses	Materials			
SMP-03	Brush or Rock Filters and Continuous Berms	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-04	Sediment Traps	◆	◇	◇	◇	◇	◇	◇	◆	◇	◇
SMP-05	Temporary Sediment / Detention Basin	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-06	Bank Stabilization	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-07	Rip-rap	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-08	Channel Linings	◆	◆	◇	◇	◇	◇	◇	◇	◇	◇
SMP-09	Temporary Diversions, Drains, and Swales	◆	◆	◇	◇	◆	◇	◇	◇	◇	◇
SMP-10	Filter Strips	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-11	Temporary Inlet Protection	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
SMP-12	Temporary Outlet Protection	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
3.4 Good Housekeeping Practices - Fact Sheets											
GHP-01	Dewatering Operations	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-02	Paving Operations	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-03	Structure Construction and Painting	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-04	Material Delivery, Storage and Use	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-05	Spill Prevention and Control	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-06	Solid Waste Management	◇	◇	◇	◇	◇	◇	◇	◆	◇	◇
GHP-07	Hazardous Waste Management	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-08	Contaminated Soil Management	◇	◇	◇	◇	◇	◆	◇	◇	◇	◇
GHP-09	Concrete Waste Management	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-10	Sanitary/Septic Waste Management	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-11	Vehicle and Equipment Cleaning	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-12	Vehicle and Equipment Fueling	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇

Significant ◆ Partial ◇ Low or Unknown ◇



**Section 2: Construction Site Management Practices for Stormwater Quality
Target Pollutant Removal Efficiencies**

BMP	Manual Description	Heavy Metals			Oxygen Demanding Substances			Toxics	Oils / Grease	Bacteria / Viruses	Floatable Materials	Construction Waste
		Sediment	Nutrients	Substances	Nutrients	Substances	Toxics					
		Significant ♦	Partial ♦	Low or Unknown ◇								
GHP-13	Vehicle and Equipment Maintenance	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-14	Employee/Subcontractor Training	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-15	Pesticides, Herbicides and Fertilizer Use	◇	◆	◇	◆	◇	◆	◇	◇	◇	◇	◇
GHP-16	Dust Control and Tracking	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
GHP-17	Maintenance of Collection Facilities and Appurtenances	◆	◇	◆	◆	◇	◇	◆	◇	◆	◇	◇
GHP-18	Preservation and Maintenance of Existing Vegetation	◆	◆	◆	◆	◇	◇	◇	◇	◆	◇	◇
GHP-19	System Flushing	◆	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
3.5 Residential and Homeowners - Fact Sheets												
RH-01	Non-Storm Water Discharge to Storm Drains	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆
RH-02	Vehicle Washing	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇	◇
RH-03	Vehicle Maintenance and Repairs	◇	◇	◇	◇	◇	◆	◆	◆	◇	◇	◇
RH-04	Landscape Irrigation and Lawn Watering	◇	◆	◇	◆	◇	◆	◇	◇	◇	◇	◇
RH-05	Pesticides and Fertilizers	◇	◆	◇	◆	◇	◆	◇	◇	◇	◇	◇
RH-06	Household Hazardous Waste	◇	◆	◇	◆	◇	◆	◇	◇	◇	◇	◇
RH-07	Sanitary Sewer Laterals and Septic Tanks	◇	◆	◇	◆	◇	◇	◇	◆	◇	◇	◇
RH-08	Pet and Animal Waste	◇	◆	◇	◆	◇	◇	◇	◆	◇	◇	◇
RH-09	Slope and Streambank Stabilization	◆	◆	◇	◆	◇	◇	◇	◇	◆	◇	◇
RH-10	Swimming Pools and Spas	◇	◇	◇	◆	◇	◆	◇	◇	◇	◇	◇
RH-11	Boats	◇	◆	◇	◆	◇	◆	◇	◆	◆	◇	◇
RH-12	Tips for Wet Basements and Crawl Spaces	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆	◆



Section 2 EROSION PREVENTION AND SEDIMENT CONTROL PLAN

2.1 Requirements

The City of Madisonville, KY will require an Erosion Prevention and Sediment Control (EPSC) Plan for most types of development construction. When preparing the EPSC Plan, the design engineer and/or developer should determine the best practices to protect active construction sites by selecting source control and sediment containment practices. In doing so, most erosion problems can be avoided and sediment containment issues can be addressed prior to construction disturbances.

Site characteristics such as soil types, topography, slopes, and geography, and construction methods should be thoroughly reviewed when selecting BMPs to implement throughout the life of the project. The design team should be mindful of how the site is changing throughout the project so that BMPs can be repaired, modified or replaced with a more suitable practice.

For more information regarding the required elements of an EPSC Plan, refer to **Appendix B – EPSC Plans**.

2.2 Minimize Disturbed Areas

Some important decisions must be made prior to BMP selections for a proposed construction site.

Construction planning and sequencing are the least expensive methods to reduce and control erosion and sediment. The following points should be considered when to minimize disturbed areas:

1. Do not disturb areas of the construction site that are not scheduled for improvements and keep existing vegetation, even if it is scheduled to be removed, for as long as possible.
2. Carefully schedule and phase construction. Avoid grading during wet months (December through May). Use temporary cover measures (seed or mulch) whenever construction is halted for an extended period.
3. Phase site grading to limit the amount and time of an area's exposure. Exposed areas should be stabilized immediately following the completion of grading.
4. Plan and implement permanent structures throughout the earlier phases of the project. This will maximize the utility practice's usefulness and help with erosion prevention and sediment containment.



5. Avoid delays and work expeditiously on any part of the site. Install landscaping fixture upon the completion of any sequence and prior to moving on to the next phase.

Any exposed soil is subject to erosion and sediment transport, even by a single rain drop. Designers and contractors should make every effort to stabilize the following susceptible areas at a construction site prior to and throughout construction:

- Slopes
- Highly erosive soils
- Construction entrances and exits
- Stream channels
- Soil stockpiles

2.3 Site Perimeter Controls

The contractor must set site perimeter controls to protect areas downstream from erosion, sediment and flooding problems.

Area of Concern	Site Perimeter Control
Disturbed areas or slopes that drain toward adjacent properties	Continuous berms, silt fences, sandbags
Stabilizing area after grading has been completed	Mulching, seeding, planting, emulsifiers, or a combination of two or more
Off site flows that enter the constructions site	Continuous berms, earth dikes, drainage swales and lined ditches
Concentrated flows that leave the construction site	Outlet control measures that will dissipate velocities

Additional controls within the interior of construction site should supplement perimeter controls once rough grading is complete.

2.4 Internal Erosion and Drainage Design

Once the perimeter controls have been selected, the issue of internal erosion and drainage controls must be addressed. Internal practices are typically more time consuming and labor intensive since they will be used in close proximity of construction activities. They are required early in the project until permanent practices can be implemented.



Some of the internal erosion and drainage design practices to be used include:

- Check dams, geotextile mats, and under extreme circumstances concrete channel lining.
- Terracing at regular intervals.
- Slope benches or ditches.
- Surface roughening or temporary seeding.

2.5 Maintenance and Inspection

Constant inspection and maintenance of the selected practices are critical towards the success of preventing erosion and sediment transport. Maintaining a daily or weekly checklist of practices to inspect for deficiencies of those practices are critical to the success of preventing erosion and sediment displacement.

A good way to ensure that all practices will be properly utilized is for the contractor to arrange a pre-construction meeting with the City of Madisonville's Stormwater Inspector. This meeting should take place after the Notice to Proceed, but prior to the mobilization of equipment.

One of the most critical aspects of maintaining the construction site's BMPs is to have a plan on when sediment should be removed from the utilized practices, and where should it be placed. The BMPs in this manual often suggest when sediment should be removed from structures, but the contractor should demonstrate sound judgment in maintaining the structures more frequently if necessary.

A sound inspection and maintenance strategy should include the following:

1. Verify that sediment-laden stormwater is directed to temporary sediment traps or basins. Verify that sediment basins and traps are at low points below disturbed areas.
2. Protect all existing or newly installed storm drainage structures from sediment clogging by providing inlet protection for area drains and curb inlets. Stormwater inlet protection can utilize sand bags, sediment traps, or other similar devices.
3. Excavate permanent stormwater detention ponds early in the project, use them as sedimentation ponds during construction, remove accumulated sediment, and landscape the ponds when the upstream drainage area is stabilized.
4. Inspect temporary sediment barriers such as silt fences, rock filters, and continuous berms after every rainfall. These barriers should only be used in areas where sheet flow runoff occurs. They are ineffective if the runoff is concentrated into rill or gully flow.



5. Internal outfalls must also be protected to reduce scour from high velocity flows leaving pipes or other drainage facilities.

2.6 EPSC Preparation Guidance

The EPSC Plan will consist of a site plan sheet at a scale suitable for illustrating the elements that will control erosion and sediment, and a set of directions in narrative form within the contract documents. The Owner of the development or project will be responsible for preparing the EPSC Plan. Whether it is the Owner, designer or a subcontractor to develop the plans, the matter is left up to the Owner.

The plans will illustrate which practices shall be used and their placement within the project. The narrative will explain decisions concerning erosion and sediment control, and when required, show why those measures were selected, either by calculations or sound engineering judgment. This will allow the reviewer to make informed decisions on the efficiency and practicality of the BMPs selected.

The level of detail shown on the drawings depends on the magnitude of the project. For single lots, a sketch may be all that is required to show the inspector. However for larger developments, such as a shopping center or industrial park, a plan sheet at an appropriate scale shall be submitted to the City for review.

Here is a list of typical notes that should be added to every EPSC plan, large and small.

1. As a minimum, all erosion and sediment control practices will be constructed and maintained according to the standards located in the City of Madisonville's BMP Manual, Stormwater Ordinances, and as required by state and federal laws.
2. A copy of the approved Erosion Prevention and Sediment Control Plans shall be maintained at the project site at all times. This copy shall be presented to the City of Madisonville's representatives upon request.
3. Prior to commencing land-disturbing activities in any area not on the approved erosion and sediment control plan, the contractor shall submit a supplementary erosion control plan to the City of Madisonville for review and approval.
4. All erosion and sediment control measures are to be placed prior to or as the first step in clearing and grading. The contractor is responsible for any additional erosion control measures necessary to prevent erosion and sedimentation as determined by the City of Madisonville.
5. During dewatering operations water must be pumped through an approved filtering device. The City of Madisonville may suspend dewatering operations if pollution is observed.



6. The contractor shall inspect all erosion and sediment control devices at least once a week and at least once a day during rainfall events. The contractor shall perform any repairs or maintenance immediately in order to ensure effective erosion and sediment control.
7. The contractor shall maintain a record of all inspections and maintenance activities at the project site. This record shall be made available to the City of Madisonville upon request.

2.7 Storm Water Pollution Protection Plan

Requirements of the Storm Water Pollution Protection Plan (SWPPP) are discussed in **Appendix C –BMP Plans**.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-01						
	Activity: Tire Washing Facility (TW)							
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: Minimal Estimated Unit Cost: Medium Annual Maintenance: Negligible		<table border="1" style="width: 100%; height: 100%;"> <tr><td style="width: 50%; height: 20px;"> </td><td style="width: 50%;"> </td></tr> <tr><td style="width: 50%; height: 20px;"> </td><td style="width: 50%;"> </td></tr> <tr><td style="width: 50%; height: 20px;"> </td><td style="width: 50%;"> </td></tr> </table>						
	Target Pollutants	<div style="border: 1px solid black; padding: 10px; width: 80px; margin: 0 auto;"> TW </div>						
	Significant ◆ Partial ◆ Low or Unknown ◇							
	Sediment ◆ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇							
Description Suitable Applications Approach	<p>As a result of vehicular ingress and egress to the construction site, the facility would remove mud and dirt from vehicle tires and the undercarriage to prevent materials from depositing onto public roads. This application can be used in conjunction with the stabilized construction entrance, EPP-03.</p> <ul style="list-style-type: none"> ➤ Temporary construction traffic, phased construction projects and off-site road access. ➤ Typically used for large construction sites. <ul style="list-style-type: none"> ➤ Incorporate with the stabilized construction entrance, EPP-03. ➤ Construct wash rack on level ground when possible, on a pad of course aggregate. ➤ Design tire rack to withstand anticipated traffic loads and drain to a detention pond or swale. A typical wash rack has been shown in the standard details. However, wash rack design may consist of other materials or configuration as long as it provides the intended function. ➤ If a swale is required, then it shall provide sufficient grade, width, and depth to carry runoff. ➤ The swale shall carry runoff from the wash area to a sediment-trapping device such as a check dam. ➤ All employees, contractors, subcontractors, and others that leave the site with mud caked tires and/or undercarriages shall use construction entrance. 							

Activity: Tire Washing Facility (TW)**EPP-01****Installation
Procedures for
Tire Washing
Facility**


- A geotextile underliner must be placed under the entire length and width of the stabilized entrance, but not under the wash rack.
- Place a layer of KTC No. 1 or No. 2 stone across the full width of the exit and construct on level ground with a minimum thickness of 6-inches.
- The length of the stabilized entrance shall be as required based on the application, unless approved otherwise by the City Engineer.
- The width of the pad shall be a minimum of 12-feet, unless approved otherwise by the City Engineer.
- If a swale is required, then it shall meet specific requirements needed to carry the wash runoff to a sediment-trapping device.

Maintenance

- Remove accumulated sediment to maintain system performance, in the wash rack and/or sediment trap.
- Inspect at the end of each shift or workday for damage and repair as needed.
- Remove any mud tracked onto adjacent roadway by sweeping or scraping as necessary.

**Inspection
Checklist**

- Vehicles are leaving the site through designated construction exit(s).
- Mud, dust or dirt is removed prior to exit onto the adjacent road.
- The construction exit is sufficiently maintained to prevent mud, dirt, fines and dust from being tracked off-site.
- Stones under wash rack have been maintained and free of deleterious materials.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-02	
	Activity: Construction Road Stabilization (CRS)		
PLANNING CONSIDERATIONS: Design Life: 2 yrs Acreage Needed: Variable Estimated Unit Cost: Medium Monthly Maintenance: Negligible		== CRS == CRS ==	
		<div style="border: 1px solid black; padding: 5px; display: inline-block;">CRS</div>	
	Target Pollutants		
	Significant ♦	Partial ♦	Low or Unknown ◇
	Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ♦ Construction Waste ◇		
Description	Construction vehicles frequently use access roads, subdivision roads, parking areas and other on-site transportation routes that are not accessible to the public. Construction specifications and drawings should demonstrate methods and practices to stabilize these routes to reduce erosion between the time of initial grading and final stabilization.		
Suitable Applications	<ul style="list-style-type: none"> ➤ Temporary construction traffic routes, phased construction projects and off-site road access. ➤ Detour roads for local or temporary construction traffic. ➤ Construction during wet weather. ➤ Construction roads utilizing a temporary stream crossing must be indicated and approved. 		
Approach	<ul style="list-style-type: none"> ➤ Road should follow topographic contours to reduce erosion of the roadway. ➤ Gravel road should be of sufficient thickness to support construction traffic. ➤ Chemical stabilizers or water are usually required on gravel or dirt roads to prevent dust. No additional costs for dust control on construction roads should be required above that needed to meet local air quality requirements. 		

Design Considerations for Construction Road Stabilization

- All existing vegetation (trees, bushes, ground cover) shall be retained as long as feasibly practicable to reduce the exposure of disturbed grounds. Removal of vegetation should be phased in concurrence with relative construction activities within the vicinity.
- The implementation of this BMP depends largely on climate and weather conditions. Alternative routes should be established to incorporate these measures to account for conditions such as dry areas, wet conditions and other circumstances that would inhabit a safe and stable route for construction traffic. Permanent roads and parking areas should be paved as soon as possible after grading. The early application of gravel or chemical stabilization may solve potential erosion and stability problems where construction will be phased. Temporary gravel roadways should be considered during the wet weather seasons and on slopes greater than 5 percent.
- When gravel roads are needed, a minimum 6-in. course of 2 to 3-in. crushed rock, gravel base, or crushed surfacing base course should be applied immediately after grading or the completion of utility installation within the right-of-way. Chemical stabilization may also be used upon compacted native sub-grade. These chemical controls should be applied per the manufacturer's directions.
- Roadways should be carefully graded to drain transversely. Provide drainage swales on each side of the roadway in the case of a crowned section, or one side in the case of super-elevated section. Simple gravel berms without a trench can also be used.
- Installed inlets should be protected to prevent sediment-laden water from entering the storm sewer system.

Temporary Roads and Parking Areas

- **Grade**
 - The gradient and vertical-horizontal alignment should be designed according to the intended traffic patterns.
 - Grades for temporary roads should not exceed 10% for lengths less than 200 LF.
 - Frequent grade changes can reduce erosion and improve sediment control.
 - Grades for parking areas should not exceed 4%.
- **Width**
 - The radius for temporary roads should not be less than 35-feet for standard construction vehicles, and 50-feet for tractor trailers.
 - Temporary road widths should not be less than 14-feet for one-way traffic, 20-feet for two-way traffic.
 - Temporary roads should include two shoulders with a minimum width of two feet on each side.
- **Side Slopes**
 - All cuts and/or fills should be graded at a slope of 2:1 whenever possible.
 - A slope of 3:1 should be used whenever machined mowing will be used to maintain ground cover.
- **Drainage**
 - The design and capacity of all drainage structures should be consistent with sound engineering principles and suitable for the type of road that will be eventually permanent.
 - Structures should withstand flows from a 25-year, 24-hour storm event.

Activity: Construction Road Stabilization

EPP-02

Design Considerations (cont'd)

- **Stabilization**
 - Install a 6-inch layer of coarse aggregate immediately after grading or utility installation within the right-of-way.
 - For added stability, a geotextile should be installed beneath the base stone.
 - All adjacent drainage swales, cuts, and fills shall be properly seeded or sodded.
- **Permanent Roads and Parking Areas**
 - Permanent roads and parking areas should be designed to the codes and standards of the local authority and the Kentucky Transportation Cabinet.
 - Permanent roads should have an initial base coarse of gravel immediately after site grading.

Maintenance

- Periodically apply additional aggregate on gravel roads.
- Active dirt construction roads are commonly watered three or more times per day during the dry season.
- Remove silt and debris from road side ditches and swales to prevent clogging or damming.
- Inspect weekly, and after each rain event and repair any eroded areas immediately.

Inspection Checklist

- Gravel roads are preventing mud and dirt from leaving project area.
- Dirt and gravel roads do not show signs of erosion, including but not limited to, rill and gully erosion.
- All stream crossings are maintained as mandated by the appropriate general or individual permit.

Activity: Stabilized Construction Entrance





EPP-03

Maintenance

- Inspect weekly and after each rainfall.
- Periodically requires addition of stones for top; add gravel material when soil sub grade becomes visible.
- Remove all mud or sediment deposited on paved roadways as necessary.
- Stir aggregate with back-hoe on a weekly basis or as required based on construction activity.

Inspection Checklist

- Entrance/exits are exclusively used by all traffic.
- Construction exit is sufficiently maintained to prevent mud, dirt, and dust from being tracked off-site, and stone has been stirred with back-hoe.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-04
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: 60% of Installation		 
Target Pollutants		
<div style="display: flex; justify-content: space-around;"> Significant ◆ Partial ◆ Low or Unknown ◆ </div>		
<div style="display: flex; justify-content: space-between;"> <div style="display: flex; gap: 10px;"> Sediment ◆ Heavy Metals ◆ Nutrients ◆ </div> <div style="display: flex; gap: 10px;"> Oxygen Demanding Substances ◆ Toxic Materials ◆ </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> Oil & Grease ◆ Bacteria & Viruses ◆ Floatable Materials ◆ Construction Waste ◆ </div>		
Description Suitable Applications	<p>Buffer zones allow the utilization of vegetation to protect soils from erosion as well as reduce the velocity of runoff. This BMP allows the removal of sediment through filtering and settling. This management practice is likely to create a significant reduction in sediment by reducing erosion and retaining plant vegetation along waterways.</p> <ul style="list-style-type: none"> ➤ There are two types of buffer strips: General Buffers and Vegetated Riparian Buffers. <ul style="list-style-type: none"> • <i>General Buffers:</i> A strip of original, undisturbed land adjacent to the disturbed site provides a general buffer. • <i>Vegetated Riparian Buffers:</i> Buffers that provide protection to adjacent streams by filtering overland flow of sediments and strengthening bank stabilization. These buffers are also useful by cooling streams to promote plant and fish habitation and providing food for the surrounding wildlife. ➤ Utilization or reinforcement of existing vegetation is preferred. However, where improvements are required; sodding, plugging, use of stockpiled vegetation or seeding is acceptable. ➤ Sodding is appropriate if it is part of the no construction activity area that contained turf prior to construction, or for any graded or cleared areas that might erode and where a robust plant cover is needed immediately. ➤ Plantings for buffer reestablishment and enhancement can consist of bare root seedlings, container grown seedlings, container grown plants and balled and burlapped plants. Standard permanent erosion control grasses and legumes may be used in denuded areas for quick stabilization. ➤ Soil preparation and maintenance are essential for the establishment of planted vegetation. 	

Approach***General Buffers***

- A sufficient width should be selected to promote plantings' growth and to serve as a filter of overland flow entering the zone.

Vegetated Riparian Buffers

- Prior to structuring the zone, careful consideration should be given to its intent and purpose and how it should be enhanced to meet the requirements of the buffer zone. Stream characteristics such as width, slope, depth and the topography of the surrounding vicinity should be considered.
- Stream buffers must at least include the floodway plus 50 feet perpendicular to the floodway. If a floodway has not been determined, the buffer must be at least 25 feet perpendicular from each side of the stream bank, creek, or unnamed waterway, under "bank-full" conditions.
- Stream buffers are typically 50 feet wide for flat lying areas.
- A buffer should be increased 2 feet in width for every 1% of slope perpendicular to the centerline of the stream.
- If existing vegetation is disturbed or removed, a new multipurpose buffer should be created using the three following zones:
 - Zone 1 – the first 20-feet adjacent to the stream should include trees and shrubs spaced 6-10 feet apart to provide stabilization of the bank deep into the soil.
 - Zone 2 – The next 10-feet should consist of managed forest for chemical absorption and wildlife habitat.
 - Zone 3 – the upper 20-feet should be comprised of grasses for sediment and chemical capture as well as noise reduction.

Maintenance

- Inspect sod installations weekly and after significant storm events, until the turf is established, and routinely thereafter.
- Maintenance shall consist of mowing, weeding, and ensuring that the irrigation system is operating properly and as designed to sustain growth.
- Inspect buffer strips weekly and after significant storm events until vegetation is established, and routinely thereafter. Repair eroded or damaged areas as needed to maintain original purpose and effectiveness of the buffer strip.
- Provisions to maintain and protect new plantings from native wildlife should be incorporated with the design documents and drawings.

Inspection Checklist

- Sod is properly maintained and watered.
- Buffer strips are properly maintained.
- Plantings are sufficiently protecting from wildlife.
- Significant rainstorm events have not deteriorated buffer zone.

**Installation/
Applications**

Seed bed Preparation

- Prepare area to be seeded.
- Apply seed, fertilizer, and lime as required
- Apply mulch as specified in [EPP-10](#).
- Grade as needed to permit the use of conventional equipment for seedbed preparation, fertilization and seeding.
- Apply to bare or denuded areas, soil stockpiles, if they will not be used for more than 21 consecutive days.
- Soil material should be capable of supporting permanent vegetation and have at least 25% silt and clay to sufficiently hold moisture during establishment.
- In compacted areas, soil should be loosened to a depth of 6-8 inches.
- Protect areas against seed wash-out using surface roughening diversions or terraces.
- Soil should be analyzed for fertilizer and lime requirements.

Conventional Seeding

- Work lime and fertilizer into the soil with disk harrow, springtooth harrow or like equipment to a depth of 2 inches.
- Apply seeding uniformly with a cyclone or drill. Seed no deeper than ¼" to ½".
- Weather conditions should be taken into account when seeding areas. Seeding should not take place during adverse weather conditions.

Hydroseeding

A practice of applying a hydraulic spray that seeds, fertilizes and tacks in a single step.

- Prepare a homogenous mixture in a slurry tank: Seed (inoculated if needed), fertilizer, wood cellulose or wood pulp fiber mulch, and water. (Ordinary mulch is not suitable for hydroseeding).
- Apply within one hour after mixture is prepared. The application rate should be approximately 35 lbs per 1000 sq ft.
- Spray in two, orthogonal directions (i.e. north/south and east/west) for an even distribution of the hydroseed mixture.
- A straw mulch can be applied after hydroseeding at a rate of 100 lbs per 1000 sq. ft.

The chart below displays the recommended rates for temporary seeding.

Seeding Rates

March 1 to October 31	Per 1000 SF	Per Acre
Oats	3 lbs	120 lbs
Perennial Ryegrass	1 lbs	40 lbs
Tall Fescue	1 lbs	40 lbs
Wheat	1 lbs	40 lbs
Annual Rye	3 lbs	120 lbs
<hr/>		
November 1 to February 28	Per 1000 SF	Per Acre
Annual Rye	3 lbs	120 lbs
Wheat	3 lbs	120 lbs
Perennial Ryegrass	1 lbs	40 lbs
Tall Fescue	3 lbs	120 lbs





Source: Kentucky EPPC Field Guide

Activity: Temporary Seeding**EPP-05**

- Maintenance**
- Inspect frequently during the first six weeks following planting to assure that appropriate moisture levels are maintained and determine if stands are uniform and dense.
 - Water until grass is thoroughly established, especially during dry, hot seasons or adverse conditions.
 - Check for damage caused by equipment or heavy rains. Damaged areas should be repaired, fertilized, seeded, and mulched. Tack or tie down mulch as necessary.

Inspection Checklist

- Area is watered daily until stabilization has taken place.
- After stabilization, water as needed.
- Heavy equipment has not been used within area.
- Washout areas have been repaired.
- Vegetative coverage is (check one): 20-40% 40-60% 60-80% 80-100%

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-06																
	Activity: Permanent Seeding (PS)																	
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: As Needed Estimated Unit Cost: Low Annual Maintenance: 20% of Capital Costs																		
																		
		Target Pollutants																
		<table border="0"> <tr> <td>Significant ♦</td> <td>Partial ♦</td> <td>Low or Unknown ♦</td> </tr> <tr> <td>Sediment ♦</td> <td>Heavy Metals ♦</td> <td>Nutrients ♦</td> </tr> <tr> <td>Oil & Grease ♦</td> <td>Bacteria & Viruses ♦</td> <td>Floatable Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Oxygen Demanding Substances ♦</td> </tr> <tr> <td></td> <td></td> <td>Toxic Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ♦</td> </tr> </table>	Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦			Oxygen Demanding Substances ♦			Toxic Materials ♦	
Significant ♦	Partial ♦	Low or Unknown ♦																
Sediment ♦	Heavy Metals ♦	Nutrients ♦																
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦																
		Oxygen Demanding Substances ♦																
		Toxic Materials ♦																
		Construction Waste ♦																
Description	Permanent seeding establishes a permanent ground cover over disturbed areas. This practice can greatly reduce erosion from a disturbed area.																	
Suitable Applications	<ul style="list-style-type: none"> ➤ Permanent seeding can be used to reduce sediment runoff from disturbed areas during construction. ➤ Permanent seeding can reduce air born pollutants arising from construction disturbances. 																	
Approach	<ul style="list-style-type: none"> ➤ <u>Conventional Seeding</u> Common methods of application include: disc, cultivator, broadcasting, and no-till drilling. ➤ <u>Hydroseeding</u> Hydroseeding uses a mixture of mulch, seed, and tactifier which is sprayed over a disturbed area for coverage. ➤ Permanent seeding shall be applied to disturbed areas within 14 days of final grading unless Temporary Seeding - EPP-05, is to be used in the interim. ➤ This practice can be used in conjunction with other BMPs to reduce erosion during and after construction. 																	

Installation Procedures**Conventional Method**

- Soil material should be capable of supporting permanent vegetation and have at least 25 % silt and clay to sufficiently hold moisture during establishment.
- In compacted areas, soil should be loosened to a depth of 6-8 inches.
- The area shall be protected from excess runoff as necessary with diversions or berms.
- Plant species shall be selected on the basis of quick germination, growth, and time of year to be seeded.
- Fertilizer, lime, seedbed preparation, seed coverage, mulch, and irrigation shall be used as necessary to promote early establishment.
- Weather conditions should be taken into account when seeding areas. Seeding should not take place during or under pending adverse weather conditions.

Seeding

- Soil should be analyzed for fertilizer and lime requirements.
- Prepare seedbed with agricultural ground limestone, at a rate of 1 ton per acre, or as determined by soil testing.
- Use a 10-10-10 fertilizer shall be applied at a rate of 800 lbs per acre, or as determined by soil testing.
- Work lime and fertilizer into the soil with disk harrow, springtooth harrow or like equipment to a depth of 4 inches.
- Protect areas against seed wash-out using surface roughening diversions or terraces.
- See [Table EPP-06-01](#), Suggested Seeding Rates, on the following page.
- Apply mulch as specified in [EPP-10](#).

Hydroseeding

A practice of applying a hydraulic spray that seeds, fertilizes and tacks in a single step.

- Prepare a homogenous mixture in a slurry tank: Seed (inoculated if needed), fertilizer, wood cellulose or wood pulp fiber mulch, and water. (Ordinary mulch is not suitable for hydroseeding).
- Apply within one hour after mixture is prepared. The application rate should be approximately 35 lbs per 1000 sq ft.
- Spray in two, orthogonal directions (i.e. north/south and east/west) for an even distribution of the hydroseed mixture.
- A straw mulch can be applied after hydroseeding at a rate of 100 lbs per 1000 sq. ft.

Maintenance





- Water soil until the grass is firmly established, especially if seedlings are made late in the planting season.
- Inspect all seeded areas for failures and make necessary repairs.
- If stand is inadequate (less than 80% coverage) overseed, fertilize, using half of the original rates.
- If stand is more than 60% damaged, reestablish following original seedbed preparation methods, seeding and mulching recommendation and apply lime and fertilizer as needed according to a new soil test.

Inspection Checklist

- Area is watered daily until stabilization has taken place.
- Area has been maintained (watered, repaired) since stabilization.
- Heavy equipment has not been used within area.
- Eroded areas have been regarded and re-established.

**Table EPP-06-01
Suggested Seeding Rates**

<i>Recommended Seed Blend for Kentucky</i>		
Seed Species and Mixtures	Seeding Rate / Acre	Per 1000 sq. ft.
<i>Seed and seed mixtures for relatively flat or slightly sloping areas</i>		
Perennial ryegrass	25 to 35 lbs.	1 lb.
+ tall fescue	15 to 30 lbs.	1 lb.
Tall fescue	40 to 50 lbs.	1.5 lbs.
+ ladino or white clover	1 to 2 lbs.	2 oz.
<i>Steep slopes, banks, cuts, and other low maintenance areas (not mowed)</i>		
Smooth bromegrass	25 to 35 lbs.	1 lb.
+ red clover	10 to 20 lbs.	0.5 lb.
Tall fescue	40 to 50 lbs.	1 lb.
+ white or ladino clover	1 to 2 lbs.	2 oz.
Orchardgrass	20 to 30 lbs.	1 lb.
+ red clover	10 to 20 lbs.	0.5 lb.
+ ladino clover	1 to 2 lbs.	2 oz.
Crownvetch	10 to 12 lbs.	0.25 lb.
+ tall fescue	20 to 30 lbs.	1 lb.
<i>Lawns and other high traffic or high maintenance areas (mowed)</i>		
Bluegrass	105 to 140 lbs.	3 lbs.
Perennial ryegrass (turf)	45 to 60 lbs.	2 lbs.
+ bluegrass	70 to 90 lbs.	2.5 lbs.
Tall fescue (turf type)	130 to 170 lbs.	4 lbs.
+ bluegrass	20 to 30 lbs.	1 lb.
<i>Ditches and other areas of concentrated water flows</i>		
Perennial ryegrass	100 to 150 lbs.	3 lbs.
+ white of ladino clover	1 to 2 lbs.	2 oz.
Kentucky bluegrass	20 lbs.	0.5 lb.
+ smooth bromegrass	10 lbs.	0.25 lb.
+ switchgrass	3 lbs.	2 oz.
+ timothy	4 lbs.	0.25 lb.
+ perennial ryegrass	10 lbs.	0.25 lb.
+ white of ladino clover	1 to 2 lbs.	2 oz.
Tall fescue	100 to 150 lbs.	3 lbs.
+ ladino or white clover	1 to 2 lbs.	2 oz.
Tall fescue	100 to 150 lbs.	3 lbs.
+ perennial ryegrass	15 to 20 lbs.	0.5 lb.
+ Kentucky bluegrass	15 to 20 lbs.	0.5 lb.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-07
Activity: Sodding (SO)		
PLANNING CONSIDERATIONS: Design Life: Permanent Acraege Needed: As required Estimated Unit Cost: Medium Monthly Maintenance: 30% of installation		 
	Target Pollutants	
	Significant ♦ Partial ♦ Low or Unknown ◇	
	Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description Suitable Applications Approach Installation Procedures	<p>Sodding is a method used to quickly establish permanent grass stands. This practice can prove very effective in quickly stabilizing critical, erosion-prone areas.</p> <ul style="list-style-type: none"> ➤ Ditches or channels carrying intermittent flow. ➤ Areas around drop inlets in grass swales. ➤ Residential or commercial lawns that would be aesthetically enhanced sodding. ➤ Other critical areas not previously described. <ul style="list-style-type: none"> ➤ Establish permanent grass stands quickly. ➤ Prevent erosion by stabilizing formerly denuded areas. ➤ Reduce the amount of air borne sediment, dust and mud leaving the project site. ➤ Stabilize channels where concentrated overland flow occurs. <p><i>Site Preparation</i></p> <ul style="list-style-type: none"> ➤ Soil material should be capable of supporting permanent vegetation and have at least 25 % silt and clay to sufficiently hold moisture during establishment. ➤ In compacted areas, soil should be loosened to a depth of 6-8 inches. ➤ Stockpile unwanted topsoil to be used in other areas at the construction site. ➤ Grade and prepare the area for conventional construction equipment to be used for preparing the sod bed. 	

Installation Procedures (cont'd)*Sod Bed Preparation*

- Soil should be analyzed for fertilizer and lime requirements.
- Use a 10-10-10 fertilizer shall be applied at a rate of 1,000 lbs per acre, or as determined by soil testing.
- Work lime and fertilizer into the soil with disk harrow, springthooth harrow or like equipment to a depth of 4 inches.
- Clear vicinity of deleterious materials and stones greater than 4" in diameter prior to laying sod.
- Loosen the top one-inch of soil prior to saying the sod pieces.

Handling

- Sod should be kept moist and covered during transport and preparation.
- Sod should be free of noxious and secondary weeds and secured from good, thick growing stands.
- Sod should be mowed to a height between 2-4 inches.

Placement





- Do not place sod in freezing conditions (ambient temperatures less than 32° F.)
- Sod shall be placed and pressed together such that it will be continuous.
- The outer edges of the sod placed along curbing or side walks shall be sufficiently deep so that the surface water will flow over onto the top of the sod.
- In swales and ditches, lay sod strips perpendicularly to the centerline of the channel.
- In steep channels, wood stakes should be used to secure the sod strips.
- On slopes 3:1 or steeper, the sod shall be rolled or tamped, then secured with chicken wire or jute mesh over the sod for protection over critical areas. The stakes should secure the sod and the net and be spaced no further than 18" apart. The size of the stakes shall be approximately ½" x ¾" x 12". The netting or mesh shall be stapled on the side of each stake within two inches of the top of the stake. The stake would then be driven flush with the top of the sod.
- The sod shall be tamped or rolled after placement and then watered.

Maintenance

- Sod should be kept moist for at least the first three weeks, until properly rooted.
- Sod areas where original placement does not establish or take root.
- Do not mow for the first three weeks.
- Once mowing begins, cutting height should be 3" or greater.
- Fertilize and mow grasses once established.

Inspection Checklist

- Sodded areas are properly watered and maintained.
- Heavy construction equipment has been prohibited from crossing sodded areas.
- Sodded areas are mowed once established.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-08	
	Activity: Surface Roughening (SR)		
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: 10% of Installation			
			
	Target Pollutants		
	Significant ♦	Partial ♦	Low or Unknown ◇
	Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇		
Description	This BMP corrects the affects of runoff velocities, sediment trapping and sheet flow length by constructing small furrows across a slope, and utilizing construction equipment to track soil surface. The primary function of surface roughening is to temporarily stabilize a slope until it can receive permanent vegetation.		
Suitable Applications	<ul style="list-style-type: none"> ➤ All exposed construction slopes. ➤ Exposed soils where seeding, planting, and mulching will benefit from surface roughening. ➤ Areas that have the potential for erosion of clay (smooth, hard surfaces), silt or sand sized particles. 		
Approach	Roughening methods include: <ul style="list-style-type: none"> ➤ Terracing, (see EPP-13) ➤ Fill Slope Roughening ➤ Grooving ➤ Roughening with tracked machinery Factors to be considered in choosing a method are: <ul style="list-style-type: none"> ➤ Slope steepness ➤ Mowing requirements ➤ Soil type 		

**Installation
Procedures****Fill Slope Roughening**

- Place fill slopes with a gradient steeper than 3:1 (H:V) in lifts not to exceed 8 in., and make sure each lift is properly compacted.
- The face of the slope should consist of loose, uncompacted fill 4 in. to 6 in. deep.
- Use grooving, furrowing, or tracking to roughen the face of the slopes, if necessary.
- Apply seed, fertilizer and mulch then track or punch in the mulch. See Permanent Seeding ([EPP-06](#)), Temporary Seeding ([EPP-05](#)), and Mulching ([EPP-10](#)) BMPs.
- Do not blade or scrape the final slope face.

Grooving - Cuts, Fills, and Graded Areas

- Slopes that will be maintained by mowing should be no steeper than 3:1 (H:V).
- To roughen these areas, create shallow grooves by normal tilling, disking, harrowing, or use a cultipacker-seeder. Make the final pass of any such tillage on the contour.
- Make grooves formed by such implements close together, less than 10 in. apart and 3 in. deep.
- Excessive roughness is undesirable where mowing is planned.
- Practice should be used on slopes no longer than 200 feet.

Furrowing





- Slope no greater than 3:1 (H:V).
- Use equipment to cut a 6" deep furrow while placing cut material below furrow
- Cut furrows along the contour and at a minimum spacing of 50'.
- Practice should not be used on slope longer than 200 feet.

Roughening with Tracked Machinery

- Limit roughening with tracked machinery to soils with a sandy textural component to avoid undue compaction of the soil surface.
- Operate tracked machinery up and down the slope to leave horizontal depressions in the soil, running with the contours of the slope. Do not back blade during the final grading operation.
- Seed and mulch roughened areas to obtain optimum seed germination and growth.
- Periodically check the seeded or planted slopes for rills and washes, particularly after significant storm events, greater than 0.5 in.
- Fill these areas slightly above the original grade, then reseed and mulch as soon as possible.

Maintenance**Inspection
Checklist**

- Surface roughened areas inspected after recent wet weather events.
- Rills and washed areas have been re-roughened and re-seeded.
- Practice is maintained and properly functioning; other practices are not required.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-09
	Activity: Top Soiling (TS)	
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Varies Estimated Unit Cost: Medium Monthly Maintenance: 10% of Capital Cost		
		
	Target Pollutants	
	Significant ◆ Partial ◆ Low or Unknown ◇ Sediment ◆ Heavy Metals ◆ Nutrients ◆ Oxygen Demanding Substances ◆ Toxic Materials ◇ Oil & Grease ◆ Bacteria & Viruses ◇ Floatable Materials ◆ Construction Waste ◇	
Description	Topsoil is used to enhance the final product of a construction site area. This act is done to support temporary and permanent seeding, as well as aiding in erosion control methods. By implementing this BMP, a reduction in construction waste and some reduction in sediment will occur.	
Suitable Applications	<ul style="list-style-type: none"> ➤ Where construction activities expose subsoil layers that may not be able to support vegetative growth. ➤ Areas where reusing and preserving topsoil increases the success rate of new vegetation. 	
Approach	<ul style="list-style-type: none"> ➤ Compost used on site as a recycled aspect of construction clearing. ➤ Verify proper placement of down slope sediment control practices prior to removing topsoil. ➤ Strip topsoil only from those areas that will be disturbed by excavation, filling, road building, or compaction by equipment. Normally, 4 to 6 inches are stripped for topsoil use. ➤ Position topsoil stockpiles where they will not erode, block drainage, or interfere with site work. ➤ Before topsoil is applied to the site, disk the subsoil to insure topsoil bonding. Apply a minimum of 4 inches of topsoil evenly. ➤ If site is excavated down to rock, such as sandstone or shale, 8 to 12 inches of topsoil is recommended for good plant growth. 	

Activity: Top Soiling**EPP-09****Installation Procedures**





- Strip topsoil 4 to 6 in. from areas to be disturbed by excavation, filling, road building or compaction by equipment and preserve for later use.
- Disk the subsoil to insure topsoil bonding before applying to site. Applying a minimum of 4 in. of topsoil evenly.
- Apply seeding & mulch or sod after final grading.

Maintenance

- Maintain areas where vegetation has been re-established to remedy erosion and damage or vegetation failure by frequently checking the newly applied topsoil.

Inspection Checklist

- Effective management practices such as netting, temporary seeding, mulch and other traditional methods are used to ensure correct storage of the soil. If these practices are not available, other equivalent practices are to be enforced.
- Appropriate layer of topsoil has been established.
- Storage piles do not interfere with site drainage.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-10
	Activity: Mulching (M)	
PLANNING CONSIDERATIONS: Design Life: 6-12 Months Acreage Needed: None Estimated Unit Cost: Low Monthly Maintenance: 60% of Installation		
		
Target Pollutants		
<div style="display: flex; justify-content: space-around;"> Significant ♦ Partial ♦ Low or Unknown ◇ </div>		
<div style="display: flex; justify-content: space-between; font-size: small;"> Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ </div> <div style="display: flex; justify-content: space-between; font-size: small;"> Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇ </div>		
Description Suitable Applications Approach	<p>To secure temporary or permanently seeded areas, mulching is used as a stabilizer. There are several types of mulches to be utilized, some of which include organic materials, straw, wood chips, and bark or other wood fibers. This management practice has the possibility to significantly reduce sediment and partial reduction of nutrients.</p> <ul style="list-style-type: none"> ➤ Temporary stabilization of freshly seeded and planted areas, sometimes during periods of unsuitable vegetative growth. ➤ Temporary stabilization of areas that cannot be seeded or planted (e.g., insufficient rain, steep slope, non-growth season). ➤ Areas which have been permanently seeded to assist in retaining moisture, and to hold seeding. ➤ On areas to increase the survival of temporary and/or permanent vegetative cover. ➤ As short term, non-vegetative ground cover on steepened slopes to reduce rainfall impact, decrease the velocity of sheet flow, and settle out sediment. ➤ As ground cover around established plants, such as trees or shrubs, and on unprotected flat to minor slopes. ➤ Apply to planting areas where slopes are 2.5:1 (H:V) or less steep. Tacking agents or devices may be necessary for steeper slopes. ➤ Areas where climatic conditions require soil moisture retention aid to avoid cracking. <p>The term “mulch” is commonly used to describe a variety of materials, such as:</p> <ul style="list-style-type: none"> ○ Shredded tree bark and other woody materials, to protect trees and shrubs. ○ Straw or hay, scattered across a slope or disturbed area. ○ Peat mulch, used in planting trees and shrubs. <p>Table EPP-10-01 has a recommended application rate for various types of mulches.</p>	

**Approach
(cont'd)****Vegetative Fibers (Straw)**

Loose hay or straw are the most common mulch materials used in conjunction with direct seeding of soil. Straw mulch is preferable over hay mulch, which may contain weeds and other objectionable material. Straw mulch is the short-term protection most commonly used with seeding. Wheat or oat straw is recommended from the current season's crop (less than 12 months old). Average fiber length should exceed 6 in.

Straw mulch is applied immediately after seeding, whether by machine or by hand distribution. Anchor the mulch in place using a tacking agent, plastic netting, or punching into the soil mechanically. Plastic netting requires wire staples, wooden stakes, or plastic stakes. If the slopes are too steep for netting, then tacking agents should be selected on the basis of longevity and the ability to hold the fibers in place.

Anchoring

- Crimping, tracking, disking, or punching into soil
 - Small areas - Hand punch mulch 2-3 inches into the loose soil.
 - Larger areas – Use mulching tool on tractor to punch and anchor mulch 2-8 inches into the soil.
 - Tracking – Cut straw into soil by using a bulldozer with cleated tracks, placed such that the cleat marks are perpendicular to the runoff.
 - Typically used on slopes 3:1 or flatter for safe operation of equipment.
- Covering with netting or mat
 - Nettings or biodegradable paper, plastic or cotton netting can be used to cover straw mulch. The safety of animals (small birds, snakes and other wildlife) should be considered when selecting materials for this measure.
- Spraying tackifiers (Polymer or Organic)
 - Polymer tackifiers are typically applied at a rate of 40-60 lbs/acre, or per manufacturer's recommendations.
 - Organic tackifiers are typically applied at a rate of 80-120 lbs/acre, or per manufacturer's recommendations.
- Cellulose fiber mulch
 - Can be tacked at a rate of 750 lbs/acre

Shredded Vegetation

"Green" mulch is produced by recycling of vegetation trimmings such as grass, shrubs, and trees. Methods of application are generally by hand, although pneumatic methods are currently being developed. It can be used as a temporary ground cover with or without seeding. The green mulch in place with a tacking agent on steep slopes and in areas where overland sheet flow is anticipated. The quality of green mulch may vary, and there is a strong potential for establishing unwanted weeds and plants.

**Approach
(cont'd)**

Wood and Bark Chips

Wood and bark chips are suitable for landscaped areas that will not be closely mowed. Wood and bark chips may require nitrogen treatment to prevent nutrient deficiency. Bark chips do not require additional nitrogen fertilizer.

If there is a wood source near the project site, wood and bark chips can be very inexpensive. Caution must be used on steep slopes, since both wood and bark chips tend to wash down slopes exceeding 6 percent. Wood and bark chips are also used around trees and shrubs, or in ornamental or landscape gardens. A typical rate for placing wood and bark chip mulch is 6 tons per acre, at a depth of 2-3 inches.

Hydraulic Mulch

Hydraulic mulch can be made from virgin wood fibers or from recycled waste paper sources (newsprint, magazine). There are also mulches available which are a combination. In general, virgin wood fibers contain a longer fiber length than recycled paper mulch.

Hydraulic mulch is mixed in a hydraulic application machine (such as a hydroseeder or a mulch blower) and then applied as liquid slurry. The hydroseeder slurry contains recommended rates of seed and fertilizer for the site, usually specified with a tacking agent. Slurry must be constantly agitated to keep the proper application rate and achieve uniform effective coverage.

**Table EPP-10-01
Recommended Rates for Mulching Materials**




Mulch Product	Application Rate
Straw or Hay	1 ½ tons per acre
Wood Chips, Bark, Sawdust	5 - 8 tons per acre
Hydraulic mulches and soil binders	1 ½ - 2 tons per acre

Maintenance

- Must be inspected weekly and after rain for damage or deterioration.
- Inspect after episodes of high winds.
- Maintain an unbroken, temporary mulched ground cover throughout the period of construction that the soils are not being reworked. Inspect before expected rainstorms and repair any damaged ground cover and re-mulch exposed areas of bare soil.

**Inspection
Checklist**

- All disturbed areas are properly covered per plans and specifications.
- Straw mulch has been properly crimped.
- Mulch has been replaced following intense wet weather events or episodes of high winds.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-11
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: None Estimated Unit Cost: Low Monthly Maintenance: 60% of Installation		 <div style="border: 1px solid black; width: 40px; height: 40px; text-align: center; margin: 5px auto;">N</div> <div style="border: 1px solid black; width: 40px; height: 40px; text-align: center; margin: 5px auto;">M</div>
	Target Pollutants	
	<div style="display: flex; justify-content: space-around;"> Significant ♦ Partial ♦ Low or Unknown ♦ </div>	
	<div style="display: flex; justify-content: space-between; font-size: small;"> Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ </div> <div style="display: flex; justify-content: space-between; font-size: small;"> Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦ </div>	
Description Suitable Applications Approach	<p>The security measures ensured by a protective blanket or soil stabilization mat to help prevent and reduce erosion on preceding shaped and seeded swales, channels and slopes while assisting in the establishment of temporary or permanent vegetation on steep slopes, channels, or stream banks. The implementation of this BMP will create a significant reduction in sediment.</p> <ul style="list-style-type: none"> ➤ Preventing erosion of the soil surface. ➤ Promoting seed germination. ➤ Protecting young vegetation ➤ Preventing wind dispersal of seed or mulch ➤ Allowing for easy installation of seed and/or mulch. <p>Selection of an appropriate mat or blanket depends on the nature of the project. Manufacturers should be consulted in selecting the product for the intended purpose.</p> <p><u>Temporary Erosion Control Blankets</u> Temporary erosion control blankets include the following options:</p> <ul style="list-style-type: none"> • plastic netting intertwined with a natural organic or manmade mulch • jute mesh <ul style="list-style-type: none"> ➤ Typically used to stabilize concentrated flow areas where velocities meet or exceed 5 ft/sec and slopes 2.5:1 or steeper. ➤ Deteriorate in a short period of time ➤ Provide protection of the seed and soil from raindrop impact and subsequent soil displacement. ➤ Thermal consistency and moisture retention for seed. ➤ Accelerates germination of grasses and legumes more completely 	

**Approach
(cont'd)**

Permanent Erosion Control Matting

Consist of permanent, non-degradable, three-dimensional plastic structures that are filled with soil prior to planting.

- Typically used to stabilize concentrated flow areas where velocities are between 5 and 10 ft/sec.
- Linings should be designed and selected by a professional experienced in the use of these materials
- Provides the same benefits as erosion control blankets.
- Protects channels from erosion within high capacity storm water conveyance channels.
- Filters fine sediment during lower flow stormwater events.

**Installation
Procedures**

Always follow the manufacturer’s recommendations for orientation, overlapping, entrenching, and securing blankets and mats.

Temporary Blankets

Some of the pertinent characteristics required in some machine produced temporary blankets are found in [Table EPP-11-01](#)

**Table EPP-11-01
Temporary Blanket Characteristics**

Blanket	Materials	Mesh	Minimum Thickness	Minimum Dry Weight
Straw	weed-free straw from agricultural crops	5/16" x 5/16"	3/8"	0.5 lbs/sy
Excelsior	curled wood excelsior (80% fibers are six inches or longer)	1 1/2" x 3"	1/4"	0.8 lbs/sy
Coconut Fiber	100% coconut fiber	5/8" x 5/8"	1/4"	0.5 lbs/sy
Wood Fiber	reprocessed wood fibers	5/8" x 3/4"	N/A	0.35 lbs/sy
Jute Mesh	woven root fiber or yarn	N/A	N/A	1 lbs/sy

All blankets should have a minimum width of 48 inches.

- Blankets are typically installed vertically from top to bottom of slopes.
- Trim blankets as needed to optimize coverage.
- In areas of concentrated flows, such as the bottom of a ditch, orient blanket in the same direction of the flow.
- Entrench blanket at the top and bottom of the slope.
- Overlap vertical joints at least 3 inches.
- Staples should be used to anchor blankets. Do not use stakes.

**Installation
Procedures
(cont'd)**Permanent Matting





- Consists of webs, nettings, monofilaments or fibers that are entangled to form a strong and dimensionally stable matrix.
- Maintain shape before, during and after installation.
- Resistant to ultraviolet degradation
- Inert to chemicals in a natural soil environment.
- Begin installing permanent matting in storm conveyances at the bottom of the slopes and progress upstream.
- Staples or stakes can be used to anchor mats.

Maintenance

- Inspect erosion control matting before (if anticipated) and within 24 hours following rainfall events to check for movement of topsoil, mulch or erosion. Continue checking until vegetation is firmly established.
- Inspect blankets or mats at least every 14 days.
- Repair or replace netting that has been washed out, broken, eroded, and/or needing surface repair, re-seeding, re-sodding, re-mulching or topsoil replacement.

**Inspection
Checklist**

- Channel grades are adequately managing runoff velocity.
- Staples are appropriately spaced to avoid loss of seed, topsoil and mulch to stormwater runoff and winds.
- Nets are adequately covered or anchored to prevent erosion, washout, and poor plant establishment.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-12
	Activity: Geotextiles (G)	
PLANNING CONSIDERATIONS: Design Life: N/A Acreage Needed: None Estimated Unit Cost: Low Monthly Maintenance: N/A		
		
	Target Pollutants	
	Significant ♦ Partial ♦ Low or Unknown ◇ Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description	Geotextiles are woven or non-woven fabrics, applied between surfaces or materials, to reduce flow velocities, release runoff as sheet flow, remove some sediment from runoff and are likely to create a significant reduction in sediment. Runoff and pollution caused by construction activities can be prevented or reduced with this BMP.	
Suitable Applications	<ul style="list-style-type: none"> ➤ Construction sites desiring stability for disturbed soils. ➤ Sloppy area where anchoring must take place. ➤ Slopes steeper than 3:1 (H:V) and/or where erosion hazard is high. ➤ Slow growing vegetated areas. ➤ Critical slopes adjacent to sensitive areas (streams, wetlands, etc.). 	
Approach	<p>Geotextiles provide stabilization, filtration, and separation properties. This BMP may be used when there is a need for separation between two materials or mediums that are likely to otherwise interfere with one another.</p> <ul style="list-style-type: none"> ➤ Separating subsoil from aggregate within a subsurface drain. ➤ Separating subsoil from aggregate placed at the soil surface. ➤ Stabilization of soil surface during temporary stream diversion. ➤ Prevent buildup of hydrostatic pressure behind gabions, decorative, or retaining walls. <p>This BMP does not require design or selection by a professional experienced in geotextile applications. However, if hydrostatic pressure becomes a concern for stability of a retaining wall, then a professional should be consulted.</p> <p>Geotextiles should be selected based on the standard specifications detailed in AASHTO M288.</p>	

Installation Procedures

Geotextiles should be non-toxic to vegetation, and inert to soil chemicals. The materials selected should meet or exceed requirements of strength, resistance to distortion, permittivity, and resistance to ultraviolet degradation.

Geotextiles should be installed according to the specifications of the manufacturer.





- Site preparation should include removal of rocks, clods, debris greater than 1" and any voids.
- The material should be loosely placed with no wrinkles, folds or distortions.
- The fabric should be in direct contact with the soil.
- Overlap sheets by placing the next consecutive sheet upstream on top of the downstream sheet.
- Fabric may require field joining with stakes or staples.
- Do not dump aggregate onto fabric from height greater than five feet. Aggregate should be placed to prevent damage.
- Damaged section may be repaired by placing a piece that overlaps the damaged area by at least 1 foot.

Maintenance

- Inspection to occur periodically, if any portion of the material is damaged, immediate correction is required.
- Inspections may occur prior to any anticipated wet weather events.
- Inspection to occur after significant rain storms to check for erosion and undermining.
- Repairs to the slope and re-installation should occur as a result of wash-out or breakage.
- Perform maintenance as required by the manufacturer.

Inspection Checklist

- Site is adequately prepared (grading or shaping, rocks, vegetation and debris removal, etc.).
- Seeding meets geotextile requirements.
- Anchoring is established at an acceptable depth.
- Anchoring trenches are used at the top and bottom of slopes.
- Trenches start, join and terminate geotextiles placed in channels.
- Soil filling is even and flat.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Erosion Prevention Practices (EPPs)	EPP-13															
	Activity: Terracing (T)																
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: As Required Estimated Unit Cost: Medium Monthly Maintenance: N/A																	
	<div style="text-align: center;">Target Pollutants</div> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">Significant ♦</td> <td style="text-align: center;">Partial ♦</td> <td style="text-align: center;">Low or Unknown ◇</td> </tr> <tr> <td style="text-align: center;">Sediment ♦</td> <td style="text-align: center;">Heavy Metals ◇</td> <td style="text-align: center;">Nutrients ◇</td> </tr> <tr> <td style="text-align: center;">Oil & Grease ◇</td> <td style="text-align: center;">Bacteria & Viruses ◇</td> <td style="text-align: center;">Floatable Materials ◇</td> </tr> <tr> <td></td> <td style="text-align: center;">Oxygen Demanding Substances ◇</td> <td style="text-align: center;">Toxic Materials ◇</td> </tr> <tr> <td></td> <td style="text-align: center;">Construction Waste ◇</td> <td></td> </tr> </table>	Significant ♦	Partial ♦	Low or Unknown ◇	Sediment ♦	Heavy Metals ◇	Nutrients ◇	Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇		Oxygen Demanding Substances ◇	Toxic Materials ◇		Construction Waste ◇		
Significant ♦	Partial ♦	Low or Unknown ◇															
Sediment ♦	Heavy Metals ◇	Nutrients ◇															
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇															
	Oxygen Demanding Substances ◇	Toxic Materials ◇															
	Construction Waste ◇																
Description Suitable Applications Approach	<p>This BMP is likely to reduce sediment by creating small areas to establish vegetation to reduce runoff velocity, increase infiltration and trap sediment. This reduces the amount of sediment leaving a site.</p> <ul style="list-style-type: none"> ➤ Cleared areas prior to temporary or permanent seeding and planting or erodible slopes steeper than 3:1 (H:V) and higher than 5 feet. ➤ Graded areas with smooth, hard surfaces. ➤ Areas where slopes need to be shortened. Adequate drainage and stabilized outlets must be a part of the design and should follow the guidelines of a licensed professional civil engineer based on site conditions. <p>Slope roughening/terracing is performed in several ways:</p> <ul style="list-style-type: none"> ➤ Stair-step grading ➤ EPP-08 ➤ Rough grading ➤ No grading <p>On slope 3:1 (H:V) the following practices found in EPP-08 can be considered:</p> <ul style="list-style-type: none"> ➤ Grooving ➤ Furrowing ➤ Tracking 																

Installation Procedures

Graded areas with smooth, hard surfaces give a false impression of “finished grading” and a job “well done”. It is difficult to establish vegetation on such surfaces due to reduced water infiltration and the potential for erosion. Rough slope surfaces with uneven soil and rocks left in place may appear unattractive or unfinished at first, but they encourage water infiltration, speed the establishment of vegetation, and decrease runoff velocity. Rough, loose soil surfaces give lime, fertilizer, and seed some natural coverage. Niches in the surface provide microclimates which generally provide a more favorable moisture level that aids seed germination.

There are different methods for achieving a roughened soil surface on a slope, and the selection of an appropriate method depends upon the type of slope. Roughening methods include stair-step grading, grooving, and tracking. Factors to be considered in choosing a method are slope steepness, mowing requirements, and whether the slope is formed by cutting or filling.

1. Disturbed areas which will not require mowing may be stair-step graded, grooved, or left rough after filling.
2. Graded areas steeper than 3:1 (H:V) should be stair-stepped with benches. The stair-stepping will help vegetation become attached and also trap soil eroded from the slopes above. Stair-step grading is particularly appropriate in soils containing large amounts of soft rock. Each “step” catches material which sloughs from above, and provides a level site where vegetation can become established. Stairs should be wide enough to work with standard earth moving equipment.
3. Make the vertical cut distance less than the horizontal distance, and slightly slope the horizontal position of the step in towards the slope.
4. Do not make individual vertical cuts more than 24 in. (600 mm) high in soft materials or more than 3 ft. (1 m) high in rocky materials.
5. Groove the slope using machinery to create a series of ridges and depressions that run across the slope and on the contour.

Fill Slope Roughening

- Place fill slopes with a gradient steeper than 3:1 (H:V) in lifts not to exceed 8 in. (200 mm), and make sure each lift is properly compacted.
- Ensure that the face of the slope consists of loose, uncompacted fill 4 in. (100 mm) to 6 in. (150 mm). This is not to be confused with proper compaction necessary for slope stabilization.
- Use grooving or tracking to roughen the face of the slopes, if necessary.
- Apply seed, fertilizer, and mulch and then track or crimp in the mulch. See [EPP-05](#), [EPP-06](#): Temporary Seeding and Temporary Mulching, respectively.
- Do not blade or scrape the final slope face.

Cuts, Fills, and Graded Areas

- Slopes that will be maintained by mowing should be no steeper than 3:1 (H:V).
- To roughen these areas, create shallow grooves by normal tilling, disking, harrowing, or use a mechanical seeder. Make the final pass of any such tillage on the contour.
- Make grooves formed by such implements close together, less than 10 in. (250 mm), and not less than 1 in. (25 mm) deep.
- Excessive roughness is undesirable where mowing is planned.

Activity: Terracing**EPP-13**

Maintenance ➤ Periodically check the seeded or planted slopes for rills and washes, particularly after significant storm events greater than 0.5 in. (12 mm). Fill these areas slightly above the original grade, then re-seed and mulch as soon as possible.

➤ Inspect roughened slopes weekly and after rainfall for excessive erosion.

**Inspection
Checklist**

Furrows at least 6 in. deep.

Furrows are spaced no more than 50 ft. apart.

Horizontal distance is greater than vertical distance on stepped slopes.

Stepped slopes or terraced slopes cut so that they drain in on themselves.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Erosion Prevention Practices (EPPs)**

EPP-14

Activity: Soil Binders (SB)

PLANNING
CONSIDERATIONS:

Design Life:

Acreage
Needed:

Estimated
Unit Cost:

Monthly
Maintenance:

Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ♦ Oxygen Demanding Substances ◇ Toxic Materials ♦
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Suitable
Applications

Approach

Activity: Soil Binders

EPP-14

Installation
Procedures ➤

Maintenance ➤

Inspection
Checklist ➤



Activity: Soil Binders

EPP-14

Installation
Procedures ➤

Maintenance ➤

Inspection
Checklist ➤

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-01
PLANNING CONSIDERATIONS: Design Life: 6 – 12 months Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: 30-40% of Installation		
	Target Pollutants	
	Significant ♦ Partial ♦ Low or Unknown ♦	
	Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦	
Description Suitable Applications Approach	<p>Check dam are use to reduce the velocity of concentrated stormwater flows, small temporary constructions are built across swale or drainage ditch. Check dams reduce erosion and promotes sedimentation within the ditch line.</p> <ul style="list-style-type: none"> ➤ Check dams are not to be used in streams and rivers. However, should be used in swales or ditch lines. ➤ Check dams are a temporary or permanent means of protection against erosion during the establishment of vegetative lining. ➤ Installation of erosion-resistant lining is not practical to use for short length of service for temporary ditches or channels. <ul style="list-style-type: none"> ➤ Stone Check Dams (CD-S) A stone check dam is intended to be used on a small drainage areas (up to one (1) acre or less). These dams are constructed with large aggregate (#1 or #2 stone with a minimum size of 1.5"). ➤ Rock Check Dam (CD-R) Rock check dams are intended for larger drainage areas than the stone check dams (areas up to 5 Acres or less). Rock check dams utilize small rip-rap such as KTC Channel Lining Class III. Smaller rock should be used on the upstream side to reduce the velocity of flow through the device. Attention should be given to placement of rock as to minimize large void areas ➤ Sandbag Check Dams (CD-SB) Sandbags with sand or aggregate fill may be used to perform the function of a check dam. The placement of bags should be staggered as to provide stability. 	

Design Criteria The following design criteria should be used:

- **Drainage Areas:** Stone check dam (1 acre or less), Rock check dam (5 acres or less)
- **Spacing:** Two or more check dams should be used for areas greater than one acre. The maximum spacing should be determined by keeping the toe of the upstream dam equal to the spill over elevation of the downstream dam (See [Table SMP-01-01](#) or attached nomograph).
- **Dimensions:** All check dams should be 24" or less in height. The overflow point should be at least 6" lower than the outer edges. Front and back slopes shall be 2:1. The designer should take into consideration potential impacts due to impounded water (see Detail [SMP-01](#)).
- **Key-in:** Rock check dams should utilized a 6" key-in techniques to aid in stabilization during peak flows.

**Table SMP-01-01
Spacing for Silt Check Dams**

Ditch slope	Silt check dam spacing	Additional information
30%	10 ft.	Calculated for 3' high silt check dams.
20%	15 ft.	
15%	20 ft.	
10%	35 ft.	Center of dam should be 6" lower than sides
5%	55 ft.	
3%	100 ft.	Use 5" – 10" rock, stone bags, or commercial products.
2%	150 ft.	
1%	300 ft.	
0.5%	600 ft.	

**Table SMP-01-02
Rock Sizing for Ditch Liners**

Flow Velocity	Average Rock Diameter
6 ft. per second	5 inches
8 ft. per second	10 inches
10 ft. per second	14 inches
12 ft. per second	20 inches

Activity: Check Dams

SMP-01

**Installation
Procedures**

Installation procedure is as follows:


- Excavate key-way (if required).
- Place geotextile (if required).
- Place check dam material to specified dimensions/elevations.
- A sump may be provided immediately upstream of the check dam to capture sediment.
- If grass is planted to stabilize the ditch or swale, the check dam should be removed when vegetation is stabilized.

Maintenance

- Sediment shall be removed before it reached one-half of the devices original height.
- Any lose or displaced stone should be repaired to the original specifications.

**Inspection
Checklist**

- Stone meets specified sizes.
- Check dam spans the entire width of the channel.
- Dimensions/elevations are as specified.
- Filter fabric on upstream face is keyed into the bed (if applicable).
- Check dams are to be removed when vegetation is stabilized.
- Sediment is maintained less than one-half of the original height.
- Sites with rain accumulation of 0.5" should be checked within 24 hours.





NOMOGRAPH PROCEDURE

1. DRAW LINE VERTICALLY FROM HEIGHT VALUE ON "X" AXIS UPWARD UNTIL IT INTERSECTS DIAGONAL DITCH GRADE LINE AT THE APPROPRIATE GRADE VALUE.
2. FROM THE POINT OF INTERSECTION WITH GRADE LINE, DRAW LINE HORIZONTALLY UNTIL THE LINE INTERSECTS WITH "Y" AXIS (SPACING).
3. DETERMINE SPACING VALUE.

EXAMPLE

GIVEN: CHECK DAM HEIGHT = 18" (1.5')
 DITCH GRADE = 2%

SOLUTION: CHECK DAM SPACING = 75 FEET

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-02
PLANNING CONSIDERATIONS: Design Life: 6 months Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: 100% of Installation		
	Target Pollutants	
	Significant ♦ Partial ♦ Low or Unknown ◇	
	Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description Suitable Applications Approach	<p>To detain sediment-laden water, silt fences are used to promote silt deposition behind the fence. These fences are made of filter fabric that has been entrenched, attached to support poles and occasionally supported by a wire fence. Silt fence is intended as a temporary sediment barrier and requires routine maintenance</p> <ul style="list-style-type: none"> ➤ Silt fence should be used in area accepting sheet flow conditions. ➤ Silt fence should not be used in ditch lines, streams, or other areas of concentrated flows. ➤ Silt fencing can be used along the downstream perimeter, below the toe of a cleared slope, upstream of sediment traps or basins, along streams and channels and around temporary spoil areas. <ul style="list-style-type: none"> ➤ Light Duty Silt Fence (SF-LD) Type A silt fence is 36" in height. This type silt fence can be used on project lasting 6 months or greater. ➤ Heavy Duty Silt Fence (SF-HD) Type C silt fence is 36" in height and has wire reinforcement. This type silt fence should be used when high velocities are encountered. Table SPD-02-01 on pg. SMP-02-02. 	

Design Criteria The design criteria for silt fence is as follows:

- Silt fencing should be installed along the contour. It should not be installed up and down slopes unless accompanied by measures such as "J" Hooks or other methods.
- The length of silt fence is determined by the amount of run-off area. The minimum area should not exceed 0.25 acre per 100 linear feet of silt fence.
- Spacing of silt fence is variable depending on the slope of land draining to the fence. See [Table SMP-02-01](#) for spacing requirements.

Table SMP-02-01
Silt Fence Spacing on Sloping Sites

Slope Angle	Soil Type		
	Silty	Clays	Sandy
Very Steep (1:1)	50 ft.	75 ft.	100 ft.
Steep (2:1)	75 ft.	100 ft.	125 ft.
Moderate (4:1)	100 ft.	125 ft.	150 ft.
Slight (10:1)	125 ft.	150 ft.	200 ft.

Installation Procedures

Silt fence installation procedure is as follows:




- Secure suitable fence materials meeting requirement set herein.
- Stake or mark silt fence location.
- Trench (6" by 6") along proposed location.
- Place fence in the trench (most fence products have a colored line indicating the depth of burial). Drive post with spacing as specified by silt fence type. Attach fence material to post as specified.
- Backfill and compact trench anchoring fence material.
- When required fence splicing should be conducted as be the method contained herein.
- Silt fence should turn up hill six feet at ends (at least 1 foot raise in elevation).

Maintenance

- Inspect after every rainfall.
- Repair/replace fence when damaged or deteriorated.
- Sediment height not to exceed one-half the height of the fence.
- Perform required maintenance before a storm event.
- Remove fence when vegetation is established.

Inspection Checklist

- Silt fence has proper placement.
- The last 6 feet of the silt fence is turned uphill and secured to the post.
- Color band of the anchor trench is not visible.
- Accumulated sediment does not exceed one half the height of the fence.
- If washaround or underwash occurs then fence should be reset.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-03
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: Low		
	Target Pollutants	
	Significant ◆ Partial ◆ Low or Unknown ◇	
	Sediment ◆ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description Suitable Applications Approach	<p>Filters, brush and berms are used to dissipate sediment in construction runoff by anchoring rock deposits, rolls of fabric and/or brush barriers. These barriers are constructed of rocks ¾ to 5 inches in diameter that make up a berm to be placed along a contour. Brush wrapped in filter cloth and anchored to the toe of the slope creates a brush barrier, which acts as another trapping method. Additionally, a continuous roll of fabric that captures sand, rock or native soil is an example of one more method to capture sediment. This BMP is used for sediment trapping and velocity reduction that will aid in significantly reducing sediment.</p> <ul style="list-style-type: none"> ➤ Rock filters should be applied near the toe of the slope, along the site perimeter, stream channels, spoil areas, small cleared areas, sediment traps ➤ Rock filters may also be used as check dams and with temporary roads <p>A filter berm can often be constructed from natural materials, such as brush or rocks. This is generally an efficient operation for the site contractor if these materials are already present on the project site, both timewise and in terms of installation cost. Brush and rock filter berms can also be installed with a geotextile fabric to increase sediment removal filtration and the overall stability of the berm. Wire netting (such as poultry fencing) can also be used to increase the stability for brush or rock berms. Gabions and other wire mattresses can also be used as a rock filter for erosion control.</p>	

**Approach
(Continued)**

Both types of filter berms are placed along a level contour. Common applications are along the edge of a gravel roadway or 5 to 7 feet beyond the toe of a slope, where overland sheet flow can be detained and ponded. Brush or rock filter berms slow the velocity of overland runoff, allowing sediment to settle out or become trapped in the filter. In this manner, the brush and rock filter berms are very similar in function to SMP-01, Check Dams, except that filter berms handle overland sheet flow and check dams handle stormwater runoff channels.

Brush and rock filter berms both contain materials (dirt, leaves, dust, silt) which could potentially cause more pollution than they might remove. These measures should be constructed and managed carefully in order to become effective BMPs. A silt fence or straw bale barrier may be needed as a secondary measure to control dirt and leaves.

➤ **Brush Filter (F-B)**

A brush filter berm is composed of brush, small tree limbs, rootmat, grass and leaves, or other material which is commonly generated as waste during the clearing and grubbing stage. The brush filter berm is constructed by piling these materials into a continuous and compacted mound along a level contour which is downhill from a disturbed area. Large logs or tree stumps should generally be avoided as part of the brush filter berm; they cause large voids or gaps in the berm and so defeat the purpose of detaining stormwater. However, large logs by themselves can be used to slow stormwater runoff in wooded areas, along paths and trails, or at the bottom of slopes.

A brush filter berm height of approximately 3 feet is recommended to slow or detain stormwater. The minimum height of 2 feet may be used for short slopes less than 100 feet long. A corresponding width is generally 5 to 10 feet, with a shape that can either be triangular or somewhat rounded. Standard dozers or other grading equipment are used to compact and shape the brush filter berm to be more dense. Use rope or sturdy string to shape the brush filter berm and to hold it together.

A geotextile fabric can be used to increase the sediment retention or to provide a more stable brush filter berm. Install the filter fabric into a trench 6 inches deep immediately uphill from the formed berm. Then lay the filter fabric over the front face of the brush filter berm. Secure the filter fabric using staples, stakes, ropes or wires so that the fabric will not be uplifted by winds or storms. Overlap edges of filter fabric by 6 inches.

Brush filter berms are generally not used in developed areas or wherever aesthetics will be of concern. Brush filter berms may also be unpredictable in terms of performance. Since they are composed of natural materials, they may or may not need to be removed after the uphill sites are stabilized. Brush filter berms may provide a habitat for various types of desirable wildlife, or they could harbor pests and rodents in areas where these problems are known to exist.

➤ **Rock Filter (F-R)**




A rock filter berm can be created from natural gravel or rock at the project site, or from imported gravel and rock. It is placed and compacted along a level contour, where sheet flow may be detained and ponded to promote sedimentation. Some type of geotextile fabric or wire screen is recommended to keep the berm shape intact. A gabion or wire mattress may be used to construct a rock filter berm, provided that the gabion wire spacing is compatible with size of aggregate or rock.

Activity: Brush or Rock Filters and Continuous Berms

SMP-03

Inspection
Checklist

- Sufficient space for ponded water.
- Brush filters are performing.
- Drainage to structure does not exceed 5 acres.

	<p>Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)</p>	<p>SMP-04</p>																	
<p>PLANNING CONSIDERATIONS:</p> <p>Design Life: 1-1 ½ years</p> <p>Acreage Needed: Minimal</p> <p>Estimated Unit Cost: Low</p> <p>Monthly Maintenance: 30% of Installation</p>		 <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;">ST</div>																	
<p>Description</p> <p>Suitable Applications</p> <p>Approach</p>	<p>The sediment trap is a control measure that detains sediment-laden runoff from small disturbed areas in an earthen embankment that will allow ponding long enough to allow the sediment to settle within the depression.</p> <ul style="list-style-type: none"> ➤ Install detention areas below disturbed vicinities of less than 10 acres. ➤ Along the perimeter of the site at locations where sediment-laden runoff is discharged off-site or areas where runoff can enter stabilized areas or waterways. ➤ Temporary sediment traps shall not be used in live or continuously-flowing streams. Sediment traps may kill nearby vegetation by excessive sediment or by long periods of submergence. ➤ Temporary sediment traps only remove coarse particles which settle quickly. Sediment traps are not effective for fine-grained soils such as silt or clay. Additional upstream erosion control measures are necessary. <ul style="list-style-type: none"> ➤ Prepare sediment traps prior to beginning of construction. ➤ Traps are to be located in areas by hollowing out areas across swales or low embankments, places where damages are excluded and areas needing maintenance to reduce sediment accumulation. ➤ Create larger traps to include a greater amount of sediment buildup. ➤ After stabilization of the construction area, the sediment trap may be removed and stabilize area as needed with vegetation or other cover. 																		
	<p style="text-align: center;">Target Pollutants</p> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;">Significant ♦</td> <td style="text-align: center;">Partial ♦</td> <td style="text-align: center;">Low or Unknown ♦</td> </tr> <tr> <td>Sediment ♦</td> <td>Heavy Metals ♦</td> <td>Nutrients ♦</td> </tr> <tr> <td>Oil & Grease ♦</td> <td>Bacteria & Viruses ♦</td> <td>Floatable Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Oxygen Demanding Substances ♦</td> </tr> <tr> <td></td> <td></td> <td>Toxic Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ♦</td> </tr> </table>	Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦			Oxygen Demanding Substances ♦			Toxic Materials ♦			Construction Waste ♦
Significant ♦	Partial ♦	Low or Unknown ♦																	
Sediment ♦	Heavy Metals ♦	Nutrients ♦																	
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦																	
		Oxygen Demanding Substances ♦																	
		Toxic Materials ♦																	
		Construction Waste ♦																	

Design Criteria ➤ **Volume**

Minimum volume of a sediment trap shall be 67 cubic yards per acre for the total drainage area. The volume shall be measured at an elevation equivalent to the spillway invert.

Optimal design volume of sediment trap depends on type of soil, size and slope of drainage area, amount of land disturbance, desired sediment removal efficiency, and desired cleanout frequency. A recommended volume for temporary sediment trap in heavily disturbed areas is 134 cubic yards per acre, which equates to 1 inch of stormwater runoff. Optimal design of this type of sediment trap includes an upper zone of at least 67 cubic yards per acre (to be dewatered using one of the outlet design alternatives) and a lower wet zone for sediment storage and settling.

➤ **Shape**

The designer should attempt to plan a basin that has a minimum 3:1 length to width ratio.

➤ **Slopes**

Basin side slopes should be restricted to 4:1 or flatter. However, the permeable, filter, portion should have a maximum cross section of 2:1.


➤ **Emergency Spillway**

The emergency overflow outlet of the temporary sediment trap must be stabilized with rock, riprap, geotextile, vegetation or another suitable material which is resistant to erosion. A stable emergency spillway must be installed to safely convey stormwater runoff for the 10-year storm event.

An emergency overflow weir should be provided at an elevation of at least 1.5 feet below the top of embankment, with a minimum freeboard of 1 foot. The minimum bottom width of a trapezoidal section for an emergency overflow weir should be:

- 4 feet - 1 acre (total drainage area)
- 6 feet - 2 acres (total drainage area)
- 8 feet - 3 acres (total drainage area)
- 10 feet - 4 acres (total drainage area)
- 12 feet - 5 acres (total drainage area)

*Drainage areas over 5 acres as designed



Sediment Trap Dimensions

<i>H</i>	<i>HO</i>	<i>W</i>	<i>W (BASE)</i>
2.0	1.0	5.0	9.0
2.5	1.0	5.5	10.5
3.0	1.5	6.0	12.0
3.5	2.0	6.5	13.5
4.0	2.5	7.0	15.0
4.5	3.0	7.5	16.5
5.0	3.5	8.0	18.0

*Units: Feet***Installation Procedures**

Contractors should construct temporary sediment traps near the beginning of a construction project, after establishing the perimeter erosion control measures and before any clearing or grading operations. This practice will be useful in the early stages of the construction process as it will negate the detrimental characteristics of grading, earthwork, trenching and other land-disturbing activities.

- Use perimeter erosion control measures in the vicinity adjacent to the sediment trap location. Areas under embankments should be cleared and grubbed. Grade and/or excavate to construct the required volume and to provide fill material for any embankments.
- Use clay for fill materials that is free of roots, large rocks, and organic material. Place fill and compact with a sheeps foot roller or other vibratory equipment in 6 inches layers.
- Install outlet structures such as rock outlet berm, or an emergency overflow weir. Prevent outlet failure by installing geotextile fabric and wire fencing. Baffles should be used to maximize storm water residence time within the sediment trap.
- Stabilize slopes using temporary vegetation, erosion control matting, mulch or other measures. Inspect final work for safety and function. Warning signs, barricades, perimeter fence or other measures necessary should be installed to protect construction workers and equipment.

Activity: Sediment Traps





SMP-04

Maintenance

- Inspect traps weekly and before and after heavy rainfall.
- Maintain traps to guarantee correct utilization.
- Remove sediment after it reaches $\frac{1}{3}$ the height of the trap.

Inspection Checklist

- Constructed traps serve 10 acres or less.
- Type of outlet structure used matches EPSC plan.
- Structure is stabilized to prevent erosion.
- Gage is visible and correctly indicates the depth of the trap.
- Sediment accumulation does not exceed $\frac{1}{3}$ the height of trap.
- Trap is constructed in such a way that no damage occurs to life or property.
- Trap is maintained

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-05	
	Activity: Temporary Sediment/Detention Basin (DB)		
PLANNING CONSIDERATIONS: Design Life: 12-18 months Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: 30% of Installation			
			
	Target Pollutants		
	Significant ♦	Partial ♦	Low or Unknown ♦
	Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oil & Grease ♦ Bacteria & Viruses ♦	Oxygen Demanding Substances ♦ Floatable Materials ♦	Toxic Materials ♦ Construction Waste ♦
Description	Typically temporary sediment/detention basins require the construction of an embankment across the drainage path in order to create a pond to trap sediment and inhibit the potential of downstream flooding. Sediment basins are usually designed by a professionally licensed engineer.		
Suitable Applications	<ul style="list-style-type: none"> ➤ For disturbed areas between 5 to 100 acres. ➤ Collect and store sediment from areas that have been cleared in preparation for construction. ➤ Used in areas where sediment-laden runoff may enter waterways. ➤ Suitable for almost all construction projects. 		
Approach	<ul style="list-style-type: none"> ➤ The sediment control basin should be designed by using SEDCAD, or another suitable computer program. ➤ The intent of this BMP is to trap sediment before it leaves the construction area. ➤ Provide a detention time of 24-48 hours for a 10-year 24-hour wet weather event. ➤ Provide a minimum storage capacity of 3600 cf per acre of bare soil. ➤ The ratio of basin flow length to flow width is 2:1. ➤ There are three components to the successful design of a sediment basin: <ul style="list-style-type: none"> • Embankment • Principal Spillway • Emergency Spillway 		

**Approach
(cont'd)**

Embankment Recommendations

- Slopes on either side of the embankment shall not be steeper than 3:1, in order to allow the area to be safely mowed and maintained.
- Provide for a minimum of 1-foot of freeboard for a 100-year 6-hour wet weather event.
- The minimum width at the top of the embankment is 12-inches.

Principal Spillway Requirements

- Provide a subsurface drain or solid riser pipe with dewatering holes to allow sufficient detention time.
- The outlet pipe diameter shall be a minimum of 8-inches.
- The post construction peak flow shall exceed the pre-developed levels of the 2-year and 10-year 24-hour wet weather events.
- Install a trash rack.

Emergency Spillway Requirements

- Emergency spillway shall be designed to pass a 100-year 6-hour wet weather event, to the top of the embankment.
- Provide a minimum of one foot of freeboard between the top of the riser pipe and the crest of the spillway.

**Installation
Procedures**

- Construct this BMP prior to any clearing and grading on the construction site.
- Construct a cut-off trench along the centerline of the earth fill embankments, extending up both embankments to the riser crest elevation. The minimum depth of this trench shall be 2-feet.
- Fill material for the embankment shall be free of roots, woody vegetation, oversized stones, rocks and other deleterious materials.
- Place fill material in 6 inch lifts with continuous layers extending the entire length fill, and compacted to 95 percent of maximum density and +/- 2 percent of optimum moisture content.
- Construction the embankment to a height 10% higher than the required crest elevation to allow for settlement if construction traffic (hauling in/out) is used to compact the soil. If compaction equipment is used, reduce the height to 5%.
- Weld the principal spillway pipe to the discharge pipe with a watertight connection.
- The principal spillway and discharge pipes shall be placed on a firm, smooth soil foundation. Pervious materials such as sand, gravel or crushed stone shall not be used as backfill around the pipes.
- Do not construct the emergency spillway in fill.
- Securely anchor and install anti-seep collar on the outlet pipe/riser for events larger than 2-year storm events.
- Stabilize the embankment with vegetation immediately following construction.

Activity: Temporary Sediment/Detention Basin**SMP-05****Installation Procedures (cont'd)**

- Check with local ordinances and state requirements to ensure proper fencing and signage are placed, warning the public of potential sediment and flooding hazards.
- The basin's volume should capture at least a 2 year 24 hour storm.

Special Note





Any sediment basin may be required to meet the dam safety requirements and approval of the Kentucky Division of Water. The definition of a dam is any impounding structure that is 25-feet in height from downstream toe to crest, or has the capacity to impound up to 50 acre feet of water. Structures that do not meet these requirements but may have the same detrimental impact downstream are subject to similar criteria as the dams.

Maintenance

- Inspect weekly as well as before and after wet weather events.
- Repair all damages to and within the basin due to construction by the end of the work day.
- Maintain all aspects of the basin (outlet area, outlet structures, etc.).
- Remove sediment when storage is $\frac{1}{2}$ full.
- Ensure that all sediment removed from the basin will not erode from the site.
- Basin failure should not affect loss in life, property, roads, or utilities.

Inspection Checklist

- Structure has appropriate outlet design.
- Stabilized outlet prevents erosion.
- Sediment accumulation does not exceed $\frac{1}{2}$ depth of basin.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-06																		
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: 50-70% of Installation																				
	<div style="text-align: center;">Target Pollutants</div> <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Significant ◆</td> <td>Partial ◆</td> <td>Low or Unknown ◆</td> </tr> <tr> <td>Sediment ◆</td> <td>Heavy Metals ◆</td> <td>Nutrients ◆</td> </tr> <tr> <td>Oil & Grease ◆</td> <td>Bacteria & Viruses ◆</td> <td>Floatable Materials ◆</td> </tr> <tr> <td></td> <td></td> <td>Oxygen Demanding Substances ◆</td> </tr> <tr> <td></td> <td></td> <td>Toxic Materials ◆</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ◆</td> </tr> </table>	Significant ◆	Partial ◆	Low or Unknown ◆	Sediment ◆	Heavy Metals ◆	Nutrients ◆	Oil & Grease ◆	Bacteria & Viruses ◆	Floatable Materials ◆			Oxygen Demanding Substances ◆			Toxic Materials ◆			Construction Waste ◆	
Significant ◆	Partial ◆	Low or Unknown ◆																		
Sediment ◆	Heavy Metals ◆	Nutrients ◆																		
Oil & Grease ◆	Bacteria & Viruses ◆	Floatable Materials ◆																		
		Oxygen Demanding Substances ◆																		
		Toxic Materials ◆																		
		Construction Waste ◆																		
Description Suitable Applications Approach	<p>Bank stabilization is used to reduce erosion from stream banks by providing protective cover through the use of vegetation and other methods.</p> <ul style="list-style-type: none"> ➤ Bank stabilization practices are used for stream banks susceptible to erosion, locations with high flow rate that are subject to produce erosion, and/or actively eroding stream banks. ➤ Due to the nature of these practices additional permitting through the state or other agencies may be required. <p>➤ Structural measures such as retaining walls, gabions, rip-rap or interlocking blocks.</p> <p>Structural practices are used for projects in which a quick stabilization of stream banks is required. Generally speaking, these practices are more costly than bioengineering solutions. However, they usually require less maintenance than bioengineering measures.</p> <p>➤ Bioengineering methods</p> <p>Bioengineering methods are commonly used for this purpose. These methods generally take longer to establish stabilization. However, they can be quite effective and economical to implement. As with any vegetative practice, careful selection of materials, installation, and maintenance is necessary to be effective.</p>																			

**Approach
(Continued)**

Several methods of Bioengineering solution are listed as follows:

➤ **Live Stake**

Live stakes are the insertion of live, rootable vegetative cuttings into the ground. Live stakes are an appropriate technique for repair of small earth slumps that are frequently wet. Or they can be used to supplement other types of bank stabilization plantings. Live stakes can also be installed through existing riprap or other aggregate materials, allowing a stabilized riprap location to eventually have natural vegetation.

Live stakes are usually 0.5 to 1.5 inches in diameter and approximately 2 to 3 feet in length. Typical spacing is 2 to 3 feet apart. The basal end (or root) is cut to an angled point for easy insertion. The top should be cut square. Willow branches have historically been specified for use as live stakes and are well-suited to the purpose. Other types of tree branches may be selected, depending on soil type and available moisture conditions, such as ash, alder, elm or dogwood.

Gently tamp the live stake into the ground at right angles to the slope. Approximately 80 percent of the live stake length should be installed into the ground. Pack soil firmly around live stake after installation. Do not split the stakes during installation; stakes that split should be removed and replaced. An iron bar can be helpful in establishing a pilot hole for the live stake.

➤ **Live Fascine**

A fascine is defined as a bundle of sticks or branches, tied together and used for a definite purpose such as preparing a primitive house, fort, or other structure. A live fascine is defined as a bundle containing live branch cuttings bound together into sausage-like structures, and then placed to provide slope stability or prevent erosion.

Live branch cuttings should be from species that easily root and have long, straight branches. Cuttings are tied together to form live fascine bundles that vary in length from 5 to 30 feet, depending on site conditions and limitations in handling. The completed bundles should be 6 to 8 inches in diameter, with all of the growing tips oriented in the same direction. Stagger the cuttings in the bundles so that tops are evenly distributed throughout the length of the uniformly sized live fascine.

Both live stakes and dead stakes are used to install fascine bundles. Stakes should be at least 2.5 feet long on cut slopes and at least 3 feet long on fill slopes. Dead stakes can be constructed from untreated 2x4 lumber with a minimum length of 2.5 feet. A diagonal cut across the 2x4 lumber will assist in creating stakes quickly.

Prepare the live fascine bundles and live stakes immediately before installation. Begin at the base of the slope and work upwards. Dig a trench along a level contour just deep enough to contain the live fascine bundle. A typical trench size is 12 to 18 inches across and also 6 to 8 inches deep. Place the live fascine bundle into the trench.

Drive dead stakes directly through the bundle every 2 to 3 feet to securely fasten it. Extra stakes should be used at connections and overlaps. Leave the top of stakes flush with the installed bundle. Live stakes are generally installed on the downslope side of the bundle. Drive the live stakes below and against the bundle between the previously installed dead stout stakes. The live stakes should protrude 2 to 3 inches above the top of the live fascine. Place moist soil along the sides of the live fascine. The top of the fascine should be slightly visible when the installation is completed as shown in Figure ES-20-1.

**Approach
(Continued)**

Place straw or similar mulching material between rows. Slopes steeper than 3:1 may need erosion control matting or some type of mesh to prevent erosion. Recommended maximum slope lengths for live fascine bundles are:

<u>Slope (H:V)</u>	<u>Maximum slope length</u>
1 : 1 to 1.5 : 1	15 feet
1.5 : 1 to 2 : 1	20 feet
2 : 1 to 2.5 : 1	30 feet
2.5 : 1 to 3 : 1	40 feet
3 : 1 and flatter	50 feet

A willow mattress (also called a brush mattress) is similar to a fascine roll. Willow branches and cuttings are formed into a layered arrangement approximately 4 to 6 inches thick and then tied with twine or string. Excavate an anchor trench along the bottom of the willow mattress to a depth of 3 inches, to prevent downhill sliding. Loosen the subgrade soil throughout the mattress installation location; add lime and slow-release fertilizer as needed. A willow mattress is anchored onto a slope by using dead stout stakes and twine. Place 4 to 6 inches of fertile soil upon the willow mattress and tamp firmly.

➤ **Branchpacking**

Branchpacking consists of alternating layers of live branch cuttings and compacted backfill to create bank stabilization vegetation. It is often used to repair small localized slumps, gully washouts, or other small areas where the slope needs to be stabilized.

Branchpacking can also be adapted as a method for planting an entire slope (see description below for brushlayering).

Live branch cuttings may range from 1/2 inch to 2 inches in diameter. Cuttings should be long enough to touch the undisturbed soil at the back of the trench. Wooden stakes (typically made from 2x4 lumber, untreated) are 5 feet or longer, depending on the depth of the hole and field conditions. Starting at the lowest point, drive the wooden stakes vertically 3 to 4 feet into the ground, at a typical spacing of 1 to 2 feet apart.

Place a 6-inch layer of live branch cuttings in the bottom of the hole or trench, between the vertical stakes and perpendicular to the slope face (as shown in Figure ES-20-2). Cuttings should be placed in a crisscross configuration with the growing tips generally oriented toward the slope face. Most branch basal ends should touch the back of the hole or slope. Each layer of branches is followed by a layer of compacted soil, typically 6 to 8 inches thick, to ensure soil contact with the branch cuttings. Final grade should match the existing slope, and branches should protrude slightly from the filled face. The soil should be moist so that the live branch cuttings do not dry out.

Branchpacking may not be effective in slumped areas or gullies which are greater than 5 feet wide. Examine the slope closely to determine the cause of slumped areas and gullies. Wet soils, inadequate drainage, excessive stormwater runoff or other site conditions may require additional solutions.

**Approach
(Continued)**

Brushlayering is a variation of branchpacking suitable for gentle slopes with only a moderate potential for erosion. The live branch cuttings are oriented perpendicular (up and down) to the slope level contours, installed in a trench or cut slope, and then covered with soil as before. The difference is that the soil for each downhill trench comes from the next excavated trench immediately uphill. The presence of branch cuttings in the soil will limit the amount of compaction that can be obtained on a slope, so that additional erosion control measures may be necessary. Straw mulch, temporary seeding, jute mesh and erosion control mats may be necessary, particularly for slopes steeper than 3:1. Avoid slopes steeper than 2:1 and generally limit slope lengths to 20 feet or less.

➤ **Vegetative Crib Walls**

A crib wall is a hollow, box-like, interlocking arrangement of structural members to create a retaining wall. A retaining wall is an engineered structure, with calculated loads and stresses used for the material selection and design. Crib walls made from prefabricated metal or reinforced concrete beams can be designed as very tall retaining walls that can handle large surcharge loads and traffic impacts; these types of crib walls must be designed by a professional engineer. Crib walls are filled with compacted soil or gravel, with provisions for subsurface drainage.

Adding vegetation may or may not affect structural stability of a retaining wall in the future. It would certainly affect large structural crib walls, but should not impact small crib walls such as the type shown in Figure ES-20-3 for a relatively short height using untreated logs or timber. The structure is filled with suitable backfill material and layers of live branch cuttings which will root inside the crib structure and extend upward into the slope or outward into the wall face. This technique is appropriate at the base of a slope where a low wall may be required to stabilize the toe.

Live branch cuttings should be long enough to reach the back of the wooden crib structure. Logs or timbers are usually 6 inches in diameter or thickness. Large nails or rebar are required to secure the logs or timbers together. Place foundation of wall 2 to 3 feet below grade, as shown on Figure ES-20-3.

Place the first course of logs or timbers at the front and back of the excavated foundation, approximately 4 to 5 feet apart. Place the second course of logs or timbers at right angles (perpendicular to the slope) on top of the previous course to overhang the front and back of the previous course by 3 to 6 inches. Repeat course in same manner and nail to the preceding course with nails or reinforcement bars. When the crib wall structure reaches the existing ground elevation, place live branch cuttings on the backfill perpendicular to the slope. Then cover the branch cuttings using fertile soil as backfill and compact firmly.

**Installation
Procedures**

- Groove or stair step cut grading is recommended for slopes steeper than 3:1 (H:V)
- To control erosion vegetation and simple retaining structures should be considered
- Retaining structure must meet two minimums: pressure beneath the base must not exceed the allowable soil pressure; structure should possess adequate strength under loaded conditions.
- Cribwall structures consisting of vegetative matters are called "live" cribwall.
- Cribwall structures should start 2-3 feet below ground elevation at the lowest point of the slope to stabilize the structure.
- The first course of reinforcement should start 4-5 feet apart and parallel to the slope

Activity: Bank Stabilization**SMP-06****Installation
Procedures
(cont'd)**

- Other courses of reinforcement will follow the same pattern as the first and second course while being fastened with nails, bars, or bands to the previous course.
- Rock Gabions follows the same procedures for foundation stabilization as Cribwall.
- The back of the foundation should be exhumed slightly deeper than the front to add stability.
- Fabricated wire baskets should be placed at the bottom of the exhumed site prior to rock filling. Rock filling should be between and behind the basket wire.
- Continue filling area with wire baskets and rock fill until desired height is reached.
- ALL structure construction must be performed by a Licensed Professional Engineer.


Maintenance

- Inspect structure before and after rainfalls.
- Make repairs when necessary.

**Inspection
Checklist**

- Licensed Professional Engineer's stamp is clearly placed on plans in order to construct the appropriate retention structure.
- Changes to site conditions have been transmitted for review by the Project Engineer.


Cross section
Not to scale



Note:
Rooted/leafed condition of the living
plant material is not representative of
the time of installation.



Figure SMP-06
Live Cribwell

Cross section
Not to scale



Note:
Rooted/leafed condition of the living plant material is not representative of the time of installation.

Figure SMP-06-2
Vegetated Rock Gabions

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-07														
	Activity: Riprap (RR)															
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: 20-40% of Installation		— RR —														
<p style="text-align: center;">Target Pollutants</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Significant ♦</td> <td>Partial ♦</td> <td>Low or Unknown ♦</td> </tr> <tr> <td>Sediment ♦</td> <td>Heavy Metals ♦</td> <td>Nutrients ♦</td> </tr> <tr> <td>Oil & Grease ♦</td> <td>Bacteria & Viruses ♦</td> <td>Floatable Materials ♦</td> </tr> <tr> <td></td> <td>Oxygen Demanding Substances ♦</td> <td>Toxic Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ♦</td> </tr> </table>		Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦		Oxygen Demanding Substances ♦	Toxic Materials ♦			Construction Waste ♦
Significant ♦	Partial ♦	Low or Unknown ♦														
Sediment ♦	Heavy Metals ♦	Nutrients ♦														
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦														
	Oxygen Demanding Substances ♦	Toxic Materials ♦														
		Construction Waste ♦														
Description Suitable Applications Installation Procedures	<p>Riprap is a permanent erosion prohibiting ground cover that requires the placement of large, loose, angular stone with a geotextile or granular underlining. This BMP significantly reduces erosion and sediment movement.</p> <ul style="list-style-type: none"> ➤ Along a stream or within a ditch to provide an erosion resistant lining. ➤ On lakefronts and riverfronts, or any other areas subject to wave harmonics. ➤ Surrounding culvert inlets and outlets to protect against scouring and undercutting ➤ In channels to reduce velocities, dissipate hydraulic energies and promote infiltration. ➤ On slopes that are not conducive to the establishment of ground cover. <ul style="list-style-type: none"> ➤ Riprap application and implementation for channel or slope stabilization should be designed by a professional familiar with drainage and stormwater conveyance measures. ➤ Riprap placement should be completed within a short time period (less than a week) to minimize potential damage resulting from stormwater runoff. ➤ The area should be cleared of trees and shrubs in order to provide sufficient access to the site for the construction equipment. ➤ When used as slope protection, riprap should be keyed into the slope toe by at least the greater of 6 inches or one half the designed riprap diameter. ➤ Riprap should not be placed until final subgrade elevation has been verified by the licensed engineer overseeing design and/or construction. 															

Installation Procedures (cont'd)

- Geotextile should be installed to maintain separation of rock material from the underlying soil. Geotextile should not be stretched or otherwise compromised. Secure fabric with anchor trenches, stakes, staples or any other method recommended by the manufacturer.
- When subgrade filters are required, place a layer of aggregate or sand so that the layer is smoothly graded and well compacted.
- When subgrade filters are not required, the subgrade should be compacted as to prevent undercutting or slumping from occurring.

Rubble-Stone Riprap (Plain)

- Rubble-stone riprap should consist of at least 90% of the stone not less than 8 inches wide by 12 inches long by 12 inches deep and should be approximately rectangular in shape. Rubble-stone should be hand placed so that the stones are close together, are staggered at all joints as far as possible, and are placed so as to reduce the voids to a minimum. The main stone should be thoroughly "chinked" or anchored in place with 1-in. to 3-in. stones by throwing them over the surface in any manner that is practical for the smaller stones to fill the voids.
- The standard depth should be 24 inches. The average depth should not be less than the required depth and is determined from evaluation of a 25 square foot surface area.
- When rubble-stone rip-rap is constructed in layers, the layers should be thoroughly tied together with large stones protruding from one layer into the other.

Rubble-Stone Riprap (Grouted)

- Stone placement for rubble-stone riprap (grouted) is the same as for rubble-stone rip-rap (plain). The grouting procedure is as follows:
- When grouting is used, care should be taken to prevent earth or sand from filling the spaces between the stones before the grout is poured. Grout should be composed of one part Portland cement and four parts of sand, measured by volume, and mixed thoroughly with sufficient water to a consistency that it will flow into and completely fill the voids.
- Immediately before pouring the grout, the stones should be wetted by sprinkling. Beginning at the lower portion of the riprap, the grout should be carefully poured into the voids between the stone and at a rate slow enough to prevent oozing to the surface. The pouring of the grout should be accomplished by the use of vessels, chutes, tubes, or hoses of adequate size and shape. Broadcasting, slopping, or spilling of grout from the vessels on the surface of the rip-rap is not allowed.
- As soon as any section of the grouted riprap has hardened sufficiently, it should be kept moist with water that is free from salt or alkali for a period of not less than 72 hours.

**Installation
Procedures
(cont'd)***Sacked Sand-Cement Riprap*

- Sand for sacked sand-cement riprap may be manufactured or natural but should conform to state regulations. The same is true for Hydraulic cement. The sand and cement should be mixed dry, with a mechanical mixer, in the proportion of one bag (94 pounds) of cement to 5 cubic feet of dry sand, until the mixture is uniform in color. The sand-cement mix should be poured into sacks of approximately 1 cubic foot capacity until they are approximately $\frac{3}{4}$ full. Sacks should be of either cotton or jute standard grade of cloth which will hold the sand-cement mixture without leakage during handling and tamping. The sacks should then be securely fastened with hog rings, by sewing, or by other suitable methods that prohibit leakage of the mixture from the bags.
- The sacks of sand-cement should be bedded by hand on the prepared grade with all the fastened ends on the grade and with the joints broken. The completed riprap should have a minimum thickness of 10 inches with a tolerance of 3 inches.
- The sacks should be rammed and packed against each other in such a manner as to form close contact and secure a uniform surface. Immediately after tight placement, the sacks of sand-cement should be thoroughly soaked by sprinkling with water. Water should not be applied under high pressure. Sacks that are ripped or broken in placement should be removed and replaced before being soaked with water.

Machined Riprap





- Machined riprap should be clean shot rock containing no sand, dust, or organic materials and should be the size designated for the class specified. The stone should be uniformly distributed throughout the size range.

Maintenance

- Riprap requires minimum maintenance
- Check after storm events for maintenance purposes, replace any portion of the riprap that needs attention
- Check for brush growth, remove the evidence which appears

**Inspection
Checklist**

- Verify that displacement does not occur due to steep slopes or small riprap.
- Proper filter cloth is used.
- Riprap graded properly according to contract documents.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-08					
	Activity: Channel Linings (CL)						
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: Negligible		 CL 					
<p style="text-align: center;">Target Pollutants</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Significant ♦</td> <td>Partial ♦</td> <td>Low or Unknown ♦</td> </tr> <tr> <td>Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦</td> <td>Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦</td> <td></td> </tr> </table>		Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦	Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦	
Significant ♦	Partial ♦	Low or Unknown ♦					
Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦	Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦						
Description Suitable Applications Approach	<p>Constructed or natural waterways will occasionally require vegetation or rock lining to protect it from erosion.</p> <p><i>Rock Lined Channels</i></p> <ul style="list-style-type: none"> ➤ Channels with runoff velocities exceeding 2 ft/sec. ➤ Channels or ditches with grades greater than 2 percent. ➤ Channels or ditches with highly erodible soils. ➤ Channels where the design velocity exceeds that allowable for grass lined channels. <p><i>Grass Lined Channels</i></p> <ul style="list-style-type: none"> ➤ Slopes that do not exceed a 5% grade. ➤ Sites where vegetation is required. <p>There are two types of channel lining:</p> <ul style="list-style-type: none"> ➤ Rock lined channels <ul style="list-style-type: none"> • Channel is required to carry the 10-year 24-hour peak flow where: <ul style="list-style-type: none"> ▪ $Q = V \cdot A$, where Q = Flow V = Velocity A = Flow Area • The Manning Equation shall be used to determine the velocity <ul style="list-style-type: none"> ▪ $V = \frac{1.486}{n} \cdot R^{2/3} \cdot S^{1/2}$, where V = Velocity R = flow area/wetted perimeter S = Slope in ft/ft n = 0.0395 (D50)^{1/6} 						

**Approach
(cont'd)**

- Rock lined channels (cont'd)
 - The maximum depth of channel shall be calculated with the following equation
 - $D_{max} = \tau / (62.4 * S)$, where
 D_{max} = maximum depth of flow
 S = Slope in ft/ft
 τ = maximum tractive force of the liner in lbs/ft²
 (see Table SMP-08-01 for shear stress quantities)
 - Side slopes shall be 2:1 or flatter
 - Riprap thickness: The thickness shall be 1.5 times thicker than the stone diameter, unless shown otherwise in the plans. Minimum of 6 inches.
 - Foundation: Extra-strength filter fabric or aggregate filter layered, as required.
 - Channel outlet must be stable.

- Vegetative channels
 - Grass channels are generally constructed with sides at a 3:1 slope to aid in establishment and safety in maintenance.
 - Channel is required to carry the 10-year 24-hour peak flow where:
 - $Q = V * A$, where
 Q = Flow
 V = Velocity
 A = Flow Area
 - The Manning Equation shall be used to determine the velocity
 - $V = \frac{1.486 * R^{2/3} * S^{1/2}}{n}$, where
 V = Velocity
 R = flow area/wetted perimeter
 S = Slope in ft/ft
 n = 0.045 for grass
 - The maximum depth of channel shall be calculated with the following equation
 - $D_{max} = \tau / (62.4 * S)$, where
 D_{max} = maximum depth of flow
 S = Slope in ft/ft
 τ = maximum tractive force of the liner in lbs/ft²
 (see Table SMP-08-02 for shear stress quantities)
 - *V-shaped Channels*
 - Typically used for smaller, roadside channels.
 - Use a grass or sod lining where velocities are low
 - *Parabolic Channels*
 - Used for larger flows if space allows.
 - Riprap should be used wherever velocities are highest
 - Areas of continuous flows use grass channels with centered reinforcement mats.
 - *Trapezoidal Channels*
 - For channels with large volume and flatter slopes.
 - In some cases concrete or riprapped channels may be required.

Approach
(cont'd)

Table SMP-08-01
KYTC Channel Lining Values

KYTC Channel Lining	D50	Manning's	Shear
		n	(lb/ft ²)
Class I	0.2	0.0302	1.00
Class II	0.5	0.0352	2.50
Class III	1.0	0.0395	5.00

Table SMP-08-01
Maximum Shear Stress of Liners

Material	Shear (lb/ft ²)
Dense sod, fair condition (Class D/E), moderately cohesive soil	0.35
Bermuda grass, fair stand < 5" tall, dormant	0.90
Bermuda grass, good stand < 5" tall, dormant	1.10
Bermuda grass, excellent stand 20" tall, dormant	2.70
Bermuda grass, excellent stand 20" tall, green	2.80
Bermuda grass, excellent stand >20" tall, green	3.20
Turf (immediately after construction)	0.20
Turf (after 3-4 season)	2.04
Turf reinforcement mat, permanent	8.00
Straw reinforcement mat, temporary	0.45
Jute mat	0.45
Straw with net	1.45
Curled wood net	1.55
Synthetic mat	2.00

Source: Salix Applied Earthcare – Erosion Draw 5.0

Installation
(cont'd)

Rock Lined Channels

- Cross sections shall be excavated according to the grade shown on plans
- Overcut for thickness of rock and filter
- As soon as foundation is prepared, place filter and/or fabric filter immediately.
- Rock should be placed such that it forms a dense, uniform, well graded mass with few voids. Hand placement may be required in places that machinery can not reach.
- Channel outlet shall be stabilized.

Grass Lined Channels



- *See the specifications for seeding and erosion control blankets.*

Maintenance

- Inspect after every storm event greater than 0.5 inches, if not every week.
- Check rip-rap BMP for appropriate installation and maintenance processes.
- Remove any deleterious debris.
- Repair eroded or damaged material immediately.
- Check grass lined channels for establishment.
- For grass lined channels, check to see if established cover is withstanding high velocity flows.

**Inspection
Checklist**

- Adequate coverage is provided to prevent washout.
- Repair torn netting or mats.
- Slope of channel is consistent with contract documents.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-09
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Medium Monthly Maintenance: N/A		→ TD → TD <div style="border: 1px solid black; padding: 5px; display: inline-block;">TD</div>
	Target Pollutants	
	Significant ◆ Partial ◆ Low or Unknown ◇	
	Sediment ◆ Heavy Metals ◆ Nutrients ◆ Oxygen Demanding Substances ◆ Toxic Materials ◇ Oil & Grease ◆ Bacteria & Viruses ◇ Floatable Materials ◆ Construction Waste ◇	
Description Suitable Applications Installation Procedures	<p>These temporary drains offer features such as conveyance for runoff down cut or fill slopes, subsurface drains that drain off excessive soil saturation, minimization of sheet flow over slope surfaces and reduced sedimentation. Once stabilized, diversions require relatively little maintenance.</p> <ul style="list-style-type: none"> ➤ Provide drains to prevent slope failures, damage to adjacent property, erosion and sediment control and removes excess water from soil. ➤ Diversions to catch runoff at the end of an undisturbed slope before entering a bared area, direct runoff, preserve stable conveyance and to prevent overflow. <p>A diversion prevents erosion by directing runoff to an erosion control device such as a sediment trap or directing runoff away from an erodible area. Temporary diversions should not adversely impact adjacent properties and must conform to local floodplain management regulations. This practice should not be used in areas with slopes steeper than 10%. The advantages of the temporary earth dike include the ability to handle flows from large tributary areas. Additionally, they are relatively inexpensive to install since the soil material required for construction may be available on-site, and can be constructed as part of the initial grading operations, while the equipment is on-site.</p> <p>Temporary swales will effectively convey runoff and avoid erosion if constructed and maintained properly:</p> <ul style="list-style-type: none"> ➤ Size temporary swales in the same manner as a permanent channel. ➤ A permanent channel must be designed by a licensed professional civil engineer. ➤ At a minimum, the swale should conform to predevelopment flow patterns and capacities. ➤ Construct the swale with an uninterrupted, positive grade to a stabilized outlet. 	

Installation
Procedures
(cont'd)*Drains*

Diversion drains are only effective if they are properly installed. Swales are more effective than dikes because they tend to be more stable. The combination of a swale with a dike on the downhill side is the most cost-effective diversion.

- Can be placed on or buried underneath the slope surface.
- Should be anchored at regular intervals of 50 to 100 ft.
- If a slope drain conveys sediment-laden water, direct flows to a sediment trap or basin.
- When using slope drains, limit tributary area to 2 acres per pipe. For larger areas, use a rock-lined channel or a series of pipes.
- Maximum slope generally limited to 2:1 (H: V), as energy dissipation below steeper slopes is difficult.
- Drain or swale should be laid at a minimum grade of 1%, but not more than 15%.
- The swale must not be overtopped by the 10-year, 24-hour storm, meeting or exceeding the design criteria stated above.
- Remove all trees, stumps, obstructions, and other objectionable material from the swale when it is built.
- Compact any fill material along the path of the swale.
- Stabilize all swales immediately. Seed and mulch swales at a slope of less than 5 percent, and use rip-rap or sod for swales with a slope between 5 and 15 percent.
- Do not operate construction vehicles across a swale unless a stabilized crossing is provided.
- Direct surface runoff to slope drains with diversion swales, dikes and berms.
- When installing slope drains:
 - Install slope drains perpendicular to slope contours.
 - Compact soil around and under entrance, outlet, and length of pipe.
 - Securely anchor and stabilize pipe and appurtenances into soil.
 - Check to ensure that pipe connections are watertight.
 - Protect inlet and outlet of slope drains: use standard flared end section at entrance for pipe slope drains 12 in. and larger.
 - Protect area around inlet with filter cloth.
 - Protect outlet with geosynthetics and rip-rap or other energy dissipation device. For high-energy discharges, reinforce rip-rap with concrete or use reinforced concrete devices.
- When installing subsurface drains:
 - Slightly slope subsurface drain towards outlet.
 - Check to ensure that pipe connections are watertight.
 - Review relative size of soil and slot/perforation size in the pipe to prevent sediment from entering pipe.
 - Relief drains lower groundwater table. Install parallel to slope and drain to side of slope. Use gridiron, herringbone or random pattern.
 - Interceptor drains prevent excessive soil saturation on sensitive slopes. Install perpendicular to slope and divert discharge to the side of the slope.

**Installation
Procedures
(cont'd)***Diversions*

- Select design flows and safety factor based on careful evaluation of risks due to erosion of the measure, over topping, flow backups, or washout.
- High flow velocities may require the use of a lined ditch, or other methods of stabilization.
- When installing diversion ditches and berms:
 - Protect outlets from erosion.
 - Utilize planned permanent ditches/berms early in construction phase when practicable.
- All dikes and berms should be compacted by earth-moving equipment.
- All dikes should have positive flow to a stabilized outlet.
- Top width may be wider and side slopes may be flatter at crossings for construction traffic.
- Dikes should direct sediment-laden runoff into a sediment trapping device.
- Dikes should be stabilized with vegetation, chemicals, or physical devices.
- Compact any fills to prevent unequal settlement.
- Dikes should remain in place until disturbed areas are permanently stabilized.
- Examine the site for run-on from off-site sources (control off-site flows through or around site).
- Select flow velocity limit based on soil types and drainage flow patterns for each project site
- Establish a maximum flow velocity, shear stress or 3-5 ft/s, for using earth dikes and swales, above which a lined ditch must be used.
- Design an emergency overflow section or bypass area for larger storms that exceed the 10-year design storm.
- Conveyances must be lined or reinforced when velocities exceed allowable limits for soil. Consider use of geotextiles, engineering fabric, vegetation, rip-rap or concrete.

Maintenance

- Inspect drains before and after each storm event
- Inspect weekly until drainage area is stabilized
- Maintain drains and swales to eliminate erosion, accumulation of debris and sediment
- Check status of water ponding activities. Remove water if such activities occur
- Temporary conveyances should be removed when surroundings become stable or when the construction is complete

**Inspection
Checklist**

- Routine visit after every heavy rain water event.
- No evidence of washout, accumulated debris and build up in ditches or berms.

Activity: Filter Strips**SMP-10****Installation
Procedures**




- Cultivate the area then install the irrigation system
- Areas should be excavated and backfilled (plant holes)
- Areas are to be fine graded and rolled prior to sodding
- Sodded areas are to be uniform and smooth (prior to sodding) and distributed with top soil were needed (to even out the area)
- Sod end of adjacent strips should stagger by half the width or length
- Areas adjacent to sidewalks, concrete headers, header boards and other paved borders shall be 1.5 in-0.25 in below the top grade of the facilities
- Seed beds should be added to fertilizers and added to the correct site condition to slow the velocity of runoff and allow sedimentation to take place
- Roll sod to eliminate air pockets and allow a closer contact with the soil.
- Water sod so that the soil at a minimum depth of 4 feet is moistened
- Do not allow sod to dry out
- Sod should not be planted on slopes that are greater than 3:1 (H:V) if no mowing is to occur
- Vegetate sodded areas
- Do not use buffer strip for vehicular traffic
- All fertilization efforts should follow the outline of the state, county, and/or local government

Maintenance

- Inspect weekly after rainfall events until turf is established
- Mowing shall consist of "tall" mowing, weeding and the irrigation system is growing and operating properly
- Fertilize as needed and as indicated by soil testing
- Overseed, repair bare spots, or apply additional mulch as necessary

**Inspection
Checklist**

- Practice has been properly mowed and maintained.
- Construction vehicles have been kept off BMP.
- Dead areas have been re-seeded, plugged or re-sodding
- Underwash turf has been maintained and compacted.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-11
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: 60% of installation		 <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: auto;">TIP</div>
Target Pollutants		
<div style="display: flex; justify-content: space-around;"> Significant ♦ Partial ♦ Low or Unknown ◇ </div>		
<div style="display: flex; justify-content: space-between; font-size: small;"> Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ </div> <div style="display: flex; justify-content: space-between; font-size: small;"> Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ♦ Construction Waste ◇ </div>		
Description Suitable Applications Approach Installation Procedures	<p>This practice allows sediment to settle prior to entering into a stormwater catch basin or inlet. The detainment of sediment-laden runoff through filtering devices allows a cleaner runoff to be discharged into the environment.</p> <ul style="list-style-type: none"> ➤ Protection of storm drain inlets or catch basins from sedimentation upstream of the inlet. ➤ Areas where ponds are not encroached into access road or highway traffic. ➤ Disturbed tributary areas have not yet been permanently stabilized. ➤ Areas where drainage is 1 acre or less. ➤ Areas with drainage more than 1 acre must be accompanied by a downstream sediment trap or basin. <p>Sediment control can be maintained using one of the following practices:</p> <ul style="list-style-type: none"> ➤ Filter Fabric Fences ➤ Block and Gravel Filter ➤ Gravel and Wire Mesh Filter ➤ Excavated Inlet Sediment Traps <p>Sediment filters are used as storm inlet protectors.</p> <ul style="list-style-type: none"> ➤ Filter Fabric Fences are desired for basins less than one acre with less than a 5% slope. Place 2 in. by 2 in. wooden stakes around the perimeter of the inlet a max. of 3 feet apart with an ending depth of at least 8 in. into the ground. Stakes should be 3 feet long. Excavate trench 8 inches wide and 12 inches deep around the outside perimeter of the stakes. Staple fabric to the stakes so that 32 in of the fabric extend out and can be formed into the trench (use heavy-duty wire staples at least 1 in. in length). Backfill trench with a ¾ in or less washed gravel all the way around. 	

Activity: Temporary Inlet Protection

SMP-11

Installation Procedures (cont'd)




- **Block and Gravel Filter** is desired for flows greater than 0.5 cfs. Hardware cloth should be dropped ½ in over drop inlet so that wire extends a minimum of 1 ft on each side. Concrete blocks should be placed lengthwise on their sides in a single row around the perimeter of the inlet with ends abut adjacently. Height can be 4, 8 or 12 in. wide by stacking combinations of concrete. Rows should be no greater than 24 inches high. Wire mesh should be over the outside vertical face of the concrete blocks to prevent stone from washing through blocks. Pile wash stone against the wire mesh to the top of the blocks. Use ¾ to 3 in. gravel.
- **Gravel and Wire Mesh Filter** is used on curb or drop inlets where construction equipment may drive over the inlet. Place over drop inlet so that wire extends on both sides at a minimum of 1 ft. Use hardware cloth or wire mesh with ½ in. opening. Place ¾ to 3 in. gravel over the filter fabric/wire mesh. Depth should be 12 inches over the entire inlet opening. Excavate drop inlet sediment trap, minimum storage capacity calculated at the rate of 67 cubic yards per acre (yd³/ac) of tributary area should be sized.
- **Sand Bag Barriers** are used to create a small sediment trap upstream of inlets on sloped, paved streets. Bags should be made of geotextile material and filled with ¾ in. rock or ¼ in. pea gravel. Leave room upstream for settlement and ponding. Place several layers of bags and pack them tightly together leaving a gap of one bag on the top row to serve as a spillway.
- **Excavated Drop Inlet Sediment Traps** are excavated areas around inlets to trap sediment.
- Gates and inlets should be sealed to prevent seepage of sediment-laden water.
- Excavate sediment sumps 1 to 2 feet with 2:1 (H:V) side slopes around the inlet.
- Provide areas around the inlet for water to pond without flooding structures and property.

Maintenance

- Replace clogged fabric immediately.
- Remove sediment when depth exceeds half the height of the filter or half the depth of the sediment trap.
- Inspect all inlets and catch basins weekly before and after each rain event.
- Inspect once every 24 hours during heavy rainfall events.
- After site is stabilized remove all inlet devices within 30 days.
- Bring disturbed area to final grade and smooth and compact it.
- Clean around and inside the storm drain inlet.

Inspection Checklist

- Filter fabric stakes are secure.
- Filter fabric is cleaned or replaced to prevent clogging.
- Sediment from behind the fabric less than ½ the height of the silt fence.
- Gravel filter is in working order. No evidence of gravel washing through.
- Do not clean any gravel adjacent to any inlet or waterway.
- Bags are properly maintained.
- No evidence of displacement of the practice.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Sediment Management Practices (SMPs)	SMP-12
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: N/A		 <div style="border: 1px solid black; padding: 5px; display: inline-block;">TOP</div>
	Target Pollutants	
	Significant ♦ Partial ♦ Low or Unknown ◇	
	Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description Suitable Applications Installation Procedures	<p>This protection outlet is constructed of rock, grouted rip-rap or concrete rubble. This practice prevents scour of the soil due to high pipe flow velocities. The dissipation of flow energy to produce non-erosive velocities is also a function of this BMP.</p> <ul style="list-style-type: none"> ➤ Areas where culverts, conduits or channels are sufficient to erode the immediate downstream reach. ➤ Outlets of pipes, drains, culverts, conduits, channels, locations at the bottom of mild to steep slopes, outlets of which carry continuous flows of water, short intense flows of water, lined conveyances discharge to unlined conveyance ➤ A sediment trap is recommended if runoff is sediment laden ➤ Do not use grouted rip-rap during freezing, which will cause grout to break <ul style="list-style-type: none"> ➤ Should be designed and sized by a licensed professional as a part of the culvert, conduit or channel design. ➤ Apply a rip-rap apron for temporary use during construction. ➤ Apron should consist of a zero grade, alignment with receiving stream. Avoid damaging the underlain filter fabric. Keep apron straight throughout the length of the stream, curving in the upper section of the harpoon if curve is needed. Bank reinforcement should be downstream to account for the curved apron. ➤ Sizing for average rock diameter and apron dimensions are found in Table SMP-12-01. 	

**Table SMP-12-01
Sizing for Flow Dissipaters at Culvert Outlet**

Culvert Size	Avg. Rock Diameter	Apron Width*	Apron Length**	Apron Length***
8"	3"	2-3 ft.	3-5 ft.	5-7 ft.
12"	5"	3-4 ft.	4-6 ft.	8-12 ft.
18"	8"	4-6 ft.	6-8 ft.	12-18 ft.
24"	10"	6-8 ft.	8-12 ft.	18-22 ft.
30"	12"	8-10 ft.	12-14 ft.	22-28 ft.
36"	14"	10-12 ft.	14-16 ft.	28-32 ft.
42"	16"	12-14 ft.	16-18 ft.	32-38 ft.
48"	20"	14-16 ft.	18-25 ft.	38-44 ft.

- Maintenance**
- Grouted or wire-tied rock rip-rap minimizes maintenance requirements.
 - Inspect weekly and before and after rainfall events.
 - Inspect apron for displacement and/or damage to the underlying fabric, scour beneath the rip-rap and around outlet.
 - Remove devices as soon as work is completed to the construction site.
 - Grouted rip-rap may break up in areas of freeze and thaw.
 - Grouted rip-rap may break up from hydrostatic pressure without adequate drainage.

- Inspection Checklist**
- Stones that have been displaced by wet weather events have been re-set and/or replaced.
 - Apron has been cleaned and properly maintained.

Activity: Slope Drains**SMP-13****Installation Procedures**

- Slope drains should be installed on well-compacted fill or undisturbed soil.
- Slope the lower section of pipe towards its outlet.
- Compact soil under and around the entrance section in lifts less than or equal to 6 inches.
- Ensure watertight connections.
- Compact all fill material.
- Secure the drain with stakes or grommets less than 10 feet apart.
- Protect the outlet from erosion using rip-rap or similar material.
- Extend conduit beyond the toe of the slope.
- Compact dike ridge no less than 1 foot above the top of the inlet pipe.
- Immediately stabilize all disturbed areas following construction.

Maintenance

- After stabilization remove temporary measures.
- Re-set or replace displaced stones after wet weather events.
- Remove sediment accumulation from slope drain inlet, channel, and outlet.

Inspection Checklist

- Stones that have been displaced by wet weather events have been re-set and/or replaced.
- Pipe connections are water tight.
- Inlet/outlet has been cleaned and properly maintained.
- Remove sediment accumulation from channel.
- Construction traffic removed from slope drain.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-01.1

Activity: Stream Corridors

**PLANNING
CONSIDERATIONS:**

Design Life:
Permanent

**Acreage
Needed:**
Width is defined
by local
ordinances

**Possible
Permits:**
KDW
Check local
ordinances



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ◇
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ◇	Oxygen Demanding Substances ◇	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ◇	Floatable Materials ♦	Construction Waste ♦	

Description

Sensitive areas such as stream corridors (waterways and riparian land) are subject to special protection due to their unique characteristics. These waterways provide habitat for fish, aquatic plants, and bottom dwelling organisms. Modifications to these inhabitants destroy physical features essential to a good habitat including: stable streambanks and bottom substrates, pools and riffles, meanders and spawning areas.

The vegetative habitat surrounding riparian land adjacent to stream banks filters pollutants from storms and floods and provides habitats for a variety of amphibians, aquatic birds and mammals. These creatures and their functions are impaired when development occurs within the corridor or riparian. Development causes more flooding to the area as well as meandering of natural streams.

To combat the developmental construction to the corridor or riparian, filter strips or forested buffers should be created or preserved along the banks of streams. Another method of preservation to corridors and riparian is the presence of vegetation along shorelines of ponds, lakes and wetlands. This aids in preventing erosion caused by wave action.

Benefits

- Improves the quality of water resources by removing or ameliorating the effects of pollutants in runoff.
- Streamside trees and bushy vegetation reduce erosion during flood events.
- Root system of trees control streambank erosion.
- Leaves from streambank trees lower water temperatures thereby improving fish habitat.
- Living and dead vegetation provide nutrients to support wildlife habitat.
- Improved fish and wildlife habitation provides recreational benefits to the community such as fishing, birding, canoeing and swimming where allowed.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-01.4

Activity: Karst Topography

**PLANNING
CONSIDERATIONS:**

Design Life:
Permanent

**Acreage
Needed:**
N/A

**Possible
Permits:**
KDOW
Check local
ordinances



Target Pollutants

Significant ♦

Partial ♦

Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

The effects of polluted stormwater runoff can be problematic to a karst system. The introduction of sediment or pollutant-laden runoff percolates into the karst system and rapidly increases can cause degradation of water quality.

Depending on the karst system rock type, some systems may be more susceptible to the development of conditions than others.

Some suggested practices are as follows:

Approach

1. Drain surface water away from karst features.
2. Provide treatment to surface water prior to its entry into karst features or walls.
3. Utilize minimal disturbance in location where karst features exist.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-02.1

Activity: Parking Lot Design

**PLANNING
CONSIDERATIONS:**

Design Life:
Permanent,
or life of
development

**Acreage
Needed:**
None

**Estimated
Unit Cost:**
Low

**Monthly
Maintenance:**
N/A



Target Pollutants

Significant ♦

Partial ♦

Low or Unknown ♦

Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦
Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦

Description

To reduce the amount of runoff volume in parking lot designs, infiltration swales and vegetation incorporation to reduce paved surfaces may occur. These two alternatives would provide water quality benefits to the parking lot design.

Reduced paved surfaces increases the amount of sediment-laden runoff that can be filtered through vegetation and settlement provided by swales. Vegetation acts as a sponge where runoff is concerned. Leaves, stems and branches intercept rainwater which then evaporates. Depending on the type of vegetation, some may even encourage infiltration (deep-rooted prairie plants).

While vegetation increases the amount of sediment-laden runoff captured and evaporated, swales enable sediment to settle out producing a cleaner runoff for the environment.

**Suitable
Applications**

- To compensate overly generous parking ration requirements.
- Lots desiring minimum stall dimensions.
- To use the most space-efficient stall configuration for a site.
- Reduce amount of surface sediment laden runoff.

Approach

- Pavement reduction can be established in five ways:
1. Variances to Municipal Codes.
 2. Reducing stall dimensions.
 3. Promoting shared parking lots.
 4. Reconfiguring parking stall patterns, orientations.
 5. Grass islands.

Activity: Parking Lot Design

SPD-02.1

**Approach
(cont'd)**

Site runoff can be reduced in two ways:

1. Consider green lots
2. Use of permeable pavers

Caution

Check zoning requirements prior to implementing BMP.

Maintenance

- Planted areas must be weeded monthly during the first two to three years. After initial years, once or twice a growing season will be sufficient.
- Water regularly during dry spells.
- Irrigation should be two inches per week maximum.
- Push street snow away from swales during winter seasons to avoid road sand accumulation.

**Inspection
Checklist**

- Plants are watered regularly during dry weather.
- Weeds are under control.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-02.2

**Activity: Street Design – Private Drives and
Roads**

**PLANNING
CONSIDERATIONS:**

Design Life:
Permanent

Acreage
Needed:
As required by
ordinances

Estimated
Unit Cost:
Low

Monthly
Maintenance:
N/A



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ◇
---------------	-----------	------------------

Sediment ♦	Heavy Metals ◇	Nutrients ◇	Oxygen Demanding Substances ◇	Toxic Materials ◇
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇	Construction Waste ◇	

Description

The design of a street will determine the effects of stormwater runoff. This gives a developer numerous opportunities to reduce impervious areas and aid in the reduction of runoff and management requirements associated with runoff. Natural drainage patterns should be preserved whenever possible during street design planning. This ensures that maximum stormwater filtration and infiltration can take place.

**Suitable
Applications**

- Siting of streets.
- Design width.
- Street drainage.

Approach

- *Siting of Streets*
Siting the street is an important consideration when planning the layout of a new street network or the siting of a road. To maximize stormwater filtration and infiltration, municipalities should aim to preserve natural drainage patterns whenever possible and avoid locating streets (and other impervious surfaces) in low areas or on highly permeable soils.
- *Design Width*
Streets should be designed with the minimum pavement width that will support the area's traffic volume; on street parking needs; and emergency, maintenance and service vehicles.
- *Street Drainage*
Curbless road design, such as the so-called "rural residential section" encourages infiltration via roadside swales. On low-traffic streets without curbs, grass shoulders can serve as an occasional parking lane, allowing a narrower paved area.

- | | |
|----------------------------------|--|
| Advantages | <ul style="list-style-type: none">➤ Thoughtful siting and design of streets improves stormwater control “at the source”, which means less runoff requiring management, reduced stormwater infrastructure, and a smaller impact on downstream water bodies.➤ Reducing paving lowers development and maintenance costs.➤ Forgoing curb-and-gutter in favor of a rural residential section is a cost savings.➤ Rural-section streets can incorporate attractive “rain garden” plantings in low areas adjacent to the roadway, when soil permits.➤ Narrower streets tend to slow traffic and create a more pedestrian-friendly environment.➤ Reducing pavement lessens the urban heat island effect - the increase in air temperature that occurs when highly developed areas are exposed to the sun. |
| Limitations | <ul style="list-style-type: none">➤ Local ordinances may preclude narrowed or curbless street design.➤ The city’s desire to design roads to accommodate future growth may impede innovations.➤ Roadside swales are difficult to accommodate in single family residential developments with net densities above 8 units per acre.➤ Good drainage for road subgrade must be provided when using roadside infiltration methods.➤ Soil and topography may limit street siting opportunities. |
| Construction Requirements | <ul style="list-style-type: none">➤ Take care not to compact adjacent, permeable soils during road construction.➤ Protect swales and other infiltrations areas from sediment influx during construction, or remove sediment after construction is complete. |
| Maintenance | <ul style="list-style-type: none">➤ Swales planted with perennials grasses and wildflowers rather than turf grass must be weeded at least monthly during the first two to three years. After that, weeding once or twice a growing season may suffice.➤ Swales will need periodic sediment removal to maintain volume and filtering ability. |



Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)

SPD-02.3

Activity: Cul-de-sac Design

PLANNING CONSIDERATIONS:

Design Life:
Permanent

Acreage Needed:
Minimal

Estimated Unit Cost:
Low

Monthly Maintenance:
N/A



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	

Description

Impervious areas can be significantly decreased with the cul-de-sac design in subdivisions. The smallest possible radius to this area ensures that stormwater runoff has less impact on downstream water bodies.

Other combating methods of runoff acceptance in a cul-de-sac stem from the application of flat apron curbs, islands to accept runoff from surrounding area and T-shaped turnarounds.



Suitable Applications

- Small subdivisions having 10 or fewer homes can benefit from the T-shaped turnaround.
- Highly developed areas desiring a solution to the urban heat island effect.

Advantages

- Cul-de-sac designs like those suggested here result in less management of stormwater runoff and reducing the impact on downstream water bodies.
- Planted cul-de-sac islands are attractive amenities.
- Less paving can lower development costs.
- Reducing pavement lessens the urban heat island effect-the increase in air temperature that can occur when highly developed areas are exposed to the sun.
- Reducing pavement can help reduce the increased runoff temperature commonly associated with impervious cover.

- | | |
|--------------------------------|---|
| Limitations | <ul style="list-style-type: none">➤ City ordinances may not accommodate small radii cul-de-sacs, due to accommodations for emergency vehicles.➤ Hammerhead turnarounds require vehicles to make a three-point-turn to exit.➤ Planted islands require more maintenance than paving during the first two to three years.➤ Difficulty in emergency vehicles ability to turn around. |
| Installation Procedures | <ul style="list-style-type: none">➤ Avoid compacting soil in center island, till soil to a 2 foot depth.➤ Select vegetation that thrives on high rainfall and drought. |
| Design Criteria | <ul style="list-style-type: none">➤ Widen rear pavements in cul-de-sacs to ensure easier turning, especially for emergency vehicles.➤ Islands should be maintained and vegetation planted for the appropriate soil type.➤ Include an unpaved, depressed island, using whatever radius will allow an appropriate road width. |
| Construction Criteria | <ul style="list-style-type: none">➤ During paving, care should be taken to avoid compacting soil in center island. Should compaction occur, it may be necessary to rip or till soils to a depth of 2 ft.➤ Choose plants that will thrive when rainfall is high, and survive droughts without watering. |
| Maintenance | <ul style="list-style-type: none">➤ Cul-de-sac island planting areas must be weeded monthly during the first two to three years. After that, weeding once or twice a growing season may suffice for maintenance. |

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Site Planning and Design Practices (SPDs)	SPD-02.4									
	Activity: Permeable Pavements										
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: Minimal Estimated Unit Cost: Low Annual Maintenance: N/A											
	<table border="1"> <thead> <tr> <th colspan="3" data-bbox="407 814 1427 856">Target Pollutants</th> </tr> <tr> <th data-bbox="407 856 810 905">Significant ♦</th> <th data-bbox="810 856 1135 905">Partial ♦</th> <th data-bbox="1135 856 1427 905">Low or Unknown ◇</th> </tr> </thead> <tbody> <tr> <td data-bbox="407 905 558 953">Sediment ◇ Oil & Grease ◇</td> <td data-bbox="558 905 729 953">Heavy Metals ◇ Bacteria & Viruses ◇</td> <td data-bbox="729 905 1427 953">Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Floatable Materials ◇ Construction Waste ◇</td> </tr> </tbody> </table>		Target Pollutants			Significant ♦	Partial ♦	Low or Unknown ◇	Sediment ◇ Oil & Grease ◇	Heavy Metals ◇ Bacteria & Viruses ◇	Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Floatable Materials ◇ Construction Waste ◇
Target Pollutants											
Significant ♦	Partial ♦	Low or Unknown ◇									
Sediment ◇ Oil & Grease ◇	Heavy Metals ◇ Bacteria & Viruses ◇	Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇ Floatable Materials ◇ Construction Waste ◇									
Description Suitable Applications Approach	<p>Infiltration and the reduction of runoff are a result of turf paving. The decrease arises from modular paving blocks or grids, cast-in-place concrete grids and soil enhancement technologies. Healthy grass growth as well as foot and vehicular traffic occur as a result of the site's increased load bearing capacity.</p> <ul style="list-style-type: none"> ➤ Areas desiring roadside right-of-ways ➤ Emergency access lanes. ➤ Delivery access routes. ➤ Overflow parking areas. <ul style="list-style-type: none"> ➤ Modular Paving Blocks and Grids Modular paving blocks or grass pavers consist of concrete or plastic interlocking units that provide structural stability while a series of gaps planted with turf grass allow for infiltration. Some blocks may also be filled with gravel and left unplanted. Depending on the use and soil type, a sand setting bed and gravel sub base is often added underneath to help further infiltration and prevent settling. ➤ Cast-in-Place Concrete Systems Monolithic concrete pavements incorporate gaps that are filled with topsoil and grass for a free-draining "pavement" with the structural capacity to handle most heavy vehicle loads. The surface is similar to that of modular concrete paving blocks. ➤ Soil Enhancements The soil-amendment technology employs synthetic mesh elements blended with a sandy growing medium, resulting in a natural turf surface and an engineered load-bearing root zone. Appropriate for summer overflow parking, golf courses, recreational fields and areas where the aesthetic appeal of uninterrupted grass is important. 										

**Approach
(cont'd)**

- **Porous Pavement**
Porous pavements may be used in lieu of conventional pavement on parking areas and areas with light traffic, provided that the grades, subsoils, drainage characteristics, and groundwater conditions are suitable. Slopes should be flat or very gentle. Soils should have field-verified permeability rates of greater than 0.5 inches per hour, and there should be a 4-foot minimum clearance from the bottom of the system to bedrock or the water table.

Advantages

- Turf pavers reduce or eliminate other stormwater management techniques by reducing runoff.
- Applied in combination with other BMPs, pollutant removal and stormwater management can be further improved.
- There may be a construction cost savings due to reduced curb-and-gutter requirements.
- Turf pavers are appropriate for driveways, walkways and overflow parking areas where handicapped access is not required or provided elsewhere.
- Turf helps soften the look of an area and make it more pleasant for pedestrians.
- Soil-enhanced turf systems are advantageous for sports and recreation fields as they resist compaction, thus increasing infiltration, and provide a soft playing surface.
- The mesh elements stabilize soil without reducing its permeability. The elements combat compaction, as they flex under pressure and "cultivate" the surrounding soils.
- Snow melts faster on a porous surface because of rapid drainage below the snow surface.
- Porous pavement can help to reduce the increased runoff temperature commonly associated with impervious cover.

Limitations

- For reasons of durability and maintenance, turf pavers are not recommended for high-traffic areas.
- Turf paving systems limit wheelchair access.
- Snow removal can be difficult, as plow blades can remove vegetation and catch the edge of the blocks, damaging the surface.
- Salt and sand in runoff from adjacent impervious pavement can damage turf and clog gaps in the blocks.
- Construction costs for turf paving may be higher than conventional pavements. Maintenance costs are generally higher.
- Clay soils will limit infiltration.
- Since turf paving encourages infiltration, it should not be applied on stormwater hotspots, places where land use or activities generate highly contaminated runoff, due to potential for groundwater contamination.

- Design Criteria**
- Infiltration rates are affected by soil types and should be considered when designing turf areas.
 - Soil type also affects the sub base depth.
 - Fill voids with sand or sandy loam planting base (adhere to manufacturer's recommendations).
 - Plant with "park grade" turf grasses which are more drought tolerant than "elite grade" grasses.

- Construction Requirements**
- **Modular and Cast-in-Place Concrete Systems**
Cells may be planted in one of three ways:
 1. Fill with a porous backfill mix (some products require sharp sand), scrape or back rake the entire surface to expose pattern. Broadcast seed or hydroseed and then top dress and fertilize as required.
 2. Fill and scrape or back rake as above, then lay 5/8-inch sod on the assembled pavers. Water the sod, then use a hand water roller or power-driven roller to compress the sod and root system completely into the cells.
 3. Do not fill the cells with any type of soil mixture. Lay 1-inch sod on the assembled pavers. Water the sod and compress as above.
 - **Soil Enhancements**
Sand or a proprietary growing medium is blended with a specific proportion of mesh elements using a mechanical shovel. A 20 kg sample of mixed material will contain 55.4-66.7 g of mesh elements (or approximately 44 lb. mesh for 5 cubic yards of sand mix). Manufacturer will supply precise proportions.

For some proprietary systems, materials are sourced locally and the patent-holder acts as project manager for the installation, using specially designed machines.



Grass cover is established using pre-germinated seed, washed turf or conventional seed.

Nonessential traffic should be kept off the area until grass is well-established.
 - **Porous Pavement**
Excavate and grade with light equipment with tracks or oversized tires to prevent soil compaction

As needed, divert storm water runoff away from planned pavement area before and during construction.

A typical porous pavement cross-section consists of the following layers:
 1. porous asphalt course, 2-4 inches
 2. filter aggregate course
 3. reservoir course of 1.5-3 inches
 4. filter fabric

- Inspection Checklist**
- Turf method matches soil type.
 - Turf is maintained to accommodate traffic patterns.

	<p>Madisonville, Kentucky</p> <p>Stormwater Best Management Practices (BMPs)</p> <p>Site Planning and Design Practices (SPDs)</p>	<p>SPD-02.5</p>		
	<p>Activity: Open-Space Preservation</p>			
<p>PLANNING CONSIDERATIONS:</p> <p>Design Life: Permanent</p> <p>Acreage Needed: Minimal</p> <p>Estimated Unit Cost: Low</p> <p>Annual Maintenance: N/A</p>				
	<p>Target Pollutants</p>			
	<p>Significant ♦</p>	<p>Partial ♦</p>	<p>Low or Unknown ♦</p>	
	<p>Sediment ♦</p> <p>Oil & Grease ♦</p>	<p>Heavy Metals ♦</p> <p>Bacteria & Viruses ♦</p>	<p>Nutrients ♦</p> <p>Floatable Materials ♦</p>	<p>Oxygen Demanding Substances ♦</p> <p>Construction Waste ♦</p>
<p>Description</p>	<p>An open-space preservation or conservation program involves a combination of methods merging long-range planning with an opportunistic action approach. Those methods include: outright purchase of land at full or "bargain-sale" prices; establishment of permanent Conservation Restrictions through gift or purchase; exercise of the local first refusal right; limited development purchases; and others.</p>			
<p>Suitable Applications</p>	<p>When prime open space in a community becomes available the opportunity to create blocks or greenbelts of local conservation land should be taken advantage of by the community.</p>			
<p>Planning Considerations</p>	<ul style="list-style-type: none"> ➤ Land preserved through acquisition, deed restriction, or other methods should be representative of each major land or habitat type within the town, and should be joined to form connecting corridors wherever possible. ➤ A multi-faceted local approach to the preservation of open space requires the support of the community, willingness to work with local or regional land trusts, the existence of a working open space plan, and the maintenance of a healthy conservation fund. 			



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-02.6

Activity: Construction Phasing

**PLANNING
CONSIDERATIONS:**

Design Life:
N/A

**Acres
Needed:**
None

**Estimated
Unit Cost:**
N/A

**Monthly
Maintenance:**
N/A

Construction Phasing																			
Task Name	Duration	Start	Finish	December 21							January 1								
				T	W	T	F	S	S	M	T	W	T	F	S	S	M	T	W
FM Feasibility Review	7 days	Mon 12/13/04	Tue 12/21/04																
Finalize Construction Dwg's	17 days	Mon 12/13/04	Tue 1/4/05																
Prepare Permit Submittals	23 days	Mon 12/13/04	Wed 1/12/05																
Permit and Enoachment Approvals	45 days	Thu 1/13/05	Wed 3/16/05																
Send Out Bid Package	1 day	Fri 1/7/05	Fri 1/7/05																
Pre-Bid Meeting	1 day	Fri 1/14/05	Fri 1/14/05																
Bid Due Date	1 day	Mon 1/31/05	Mon 1/31/05																
Contractor Selection	5 days	Tue 2/1/05	Mon 2/7/05																
Commissioner Approval	1 day	Mon 2/21/05	Mon 2/21/05																
Start Construction	1 day	Thu 3/17/05	Thu 3/17/05																

Target Pollutants				
Significant ♦	Partial ♦	Low or Unknown ◇		
Sediment ♦	Heavy Metals ◇	Nutrients ◇	Oxygen Demanding Substances ◇	Toxic Materials ◇
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇	Construction Waste ◇	

Description

A work schedule that coordinates the sequence of land-disturbing activities with the installation of erosion and sedimentation control practices.

A construction sequence schedule is a specified work schedule that coordinates the timing of land-disturbing activities and the installation of erosion protection and sedimentation-control measures.

Approach

- To reduce on-site erosion and off-site sedimentation from land-disturbing activities by installing EPSC practices in accordance with a planned schedule.
- Reduce on-site erosion and off-site sedimentation by performing land-disturbing activities and installing EPSC practices in accordance with a planned schedule.
- Preserving the natural vegetation on-site to the maximum extent practicable will minimize the impacts of development on stormwater runoff. Preferably 65% or more of the development site should be protected from the purposes of retaining or enhancing existing forest cover and preserving wetlands and stream corridors.

Activity: Construction Phasing

SPD-02.6

Suitable Applications

Purpose of the construction sequence schedule is to address the EPSC plan in an efficient and effective manner. Appropriate sequencing of construction activities can be a cost-effective way to help accomplish this goal. The plan can be open to changes that would be discussed at the erosion control project meetings.

The generalized construction activities shown in the following [Table SPD 02.6-01](#), do not usually occur in a specified linear sequence, and schedules will vary due to weather and other unpredictable factors. However, the proposed construction sequence should be indicated in the EPSC plan.

Maintenance

- Follow the construction sequence throughout project development.
- When changes in construction activities are needed, amend the sequence schedule in advance to maintain management control.
- Vegetation and trees should not be removed from the natural growth retention area, except for approved timber harvest activities and the removal of dangerous diseased trees.

**Table SPD-02.6-1
SEQUENCING TABLE**

	CONSTRUCTION ACTIVITY	SCHEDULE CONSIDERATION
1	Identify and label protection areas (e.g. buffer zones, filter strips, trees)	Site delineation should be completed before construction begins
2	Construction access. Construction entrance, construction routes, equipment parking areas and cutting of vegetation (necessary perimeter controls.	First land-disturbing activity. - Establish protected areas and designated resources for protection. Stabilize bare areas immediately with gravel and temporary vegetation as construction takes place.
3	Sediment traps and barriers. Basin traps, sediment fences, and outlet protection	Install principal basins after construction site is accessed. Install additional traps and barriers as needed during grading
4	Runoff control. Diversions, silt fence, perimeter dikes, and outlet protection.	Install key practices after principal sediment traps and before land grading. Install additional runoff control measures during grading.
5	Runoff conveyance system. Stabilize stream banks, storm drains, channels, inlet and outlet protection, and slope drains.	Where necessary, stabilize stream banks as early as possible. Install principal runoff conveyance system with runoff-control measures. Install remainder of system after grading.
6	Grubbing and grading. Site preparation: cutting, filling and grading, sediment traps, barriers, diversions, drains, surface roughening.	Begin major grubbing and grading after principal sediment and key runoff control measures are installed. Clear borrow and disposal areas only as needed. Install additional control measures as grading progresses.
7	Surface stabilization: temporary and permanent seeding, mulching, sodding, and installing riprap.	Apply temporary or permanent stabilization measures immediately on all disturbed areas where work is delayed or complete.
8	Building construction: buildings, utilities, paving	Install necessary erosion and sedimentation control practices as work takes place.
9	Landscaping and final stabilization: topsoiling, planting trees and shrubs, permanent seeding, mulching, sodding, installing riprap.	Last construction phase - Stabilize all open areas including borrow and spoil areas. Remove and stabilize all temporary control measures.
10	Maintenance	Maintenance inspections should be performed weekly, and maintenance repairs should be made immediately after periods of rainfall.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-03.1

Activity: Vegetative Buffers

**PLANNING
CONSIDERATIONS:**

Design Life:
1 yr

**Acreage
Needed:**
Minimal

**Estimated
Unit Cost:**
Low

**Monthly
Maintenance:**
60% of
Installation



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ◇
---------------	-----------	------------------

Sediment ♦	Heavy Metals ◇	Nutrients ◇	Oxygen Demanding Substances ◇	Toxic Materials ◇
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇	Construction Waste ◇	

Description

Vegetative buffers consists of an undisturbed vegetation barrier that has been enhanced or restored surrounding an area of disturbance or bordering streams, ponds, wetlands and lakes. This planning BMP filters runoff, reduces storm runoff velocities, protects channel banks, provides flood protection and a number of other enhancing traits.

**Suitable
Applications**

- Areas desiring enhancement to wildlife inhabitant.
- Areas needing temperature regulation and replenishment of wildlife victuals.

**Installation
Procedures**



- Planting can consists of bare root seeding.
- Container grown seeding, grown plants and balled and burlapped plants.
- Soil preparation and maintenance are essential for the establishment of planted vegetation.
- Standard permanent erosion control grasses and legumes may be used in denuded areas for quick stabilization.

Maintenance

- Areas closest to the stream should be maintained with minimum impact.
- Watering required during periods of drought as well as during the initial year; watering may be necessary in all buffer areas planted or seeded for enhancement.
- It is imperative that the structure of the vegetated stream buffer be maintained.
- If the buffer has been planted, it is suggested that the area be monitored to determine if plant material must be replaced. Provisions for the protection of new plantings from destruction or damage from beavers or other damaging pests should be incorporated into the plan.

Design Criteria

- Buffer width should be selected to permit the zone to perform its intended purpose.
- Slope, hydrology, width and structure shall be considered.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Site Planning and Design Practices (SPDs)	SPD-03.2																		
PLANNING CONSIDERATIONS: Design Life: 1 yr Acreage Needed: Minimal Estimated Unit Cost: Low Monthly Maintenance: 60% of Installation																				
	<table border="1"> <thead> <tr> <th colspan="3" data-bbox="404 810 1430 856">Target Pollutants</th> </tr> <tr> <th data-bbox="404 856 803 905">Significant ◆</th> <th data-bbox="803 856 1117 905">Partial ◆</th> <th data-bbox="1117 856 1430 905">Low or Unknown ◇</th> </tr> </thead> <tbody> <tr> <td data-bbox="404 905 560 953">Sediment ◆</td> <td data-bbox="560 905 727 953">Heavy Metals ◇</td> <td data-bbox="727 905 894 953">Nutrients ◇</td> </tr> <tr> <td data-bbox="404 953 560 1001">Oil & Grease ◇</td> <td data-bbox="560 953 803 1001">Bacteria & Viruses ◇</td> <td data-bbox="803 953 1062 1001">Floatable Materials ◇</td> </tr> <tr> <td></td> <td data-bbox="1062 905 1229 953">Oxygen Demanding Substances ◇</td> <td data-bbox="1229 905 1430 953">Toxic Materials ◇</td> </tr> <tr> <td></td> <td></td> <td data-bbox="1062 953 1430 1001">Construction Waste ◇</td> </tr> </tbody> </table>		Target Pollutants			Significant ◆	Partial ◆	Low or Unknown ◇	Sediment ◆	Heavy Metals ◇	Nutrients ◇	Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇		Oxygen Demanding Substances ◇	Toxic Materials ◇			Construction Waste ◇
Target Pollutants																				
Significant ◆	Partial ◆	Low or Unknown ◇																		
Sediment ◆	Heavy Metals ◇	Nutrients ◇																		
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇																		
	Oxygen Demanding Substances ◇	Toxic Materials ◇																		
		Construction Waste ◇																		
Description Suitable Applications Maintenance	<p>For seasonal protection and areas with fast growing species the establishment of temporary seeding is desired to reduce storm water runoff velocity, maintain sheet flow, protect the soil surface from erosion, to promote infiltration of runoff into the soil, improve wildlife habitat, aesthetics and soil condition for permanent planting.</p> <ul style="list-style-type: none"> ➤ Coordinate with permanent measures (See EPP-06) to assure economical and effective stabilization. ➤ Used as companion crops until permanent seeding is established. <ul style="list-style-type: none"> ➤ Inspection of area made before anticipated rain events and within 24 hours after the end of a storm event of 0.5 inches or greater. ➤ Maintenance should be corrected prior to the next known storm event or within 7 days after identification of the previous significant wet weather event. 																			



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-03.3

Activity: Disturbed Area Stabilization (Permanent Seeding)

**PLANNING
CONSIDERATIONS:**

Design Life:
1 yr

Acreage
Needed:
Minimal

Estimated
Unit Cost:
Low

Monthly
Maintenance:
60% of
Installation



Target Pollutants

Significant ♦

Partial ♦

Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Final stabilization occurs when perennial vegetation is introduced to construction areas. This stabilization occurs as a result of planting trees, shrubs, vines, grasses or legumes on exposed areas. The result of this aesthetic overture reduces stormwater runoff velocity, maintains sheet flow, protects soil surface from erosion, promotes infiltration of runoff into the soil and improves wildlife habitat. Permanent stabilization also acts as a protective cover for cuts, fills, and other denuded areas that will not be regarded.

**Suitable
Applications**

- Areas where topsoil was never stripped.
- Topsoil has been returned and incorporated into the soil surface.
- See [EPP-06](#), Permanent Seeding for more information.

Activity: Disturbed Area Stabilization (Permanent Seeding)

SPD-03.3

Installation Procedures

- Grade and shape slope unless hydraulic seeding has taken place.
- Divert erosion causing concentrations of water to safe outlets.
- Plants should be selected based on characteristics specific to soil conditions, site, planned and maintenance of the area, method of planting, etc.
- Topsoil should be friable and loamy, free of debris with a uniform application of 5 inches recommended.
- Seedbed preparations: When conventional seeding is to be used, topsoil should be applied where the disturbance results in subsoil being the final grade surface.

Broadcast Planting

1. Seedbed preparation may not be required where hydraulic seeding equipment is to be used.
2. Tillage, at a minimum, shall adequately loosen the soil to a depth of 4 to 6 in.; alleviate compaction; incorporate topsoil, lime, and fertilizer; smooth and firm the soil; allow for the proper placement of seed, sprigs, or plants; and allow for the anchoring of plants; and allow for the anchoring of straw or hay mulch if a crimper is to be used.
3. Tillage may be done with any suitable equipment
4. Tillage should be done parallel to the contour where feasible
5. On slopes too steep for the safe operation of tillage equipment, the soil surface shall be pitted or trenched across the slope with appropriate hand tools to provide consecutive beds, 6 to 8 in. apart, in which seed may lodge and germinate. Hydraulic seeding may also be used.

Individual Plants

1. Where individual plants are to be set, the soil shall be prepared by excavating holes, opening furrows, or dibble planting.
2. For nursery stock plants, holes shall be large enough to accommodate roots without crowding.
3. Where pine seedlings are to be planted, use a subsoiler under the row to a depth of 36 in. on the contour four to six months prior to planting. Subsoiling should be done when the soil is dry, preferably in August or September.
4. Trees should not be planted in power line right-a-ways or under power lines.

Inoculants

1. All legume seeds shall be inoculated with appropriate nitrogen fixing bacteria. The inoculants shall be pure culture prepared specifically for the seed species and used within the dates on the container.
2. A mixing medium recommended by the manufacturer shall be used to bind the inoculants to the seed. For conventional seeding, twice the amount of inoculants recommended by the manufacturer. For hydraulic seeding, four times the amount of inoculant recommended by the manufacturer shall be used.
3. All inoculant seed shall be protected from the sun and high temperatures and shall be planted the same day inoculated. No inoculated seed shall remain in the hydroseeder longer than one hour.

Activity: Disturbed Area Stabilization (Permanent Seeding)

SPD-03.3

Installation Procedures (cont'd)

Planting

1. Hydraulic Seeding: Mix the seed (inoculant if needed), fertilizer, and wood cellulose or wood pulp fiber mulch with water and apply in a slurry uniformly over the area to be treated. Apply within one hour after the mixture is made.
2. Conventional Seeding: Seeding will be done on a freshly prepared seedbed. For broadcast planting, use a cultipacker seeder, drill, rotary seeder, other mechanical seeder, or hand seeding to distribute the seed uniformly over the area to be treated. Cover the seed lightly with $\frac{1}{8}$ to $\frac{1}{4}$ in. of soil for small seed and $\frac{1}{2}$ to 1 in. for large seed when using a cultipacker or other suitable equipment.
3. No-Till Seeding: No-till seeding is permissible into annual cover crops when planting is done following maturity of the cover crop or if the temporary cover stand is sparse enough to allow adequate growth of the permanent (perennial) species. No-till seeding shall be done with appropriate no-till seeding equipment. The seed must be uniformly distributed and planted at the proper depth.
4. Individual Planting: Shrubs, vines and sprigs may be planted with appropriate planters or hand tools. Pine trees shall be planted manually in the subsoil furrow. Each plant shall be sent in a manner that will avoid crowding the root.

Nursery stock plants shall be planted at the same depth or slightly deeper than they grew at the nursery. The tips of the vines and sprigs must be at slightly above the ground surface.

Where individual holes are dug, an appropriate amount of fertilizer shall be placed in the bottom of the hole, two in. of soil shall be added, and the plant shall be set in the hole and the hole filled.

Applying Mulching

Mulch is required for all permanent vegetation applications. Mulch applied to seeded areas shall achieve 75% soil cover. Select the mulching material from the following and apply as indicated.

1. When using temporary erosion control blankets or block sod, mulch is not required.
2. Dry straw or dry hay of good quality and free of weed seeds can be used. Dry straw shall be applied at the rate of 2 tons per acre. Dry hay shall be applied at a rate of 2 $\frac{1}{2}$ tons per acre. *Sericea lespedeza* hay containing mature seed shall be applied at a rate of three tins per acre.
3. Straw or hay mulch will be spread uniformly within 24 hours after seeding and/or planting. The mulch may be spread by blower type spreading equipment, other spreading equipment, or by hand.
4. Wood cellulose mulch or wood pulp fiber shall be used with hydraulic seeding. It shall be applied at the rate of 500 pounds per acre. Dry straw or dry hay shall be applied (at the rate indicated above) after hydraulic seeding.
5. One thousand pounds per acre of wood pulp fiber, which includes a tackifier, shall be used with hydraulic seeding on slopes $\frac{3}{4}$:1 or steeper.
6. Wood cellulose and wood pulp fibers shall not contain germination or growth inhibiting factors. They shall be evenly dispersed when agitated in water. The fibers shall contain a dye to aid in uniform application during seeding.

Activity: Disturbed Area Stabilization (Permanent Seeding)

SPD-03.3

Installation Procedures (cont'd)

Anchoring Mulch

1. Emulsified asphalt can be (a) sprayed uniformly onto the mulch as it is ejected from the blower machine or (b) sprayed on the mulch immediately following mulch application when straw or hay is spread by methods other than special blower equipment. The combination of asphalt emulsion and water shall consist of a homogeneous mixture satisfactory for spraying. The mixture shall consist of 100 gallons of water per ton of mulch. Care shall be taken at all times to protect state waters, the public, adjacent property, pavements, curbs, sidewalks, and all other structures from asphalt discoloration.
2. Hay and straw mulch may be pressed into the soil immediately after the mulch is spread. A special "crimper" or disk harrow with the disks set straight may be used. Serrated disks are preferred, and should be 20 in. or more in diameter and 8 to 12 in. apart. The edges of the disks shall be dull enough to press the mulch into the ground without cutting it, leaving much of it in an erect position. Mulch shall not be plowed into the soil.
3. Synthetic tackifiers or binders may be applied in conjunction with or immediately after the mulch is spread. Synthetic tackifiers should be mixed and applied according to manufacturer's specifications.

Irrigation

Irrigation will be applied at a rate that will not cause runoff.

Maintenance

- Inspect seeding and mulch regularly.
- Any washout areas should be repaired immediately.
- Maintenance needs that have been identified should be repaired before the next storm event or within seven days of identification.

Inspection Checklist

- Inspect all applications and make appropriate repairs.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-03.4

Activity: Disturbed Area Stabilization (Mulch)

**PLANNING
CONSIDERATIONS:**

Design Life:
1 yr

Acreage
Needed:
Minimal

Estimated
Unit Cost:
Low

Monthly
Maintenance:
N/A



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Mulch is used to promote vegetation during vegetative stabilization practices to reduce stormwater runoff and erosion, conserve moisture, promote germination of seed, prevent surface compaction or crusting, protect seed from birds, modify soil temperature and increase biological activities in the soil.

**Suitable
Applications**

- Cleared areas where seed may not promote an erosion-retardant cover.
- Protection of seed from birds.
- Reduction of soil surface temperature is desired.

Design Criteria

- Select mulching material depending on desired soil coverage.
- Anchor mulch immediately after application.
- Refer to [EPP-10](#) Mulching for more information regarding design and installation of this BMP.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-03.5

**Activity: Disturbed Area Stabilization
(Sodding)**

**PLANNING
CONSIDERATIONS:**

Design Life:
Permanent

**Acreage
Needed:**
As required

**Estimated
Unit Cost:**
Low

**Monthly
Maintenance:**
30% of
Installation



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Areas needing immediate vegetative cover such as grass swales, drop inlets, and waterways with intermittent flow use sod brought from other locations. This BMP is referred to as Disturbed Area Stabilization. The stabilization establishes immediate ground cover, reduces stormwater runoff, protects soil surface from erosion, reduces damage from sediment and runoff to downstream areas as well as improves aesthetics.

Design Criteria

- Sod selected material should be certified.
- Sod grown in the area is preferred.
- Sod should be machine cut and contain ¾" (+ or - ¼ inch) of soil.
- Cuts should be installed within 36 hours of digging.
- Avoid planting when subject to frost heave or hot weather if irrigating is not available.
- Refer to [EPP-07 Sodding](#), for more information on its applications, installation, and maintenance.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Site Planning and Design Practices (SPDs)**

SPD-03.6

Activity: Erosion Control Mats/Blankets

**PLANNING
CONSIDERATIONS:**

Design Life:
1-2 years

**Acreage
Needed:**
Varies

**Estimated
Unit Cost:**
Medium

**Monthly
Maintenance:**
N/A



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	

Description

In areas where erosion hazards are high, matting and blankets can be applied. This protective blanket or stabilization mat aids in establishing temporary or permanent vegetation on steep slopes, channels or stream banks. The presence of this BMP prevents erosion of the soil surface or seed, promotes seed germination, protects young vegetation and prevents the dispersion of seed or mulch.

**Suitable
Applications**

- All concentrated flow areas with slopes steeper than 2.5:1, with a height of 10 ft. or greater and cuts and fills within stream buffers.
- Temporary blankets should be (at a minimum) used to stabilize concentrated flow areas.
- Vegetative lining is desired in stormwater conveyance channels where velocity is projected to be between 5 and 10 ft. per second.

Design Criteria

- Care must be taken to choose the type of blanket or matting appropriate for each project.
- Rolled erosion control blankets are made of plastic netting intertwined with natural organic or manmade mulch.
- Jute mesh is a typical homogeneous design that can act alone as a stabilization blanket.

Activity: Erosion Control Mats/Blankets



SPD-03.6

- Approach**
- **Straw Blanket** consist of weed free straw with a $\frac{5}{16} \times \frac{5}{16}$ top side and a minimum thickness of $\frac{3}{8}$ in. and minimum dry weight of 0.5 lbs per square yard.
 - **Excelsior blankets** are curled wood excelsior formed into a blanket with $1 \frac{1}{2} \times 3$ in. mesh sides and a minimum thickness of $\frac{1}{4}$ in. with a 0.8 dry weight lbs per square yard.
 - **Coconut blankets** consist of 100% coconut fiber with a $\frac{1}{4}$ thickness, a minimum dry weight of 0.5 lbs per square yard and a $\frac{5}{8} \times \frac{5}{8}$ in. maximum mesh .
 - **Wood fiber blankets** consist of reprocessed wood fiber with a maximum mesh size of $\frac{5}{8} \times \frac{3}{4}$ in. and a 0.35 lbs per square yard minimum dry weight.
 - **Jute mesh** consist of woven root fiber or yarn with regularly spaced openings between strands and a 1.0 lbs per square yard dry weight for basic slope applications.

- Installation Procedures**
- Shape and grade site.
 - Prepare a friable seedbed free from clods and rocks.
 - Temporary blankets should be installed vertically from the top of the slope to bottom.
 - For shallower slopes (less than 2:1) with height twice as much as the width, and a maximum height of 16 feet, the blanket may be applied horizontally. Concentrated flow area blankets should be placed in the direction of water flow.
 - Entrench blanket beyond the top and bottom of the slope and at any horizontal joint a minimum of 6 in.
 - Permanent matting begins installation at the bottom of the slope and works towards the top while being centered in the middle of the channel.
 - Shingle upstream layer over downstream layer overlapping 3 ft.
 - Temporary blankets should be anchored with staples per manufacturing directions.
 - Manufacturer's recommendations should be followed when choosing products.
 - All preliminary seeding and soil amendments should be done prior to installation of temporary blankets.
 - Permanent matting areas should be brought to final grade before installation of matting. After installation and backfilling of topsoil, seeding and mulch should be applied.

- Maintenance**
- Inspect erosion control matting before (if anticipated) and within 24 hours following rainfall events to check for movement of topsoil, mulch or erosion. Continue checking until vegetation is firmly established.
 - Inspect blankets or mats at least every 14 days.
 - Repair or replace netting that has been washed out, broken, eroded, and/or needing surface repair, re-seeding, re-sodding, re-mulching or topsoil replacement.

- Inspection Checklist**
- Inspection completed before a storm event.
 - Inspection completed within 24 hours after the end of a storm event of 0.5 inches or greater.
 - Erosion control mats are properly tucked.
 - Damaged areas have been repaired.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Site Planning and Design Practices (SPDs)	SPD-04.1																				
PLANNING CONSIDERATIONS: Design Life: Permanent Acreage Needed: N/A Estimated Unit Cost: High Monthly Maintenance: N/A	Activity: Covenants  <table border="1" data-bbox="409 814 1425 1001"> <thead> <tr> <th colspan="3" data-bbox="409 814 1425 856">Target Pollutants</th> </tr> <tr> <th data-bbox="409 856 808 905">Significant ♦</th> <th data-bbox="808 856 1094 905">Partial ♦</th> <th data-bbox="1094 856 1425 905">Low or Unknown ◇</th> </tr> </thead> <tbody> <tr> <td data-bbox="409 905 561 953">Sediment ♦</td> <td data-bbox="561 905 721 953">Heavy Metals ◇</td> <td data-bbox="721 905 880 953">Nutrients ◇</td> </tr> <tr> <td data-bbox="409 953 561 1001">Oil & Grease ◇</td> <td data-bbox="561 953 808 1001">Bacteria & Viruses ◇</td> <td data-bbox="808 953 1062 1001">Floatable Materials ◇</td> </tr> <tr> <td colspan="2"></td> <td data-bbox="1062 905 1425 953">Oxygen Demanding Substances ◇</td> </tr> <tr> <td colspan="2"></td> <td data-bbox="1062 953 1425 1001">Toxic Materials ◇</td> </tr> <tr> <td colspan="2"></td> <td data-bbox="1062 1001 1425 1045">Construction Waste ◇</td> </tr> </tbody> </table>		Target Pollutants			Significant ♦	Partial ♦	Low or Unknown ◇	Sediment ♦	Heavy Metals ◇	Nutrients ◇	Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇			Oxygen Demanding Substances ◇			Toxic Materials ◇		
Target Pollutants																						
Significant ♦	Partial ♦	Low or Unknown ◇																				
Sediment ♦	Heavy Metals ◇	Nutrients ◇																				
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ◇																				
		Oxygen Demanding Substances ◇																				
		Toxic Materials ◇																				
		Construction Waste ◇																				
Description	<p>Conservation covenants are voluntary, legally binding agreements between a landowner and the State or Local Government which are designed to provide permanent protection for areas or species that have conservation value. The covenant is registered on the title of the land and travels with the title to future landowners. Once a covenant is in place it can only be modified or revoked with the agreement of the landowner and the relevant state or local agency.</p> <p>A management agreement is usually provided with a covenant and will detail how the conservation values are to be managed. Some activities such as grazing and firewood collection may be allowed within a conservation covenant. For those activities that are allowed, the details of how they will be undertaken are outlined in detail within the management plan. Both documents are drafted in consultation with the landowner.</p> <p>The aim of conservation covenants is to ensure that land use is compatible with the natural values of that area. A conservation covenant will apply to all or most of the native vegetation on a property. However, a landowner may also choose to exclude parts of their property from the covenant for example to allow for building a house in the future.</p> <p>Participation in a conservation covenant is entirely voluntary and the details of the covenant and management agreement are agreed only with the cooperation and consent of the landowner.</p>																					



**Description
(cont'd)****Management Agreements**

Management agreements are agreements between a landowner and the State Government that are not registered on the land title. Management agreements set out required management practices to protect the nature conservation values.

Benefits of Covenanting Land

There are many benefits gained by having a conservation covenant on your land, they include:

- Rate rebates in some areas or districts.
- Exemption from land tax.
- Having a conservation covenant helps if you are applying for grants for environmental work.
- By maintaining remnant native vegetation you benefit from erosion and salinity protection; and you provide shade and shelter for livestock; and protect wetlands, catchments and water quality.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Site Planning and Design Practices (SPDs)	SPD-04.2									
	Activity: Setbacks and Buffers										
PLANNING CONSIDERATIONS: Design Life: Permanent Acreege Needed: Varies Estimated Unit Cost: High Monthly Maintenance: N/A											
	<table border="1"> <thead> <tr> <th colspan="3" data-bbox="397 810 1421 856">Target Pollutants</th> </tr> <tr> <th data-bbox="397 856 803 903">Significant ♦</th> <th data-bbox="803 856 1128 903">Partial ♦</th> <th data-bbox="1128 856 1421 903">Low or Unknown ♦</th> </tr> </thead> <tbody> <tr> <td data-bbox="397 903 544 1001">Sediment ♦ Oil & Grease ♦</td> <td data-bbox="544 903 803 1001">Heavy Metals ♦ Bacteria & Viruses ♦</td> <td data-bbox="803 903 1421 1001">Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ Floatable Materials ♦ Construction Waste ♦</td> </tr> </tbody> </table>		Target Pollutants			Significant ♦	Partial ♦	Low or Unknown ♦	Sediment ♦ Oil & Grease ♦	Heavy Metals ♦ Bacteria & Viruses ♦	Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ Floatable Materials ♦ Construction Waste ♦
Target Pollutants											
Significant ♦	Partial ♦	Low or Unknown ♦									
Sediment ♦ Oil & Grease ♦	Heavy Metals ♦ Bacteria & Viruses ♦	Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ Floatable Materials ♦ Construction Waste ♦									
Description	<p>A <i>setback</i> is the area between intensive development (i.e., buildings, parking lots, roads) and a protected area, such as a wetland. Setbacks are necessary for:</p> <ul style="list-style-type: none"> • Controlling the peripheral effects of development • Protecting developments • Providing access for maintenance <p>For example, a highway or parking lot built directly on the edge of a high-quality wetland may adversely affect water quality and wildlife habitat from pollutant runoff or spray and traffic noise. Setback requirements for structures, particularly adjacent to streams, reflect the fact that streams naturally meander or expand over time. Placing structures in the natural path of a meandering stream virtually guarantees that expensive stabilization measures will be needed in the future as the stream approaches building foundations, threatening their collapse.</p> <p>Only limited activities are recommended for approval in a setback. The types of activities include minor improvements, such as walkways, foot bridges, and observation decks; roadways necessary for crossing a water body; maintenance and repair of existing roads and utilities; and the establishment of landscaped lawns or parks. In general, major modifications to the land surface should be avoided in setbacks.</p>										

**Description
(cont'd)**

Limiting activities in a *floodway* to appropriate uses is similar to a setback requirement. A floodway is the part of the floodplain, centered on the stream, which will convey most of the flow during a high water event. Appropriate uses exclude most buildings and structures. However, other uses that are allowed may adversely affect water quality and habitat. These include:

- Parking lots
- Roadways parallel to the waterbody
- Garages and storage sheds
- Treatment plants and pumping facilities

Within a setback, a *buffer strip* is the transitional vegetated area closest to the waterbody or wetland. The purposes of a buffer are to:

- Minimize erosion
- Stabilize the stream bank or lakeshore
- Filter runoff pollutants from adjacent developments
- Preserve fish and wildlife habitat
- Screen manmade structures and preserve aesthetic values
- Provide access for maintenance or trails

Buffers reflect that natural aquatic systems may not function well in isolation and that a gradual continuum exists from natural riparian or wetland systems to upland. Ideally, a buffer should be maintained or planted in native riparian vegetation to maximize pollutant filtering, soil stabilization, and habitat functions.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-01

Activity: Dewatering Operations (DW)


PLANNING CONSIDERATIONS:

Design Life:
1-2 years

Acreage Needed:
Minimal

Estimated Unit Cost:
Medium

Monthly Maintenance:
Moderate



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Testing of groundwater for pollution accumulation by using sediment controls is the basis of this BMP. This dewatering operation will reduce or prevent discharge of pollutants and aid in a partial reduction in toxic materials.

Approach

Sediment and toxic and petroleum products are two general classes of pollutants that may result from dewatering operations. Toxics and petroleum are rarely found in dewatering discharges unless the site or the surrounding vicinity has been used for light or heavy industrial activities. Sediment, on the other hand, usually has a high content in dewatering discharges due to the commonality of the operation. **This BMP only addresses capture of sediment.** If it is determined that dewatering will result in transfer or accumulation of toxics or petroleum products then the Kentucky Division of Water (KDOW) should be consulted before any dewater activities are performed.

Methods for Mitigating sediment discharge

- Use of sock filters or sediment filter bags on discharge pipes.
- Discharge muddy water into silt fence enclosures installed in vegetated areas away from water ways.
- Discharge muddy water to a de-silting basin.

Afterwards sediment can be removed once water has dispersed and stabilized. Seeding the area is also suggested.

Maintenance and Inspection Checklist

- Inspect filtering device frequently and repair or replace once the sediment build-up prevents the structure from functioning as designed.
- Sediment removal must be disposed of at a disposal site or spread and stabilized onsite.
- Inspect excavated areas daily for signs of contaminated water (signs such as discolored water, oily sheen or odor).



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-02

Activity: Paving Operations (PO)

**PLANNING
CONSIDERATIONS:**

Training:
None

**Inspection
Frequency:**
Daily

**Implementation
Cost:**
Low

**Monthly
Maintenance:**
Low



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	

Description

Paving operations have the potential to introduce a large amount of pollutants to into the environment. This BMP will reduce or prevent the discharge of pollutants by using measures to prevent run-on and runoff pollution along with proper disposal of waste, and proper training of employees and subcontractors.

Approach

- Do not pave during wet weather.
- Store paving materials away from water courses to prevent stormwater run-off.
- Protect water courses, particularly in areas with a grade, by implementing BMPs to divert runoff or trap/filter sediment (see [SMP-05](#), [-06](#), [-10](#), [-12](#)).
- Leaks and spills can contain toxic levels of heavy metals and oil and grease generated from paving equipment. To alleviate these pollutants into the area, place drip pans or absorbent materials under paving equipment when they are not being used. When spills do occur, clean up spills with absorbent materials (see [GHP-05](#)).
- Cover catch basins and manholes when applying seal coat, tack coat, slurry seal or fog seal.
- Most commercial covers will magnetically seal flat catch basins and inlets.
- If paving involves Portland cement concrete, see [GHP-09](#), Concrete Waste Management
- If paving involves asphalt concrete do the following:
 1. Keep sand or gravel placed over new asphalt from being washed into storm drains, streets or creeks by sweeping. Refer to [GHP-06](#), Solid Waste management for proper disposal.
 2. Old asphalt must be disposed of properly. Collect and remove all broken asphalt from the site and recycle.
 3. If paving involves on-site mixing plant, follow the stormwater permitting requirements for Industrial activities.

Activity: Paving Operations**GHP-02**

- Maintenance**
- Maintain inlet protection so that water is not allowed to back up onto areas subject to traffic. Alternative measures should be employed if back up occurs.
 - When sediment reaches storage capacity inlets need to be cleaned and repair as needed.
 - Keep ample supplies of drip pans or absorbent materials on-site.

- Inspection Checklist**
- Machinery is not leaking and properly maintained.
 - Inspect employees and subcontractors to ensure that measures are being followed.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-03

**Activity: Structure Construction and Painting
(SCP)**

**PLANNING
CONSIDERATIONS:**

Training:
None

**Inspection
Frequency:**
Daily

**Implementation
Cost:**
Low

**Monthly
Maintenance:**
Low



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ♦ Construction Waste ◇

Description

A number of preventive measures around the construction site greatly decrease the amount of pollution entering the environment. Enclosing, covering or berming building material storage areas, using good housekeeping practices, utilizing safer products and training employees and subcontractors will make a significant difference in the amount of pollutants entering stormwater runoff. This will cause a significant reduction in floatable materials, other construction waste and a partial reduction of toxic materials.

Approach

- Keep the work site clean and orderly. Remove debris in a timely fashion. Sweep the area regularly.
- Use soil erosion control techniques if bare ground is exposed. See Erosion Prevention Practices ([EPP](#)).
- Buy recycled or less hazardous products to the maximum extent practicable.
- Conduct painting operations consistent with local air quality and Occupational Safety and Health Administration (OSHA) regulations.
- Properly store paints and solvents. See [GHP-04: Material Delivery, Storage and Use](#) in this section.
- Properly store and dispose waste materials generated from the activity. See the waste management BMPs [GHP-06,-07, -08,-09](#) and [-10](#) in this section.
- Recycle residual paints, solvents, lumber, and other materials to the maximum extent practicable.
- Make sure that nearby storm drains are well marked to minimize the chance of inadvertent disposal of residual paints and other liquids.

Activity: Structure Construction and Painting

GHP-03

**Approach
(cont'd)**

- Clean the storm drain system in the immediate construction area after construction is completed.
- Educate and remind employees who are doing the work of the importance of keeping pollutants out of the stormwater system.
- Inform subcontractors of company policy on these matters and include appropriate provisions in their contract to make certain proper housekeeping and disposal practices are implemented.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the [GHP 14-1](#), Employee/Subcontractor Training BMP fact sheet.
- For oil-based paints, paint out brushes to the extent practical, and filter and reuse thinners and solvents.
- Never clean paintbrushes or rinse paint containers into a street, gutter, storm drain or watercourse.
- Dispose of any paint, thinners, residue, and sludges that cannot be recycled as hazardous waste. For a quick reference on disposal alternatives for paint, thinners, residue and sludges see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
- Latex paint and paint cans, used brushes, rags, absorbent materials, and drop cloths, when thoroughly dry and are no longer hazardous, may be disposed of with other construction debris.
- Use recycled and less hazardous products when practical.
- Recycle residual paints, solvents, lumber, and other materials.

Maintenance

- Minimum maintenance required.
- Spot check employees and subcontractors monthly to assure appropriate practices are being employed.

Inspection

- Unused materials are properly contained, sealed and stored.
- Containment measures are being used to keep materials from entering watercourses.
- Used or discarded materials are properly disposed.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-04

Activity: Material Delivery, Storage and Use (MS)

PLANNING CONSIDERATIONS:

Training:
None

Inspection Frequency:
Weekly

Implementation Cost:
Low

Monthly Maintenance:
Low



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	

Description

A properly maintained and organized construction site can partially reduce the amount of contaminated sediment, nutrients, toxic materials, oil and grease and floatables from leaving the vicinity. By limiting the amount of onsite hazardous materials, storing materials in designated areas, installing secondary containment, conducting regular inspections and training employees and subcontractors, pollution can be prevented or reduced.

Approach

The following materials are commonly stored on construction sites:

- Soil
- Concrete compounds
- Pesticides and herbicides
- Fertilizers
- Detergents
- Plaster or other products
- Petroleum products such as fuel, oil, and grease
- Other hazardous chemicals such as acids, lime, glues, paints, solvents, and curing compounds.

Activity: Material Delivery, Storage and Use

GHP-04

**Approach
(cont'd)**

Storage of these materials on-site can pose various degrees of the following risks:

- Stormwater pollution,
- Injury to workers or visitors,
- Groundwater pollution, and
- Soil contamination.

Therefore, the following steps should be taken to minimize your risk:

1. Designate areas of the construction site for material delivery and storage.
2. Place near the construction entrances and away from waterways.
3. Avoid transport near drainage paths or waterways.
4. Surround with earth berms, dikes, swales or other containment practices.
5. Place in an area which will be paved.
6. Storage of reactive, ignitable, or flammable liquids must comply with the fire codes of your area. Contact the local Fire Marshal to review site materials, quantities, and proposed storage area to determine specific requirements. See the Flammable and Combustible Liquid Code, NFPA30.
7. Follow manufacturer's instructions regarding uses, protective equipment, ventilation, flammability, and mixing of chemicals.
8. For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
9. Keep an accurate, up-to-date inventory of materials delivered and stored on-site.
10. Keep your inventory as close to "when you need it" levels as possible.
11. Minimize hazardous materials stored on-site and handle hazardous materials as infrequently as possible.
12. Consider storing materials in a covered area. Store materials in secondary containment's such as an earthen dike, horse trough, or even a children's wading pool for non-reactive materials such as detergents, oil, grease, and paints. Small amounts of material may be secondarily contained in 'bus boy' trays or concrete mixing trays.
13. Do not store chemicals, drums, or bagged materials directly on the ground unless otherwise contained. Place these items on a pallet and, when possible, in secondary containment.
14. Try to keep chemicals in their original containers, and keep them well labeled. If other containers are used then be sure they are well marked and can be adequately sealed and stored in an appropriate place.
15. Train employees and subcontractors.

Maintenance

- Keep designated storage areas clean and organized.
- Conduct routine weekly inspections and check for external corrosion of material containers.
- Keep an ample supply of clean up material on hand.
- Inspect storage areas before and after rainfall events.
- Repair or replace perimeter controls, containment structures and covers needed for functionality.

**Inspection
Checklist**

- Inspect storage area frequently for cleanliness and spills and leaks.
- Functions are appropriately utilized and ensured to allow proper procedures for delivery, storage and use.

**Approach
(cont'd)**

- Hold regular meetings to discuss and reinforce appropriate disposal procedures (incorporate into regular safety meetings).
- Establish a continuing education program to indoctrinate new employees.
- Designate a foreman or supervisor to oversee and enforce proper spill prevention and control measures.

NOTE: The first step for any spill cleanup, whether minor or significant, is for the employee to identify the spilled material or to find a co-worker that can do so. Once identified it may be necessary for personnel to use Personal Protective Equipment (PPE) prior to continuing with the cleanup. If the spill is significant or hazardous, then it will likely require help from a local emergency response team with more experience.

Cleanup

- Clean up leaks and spills immediately.
- Use as little water as possible when cleaning spills. Use a rag for small spills, a damp mop for general cleanup, and absorbent material for larger spills. If the spilled material is hazardous, then the used cleanup materials are also hazardous and must be sent to either a certified laundry (rags) or disposed of as hazardous waste.
- Never hose down or bury dry material spills. Clean up as much of the material as possible and dispose of properly. See the waste management BMPs in this section for specific information.

Minor Spills

- Minor spills typically involve small quantities of oil, gasoline, paint, etc. which can be controlled by the first responder at the discovery of the spill.
- Use absorbent materials on small spills rather than hosing down or burying the spill.
- Remove the absorbent materials promptly and dispose of properly.
- The practice commonly followed for a minor spill is:
 1. Contain the spread of the spill.
 2. Recover spilled materials.
 3. Clean the contaminated area and/or properly dispose of contaminated materials.

Semi-Significant Spills

- Remove the absorbent materials promptly and dispose of properly.
- Semi-significant spills still can be controlled by the first responder along with the aid of other personnel such as laborers and the foreman, etc. This response may require the cessation of all other activities and the use of PPEs.
- Clean up spills immediately:
 1. Notify the project foreman immediately. The foreman shall notify the Engineer or Safety Manager.
 2. Determine if spill response construction personnel are qualified to perform the cleanup in a safe manner. Alert additional trained personnel if necessary including a Haz-Mat team or dial 911 for local authorities.
 3. Contain spread of the spill.

Activity: Spill Prevention and Control

GHP-05

**Approach
(cont'd)**

4. If the spill occurs on paved or impermeable surfaces, clean up using "dry" methods (absorbent materials, cat litter and/or rags). Contain the spill by encircling with absorbent materials and do not let the spill spread widely.
5. If the spill occurs during rain, cover spill with tarps or other material to prevent contaminating runoff.

Significant/Hazardous Spills

For significant or hazardous spills that cannot be controlled by personnel in the immediate vicinity, the following steps shall be taken:

1. Notify the Engineer immediately and follow up with a written report.
2. Notify the local emergency response by dialing 911. In addition to 911, the contractor will notify the proper county officials. It is the contractor's responsibility to have all emergency phone numbers at the construction site.
3. For spills of state reportable quantities or into a water body or adjoining shoreline, the contractor shall notify the Kentucky Division of Water (KDOW) general hotline – environmental assistance at 1-800-928-2380.
4. For spills of federal reportable quantities or into a water body or adjoining shoreline, the contractor shall notify the National Response Center at (800) 424-8802.
5. Notification should first be made by telephone and followed up with a written report.
6. The services of a spill contractor or a Haz-Mat team shall be obtained immediately. Construction personnel should not attempt to clean up until the appropriate and qualified staff has arrived at the job site.
7. Other agencies which may need to be consulted include, but are not limited to, the Fire Department, the Public Works Department, the City/County Police Department, Occupational Safety and Health Administration (OSHA), etc.

See [GHP-12](#) and [-13](#) for details about spill prevention and control while maintaining or fueling vehicles and equipment.

Maintenance

- Keep an ample supply of spill control and cleanup material on-site, near storage, unloading and maintenance areas.
- Employee Training

**Inspection
Checklist**

- Required amount of clean up material available at the site.
- Employees clearly understand their duties when a spill occurs.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-06

Activity: Solid Waste Management (SWM)

**PLANNING
CONSIDERATIONS:**

Training:
No

**Inspection
Frequency:**
Weekly

**Implementation
Cost:**
Low

**Monthly
Maintenance:**
Low



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ◇ Heavy Metals ◇ Nutrients ◇ Oxygen Demanding Substances ◇ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ♦ Construction Waste ♦

Description

The management of waste in and out of a construction site reduces and in some cases prevents the discharge of pollutants to stormwater. This waste may be solid or construction waste, and can be disposed of at designated waste collection areas and in containers. This management practice will significantly reduce the quantity of floatable materials and other construction waste materials from escaping the construction site.

Approach

Solid waste is one of the major pollutants resulting from construction. Construction debris includes:

- Solid waste generated from trees and shrubs removed during land clearing, demolition of existing structures (rubble), and building construction;
- Packaging materials including wood, paper and plastic;
- Scrap or surplus building materials including scrap metals, rubber, plastic, glass pieces, and masonry products;
- Concrete, brick, and mortar;
- Pipe and electrical cuttings;
- Pavement planning or grinding and removal;
- Wood framing or false work; and
- Domestic wastes including food containers such as beverage cans, coffee cups, paper bags, and plastic wrappers, and cigarettes.

Activity: Solid Waste Management**GHP-06****Approach
(cont'd)**

The following steps will help keep a clean site and reduce stormwater pollution:



- Designate waste storage areas that are away from storm drain inlets, stormwater facilities, or watercourses.
- Provide containers in areas where employees congregate for breaks and lunch.
- Inform trash-hauling contractors that you will accept only watertight dumpsters for on-site use. Inspect dumpsters for leaks or open drain valves and repair any dumpster that is not watertight and tightly close the drain valve.
- Do not hose out dumpsters on the construction site. Leave dumpster cleaning to trash hauling contractor.
- Arrange for regular waste collection before containers overflow.
- If a container does spill, clean up immediately.
- Locate storage containers in a covered area and/or in secondary containment.
- Segregate potentially hazardous waste from non-hazardous construction site waste.
- Provide an adequate number of containers with lids or covers that can be placed over the container to keep rain out or to prevent loss of wastes when it is windy.
- Plan for additional containers and more frequent pickup during the demolition phase of construction.
- Collect site trash daily, especially during rainy and windy conditions.
- Erosion and sediment control devices tend to collect litter. Remove this solid waste promptly.
- Make sure that toxic liquid wastes (used oils, solvents, and paints) and chemicals (acids, pesticides, additives, curing compounds) are not disposed of in dumpsters designated for construction debris.
- Salvage or recycle any useful material. For example, trees and shrubs from land clearing can be used as a brush barrier or converted into wood chips, then used as mulch on graded areas.
- Make sure that construction waste is collected, removed, and disposed of only at authorized disposal areas.
- Train employees and subcontractors in proper solid waste management.
- Require that employees and subcontractors follow solid waste handling and storage procedures.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).

Maintenance

- Collect site trash daily.
- Inspect construction waste area regularly.
- Arrange for regular waste collection.

**Inspection
Checklist**

- There are no major limitations to this best management practice.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Good Housekeeping Practices (GHPs)	GHP-07																				
Activity: Hazardous Waste Management (HWM)																						
PLANNING CONSIDERATIONS: Training: Yes Inspection Frequency: Weekly Implementation Cost: Low Monthly Maintenance: Low	<table border="1"> <thead> <tr> <th colspan="5" data-bbox="407 852 1425 894">Target Pollutants</th> </tr> <tr> <th data-bbox="407 898 716 940">Significant ♦</th> <th data-bbox="719 898 1027 940">Partial ♦</th> <th data-bbox="1031 898 1425 940">Low or Unknown ♦</th> <th colspan="2"></th> </tr> </thead> <tbody> <tr> <td data-bbox="407 945 553 966">Sediment ♦</td> <td data-bbox="557 945 703 966">Heavy Metals ♦</td> <td data-bbox="706 945 852 966">Nutrients ♦</td> <td data-bbox="855 945 1164 966">Oxygen Demanding Substances ♦</td> <td data-bbox="1167 945 1425 966">Toxic Materials ♦</td> </tr> <tr> <td data-bbox="407 970 553 991">Oil & Grease ♦</td> <td data-bbox="557 970 703 991">Bacteria & Viruses ♦</td> <td data-bbox="706 970 852 991">Floatable Materials ♦</td> <td data-bbox="855 970 1002 991">Construction Waste ♦</td> <td></td> </tr> </tbody> </table>		Target Pollutants					Significant ♦	Partial ♦	Low or Unknown ♦			Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦	Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	
Target Pollutants																						
Significant ♦	Partial ♦	Low or Unknown ♦																				
Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦																		
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦																			
Description Approach	<p>Educating employees and subcontractors on methods for properly managing, storing, and disposing hazardous waste will aid in reducing pollution leaving the construction site, thus resulting in a partial reduction of toxic materials entering stormwater conveyance systems.</p> <p>Most chemicals used on-site can be hazardous materials which become hazardous waste upon disposal. These wastes may include:</p> <ul style="list-style-type: none"> ➤ Paints and solvents ➤ Petroleum products such as oils, fuels, and grease ➤ Herbicides and pesticides ➤ Acids for cleaning masonry ➤ Concrete curing compounds <p>In addition, sites with existing structures may contain wastes which must be disposed of in accordance with Federal, State, and local regulations. These wastes include:</p> <ul style="list-style-type: none"> ➤ Sandblasting grit mixed with lead-, cadmium-, or chromium-based paints; ➤ Asbestos; and ➤ PCBs (particularly in older transformers). 																					

**Approach
(cont'd)**

The following steps will help reduce stormwater pollution from hazardous wastes:

Material Use

- Use the entire product before disposing of the container.
- Do not remove the original product label; it contains important safety and disposal information.
- Material Safety Data Sheets should be provided for each product being handled. All persons using or handling the product should be made aware of the safety information and the location of the readily available Material Safety Data Sheets.
- Do not over-apply herbicides and pesticides. Prepare only the amount needed. Follow the recommended usage instructions. Over-application is expensive, environmentally harmful and generally doesn't provide the intended additional benefit. Apply surface dressings in several smaller applications, as opposed to one large application, to allow time for infiltration and to avoid excess material being carried off-site by runoff. Do not apply these chemicals just before it rains. People applying pesticides must be trained and certified in accordance with Federal and State regulations.
- Do not clean out brushes or rinse paint containers into the dirt, street, gutter, storm drain, or stream. "Paint out" brushes as much as possible. Rinse water-based paints to the sanitary sewer. Filter and re-use thinners and solvents. Dispose of excess oil-based paints and sludge as hazardous waste.

Waste Recycling/Disposal

- Select designated hazardous waste collection areas on-site.
- Regularly schedule hazardous waste removal to minimize on-site storage.
- Hazardous materials and wastes should be stored in covered containers and protected from vandalism. They should be stored in the original containers or in other well marked containers.
- Place hazardous waste containers in secondary containment.

Storage Procedures

- Ensure that adequate hazardous waste storage volume is available.
- Ensure that hazardous waste collection containers are conveniently located.
- Designate hazardous waste storage areas on site, away from storm drains or watercourses.
- Minimize production or generation of hazardous materials and hazardous waste on the jobsite.
- Use containment berms in fueling and maintenance areas and where the potential for spills is high.
- Segregate potentially hazardous waste from non-hazardous construction site debris.
- Store hazardous materials and wastes in covered containers and protected from vandalism.
- Keep liquid or semi-liquid hazardous waste in appropriate containers (closed drums or similar) and under cover.

**Approach
(cont'd)**

- Clearly mark on all hazardous waste containers which materials are acceptable for the container.
- Place hazardous waste containers in secondary containment.
- Do not allow potentially hazardous waste materials to accumulate on the ground.
- Do not mix wastes as this can cause unforeseen chemical reactions, make recycling impossible and complicate disposal.
- Recycle any useful material such as used oil or water-based paint.
- Make sure that toxic liquid wastes (used oils, solvents, and paints) and chemicals (acids, pesticides, additives, curing compounds) are not disposed of in dumpsters designated for non-hazardous construction debris.
- Arrange for regular waste collection before containers overflow.
- Make sure that hazardous waste (e.g. excess oil-based paint and sludge) is collected, removed, and disposed of only at authorized disposal areas.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).

Training

- Educate employees and subcontractors on hazardous waste storage and disposal procedures.
- Educate employees and subcontractors of potential dangers to humans and the environment from hazardous wastes.
- Instruct employees and subcontractors on safety procedures for common construction site hazardous wastes.
- Instruct employees and subcontractors in identification of hazardous and solid waste.
- Hold regular meetings to discuss and reinforce disposal procedures (incorporate into regular safety meetings).
- Designate a foreman or supervisor to oversee and enforce proper solid waste management procedures and practices.
- Make sure that hazardous waste is collected, removed, and disposed of only at authorized disposal areas.
- Train employees and subcontractors in proper hazardous waste management including review of material safety data sheets.
- Warning signs should be placed in areas recently treated with chemicals.
- Place a stockpile of spill cleanup materials where it will be readily accessible.
- If a container does spill, clean up immediately.

Activity: Hazardous Waste Management



GHP-07

Maintenance

- Inspect hazardous waste receptacles and area regularly.
- Arrange for regular hazardous waste collection.

Inspection

- Hazardous waste receptacles are properly maintained.
- Hazardous waste material is properly and routinely removed from the site by a licensed hazardous waste hauler.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Good Housekeeping Practices (GHPs)	GHP-08
PLANNING CONSIDERATIONS: Training: Yes Inspection Frequency: Weekly Implementation Cost: Low Monthly Maintenance: Low		
	Target Pollutants	
	<div style="display: flex; justify-content: space-around;"> Significant ♦ Partial ♦ Low or Unknown ♦ </div>	
	<div style="display: flex; justify-content: space-between;"> Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ </div> <div style="display: flex; justify-content: space-between;"> Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦ </div>	
Description Suitable Applications Approach	<p>Contaminated soil and highly acidic or alkaline soils produce pollutants in stormwater. Contaminated Soil Management allows preventive measures such as pre-construction surveying, inspecting excavations regularly, and remediating contaminated soil promptly all reduce or prevent the discharge of pollutants to stormwater.</p> <ul style="list-style-type: none"> ➤ Applicable to many construction projects, especially those in highly urbanized or industrial areas, where soil contamination may have occurred due to spills, illicit discharges, and underground storage tanks. ➤ Applicable to highway widening projects in older areas where median and shoulder soils may have been contaminated by aerially deposited lead. <p>Contaminated soils are often identified in the project material report with known locations identified in the plans and specifications. The contractor shall review applicable reports and investigate appropriate callouts in the plans and specifications.</p> <p>Contaminated soils may occur on your site for several reasons including:</p> <ul style="list-style-type: none"> ➤ Past site uses and activities; ➤ Detected or undetected spills and leaks; and ➤ Acid or alkaline solutions from exposed soil or rock formations high in acid or alkaline-forming elements. 	

**Approach
(cont'd)**

Most developers conduct pre-construction environmental assessments as a matter of routine. Recent court rulings holding contractors liable for cleanup costs when they unknowingly move contaminated soil, highlight the need for contractors to confirm that a site assessment is completed before earth moving begins.

The following steps will help reduce stormwater pollution from contaminated soil:

- Conduct thorough site planning including pre-construction geologic surveys.
- Look for contaminated soil as evidenced by discoloration, odors, differences in soil properties, abandoned underground tanks or pipes, or buried debris.
- Prevent leaks and spills to the maximum extent practicable. Contaminated soil can be expensive to treat and/or dispose of properly. However, addressing the problem before construction is much less expensive than after the structures are in place.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).

Application of this BMP Fact Sheet

Excavation, transport, and disposal of contaminated material and hazardous material shall be in accordance with the rules and regulations of the following agencies (the specifications of these agencies shall supersede the procedures outlined in this BMP):

- United States Environmental Protection Agency (USEPA)
- Kentucky Division of Water (KDOW)
- UST Branch, Kentucky Division of Waste Management (KDWM)
- Kentucky Division of Occupation Safety and Health Administration (OSHA)

Education

- Prior to performing any excavation work at the locations containing material classified as hazardous, employees and subcontractors shall complete a safety-training program.
- Educate employees and subcontractors on contaminated soil handling and disposal procedures.
- Instruct employees and subcontractors in identification of contaminated soil.
- Hold regular meetings to discuss and reinforce disposal procedures (incorporate into regular safety meetings).
- Provide additional training for field supervisors and inspectors, including hazardous material safety training.

Handling Procedures for Material with Aerially Deposited Lead

- Materials from areas designated as containing aerially deposited lead may, if allowed by the contract special provisions, be excavated, transported, and used in the construction of embankments and/or backfill.
- Excavation, transportation, and placement operations shall result in no visible dust.
- Use caution to prevent spillage of lead containing material during transport.
- Monitor the air quality during excavation of soils contaminated with lead.

**Approach
(cont'd)*****Handling Procedures for Contaminated Soils or Hazardous Materials***

- Test suspected soils at a certified laboratory.
- If the soil is contaminated, work with KDOW or environmental contractor to develop options for treatment and/or disposal.
- Avoid temporary stockpiling of contaminated soils or hazardous material.
- If temporary stockpiling is necessary:
 1. Cover the stockpile with plastic sheeting or tarps.
 2. Install a berm around the stockpile to prevent runoff from leaving the area.
 3. Do not stockpile in or near storm drains or watercourses.
 4. Implement stockpile controls as presented in [GHP-04: Material Delivery, Storage, and Use](#).
- Contaminated material and hazardous material on exteriors of transport vehicles shall be removed and placed either into the current transport vehicle or the excavation prior to the vehicle leaving the exclusion zone.
- Monitor the air quality continuously during excavation operations at all locations containing hazardous material.
- Procure all permits and licenses, pay all charges and fees, and give all notices necessary and incident to the due and lawful prosecution of the work, including registration for transporting vehicles carrying the contaminated material and the hazardous material.
- Collect water from decontamination procedures and dispose of at an appropriate disposal site.
- Collect non-reusable personal protective equipment (PPE), once used by any personnel, and dispose of at an appropriate disposal site.
- Install temporary security fence to surround and secure the exclusion zone. Remove fencing when no longer needed.

Procedures for Underground Storage Tank Removals

- Prior to commencing tank removal operations, obtain the required underground storage tank removal permits and approval from UST Branch, Kentucky Division of Waste Management, which has jurisdiction over such work.
- Arrange to have tested, as directed by the design professional, any liquid or sludge found in the underground tank prior to its removal to determine if it contains hazardous material.
- Following the tank removal, take soil samples beneath the excavated tank and perform analysis as required by UST Branch, Kentucky Division of Waste Management and the local agency representative(s).
- The underground storage tank, any liquid and/or sludge found within the tank, and all contaminated material and hazardous material removed during the tank removal shall be transported to disposal facilities permitted to accept such material by a licensed hazardous waste hauler.

Activity: Contaminated Soil Management

GHP-08

**Approach
(cont'd)***Water Control*

- Take all necessary precautions and preventive measures to prevent the flow of water, including ground water, from entering hazardous material or underground storage tank excavations. Such preventative measures may consist of, but are not limited to berms, cofferdams, grout curtains, freeze walls, and seal course concrete or any combination thereof.
- If water does enter an excavation and becomes contaminated, such water, when necessary to proceed with the work, shall be discharged to clean, closed top, watertight, transportable holding tanks, and disposed of in accordance with federal, state, and local laws.

Maintenance

- Inspect excavated areas daily for indications of contaminated soil.
- Implement [GHP-05](#): Spill Prevention and Control, to prevent leaks and spills as much as possible.
- Monitor air quality continuously during excavation operations at all locations containing hazardous material.
- Coordinate contaminated soils and hazardous material management with the appropriate federal, state, and local agencies.
- Inspect hazardous waste receptacles and areas regularly.

**Inspection
Checklist**

- The procedures and practices presented in this BMP are general. The contractor shall identify appropriate practices and procedures for the specific contaminants known to exist or discovered on site.
- Contaminated soils that cannot be treated on-site must be disposed of off-site by a licensed hazardous waste hauler.
- The presence of contaminated soil may indicate contaminated water as well. See [GHP-01](#): Dewatering Operations for more information.

Activity: Concrete Waste Management**GHP-09****Approach
(cont'd)**

- When washing concrete to remove fine particles and expose the aggregate, avoid creating runoff by draining the water to a bermed or level area.
- Do not wash sweepings from exposed aggregate concrete into the street or storm drain. Collect and return sweepings to aggregate base stockpile, or dispose in the trash.
- Train employees and subcontractors in proper concrete waste management.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
- Illicit dumping on-site or off-site without property owner's knowledge and consent is unacceptable.
- Washout locations may be flagged with lath and surveyors tape or designated as necessary to insure that truck drivers utilize proper areas.

Education

- Instruct drivers and equipment operators on proper disposal and equipment washout practices.
- Educate employees, subcontractors, and suppliers on concrete waste storage and disposal procedures.
- Designate a foreman or supervisor to oversee and enforce concrete waste management procedures. Make supervisors aware of the potential environmental consequences of improperly handled concrete wastes.

Demolition Practices

- Monitor weather and wind direction to ensure concrete dust is not entering storm drains, watercourses, or surface waters.
- Where appropriate, construct sediment traps or other types of sediment detention devices downstream of demolition activities.

Maintenance

- Inspect subcontractors to ensure that concrete wastes are being properly managed.
- If using a temporary pit, dispose hardened concrete on a regular basis that will prevent the pit from being more than half-full.
- Foreman and/or construction supervisor shall monitor on site concrete waste storage and disposal procedures at least weekly.

Inspection

- Concrete waste receptacles are maintained and emptied routinely.
- On-site wash out area is located at least 50 ft. from storm drains, open ditches, or other water bodies
- On-site wash out area is properly maintained and cleaned.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-10

**Activity: Sanitary/Septic Waste Management
(S&SWM)**

**PLANNING
CONSIDERATIONS:**

Training:
Yes

**Inspection
Frequency:**
Weekly

**Implementation
Cost:**
Medium

**Monthly
Maintenance:**
Medium



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ♦

Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦
Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦

Description

Providing convenient well-maintained sanitary and septic waste facilities with regular service and disposal reduces or prevents discharge of pollutants to stormwater from sanitary/septic waste.

Approach

- Sanitary or septic wastes should be treated or disposed of in accordance with Kentucky Division of Water (KDOW) and local health department requirements.
- Locate sanitary facilities in a convenient location.
- Never discharge untreated or raw wastewater to a ditch, creek or other waterway, or bury on site.
- Temporary septic systems should treat wastes to appropriate levels prior to discharging. KDOW should be consulted to determine appropriate levels.
- If using an on-site disposal system (OSDS), such as a septic system, comply with local health agency requirements.
- Temporary sanitary facilities that discharge to the sanitary sewer system should be properly connected and inspected by the local sewer authority to avoid illicit discharges to the storm sewer system and other pertinent requirements.
- Privately held sanitary/septic facilities should be maintained in good working order by a licensed service.
- Arrange for regular waste collection by a licensed hauler before facilities overflow.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
- Anchor portable sanitary facilities, when needed, to prevent them from tipping by vandals.

Activity: Sanitary/Septic Waste Management

GHP-10

- Maintenance**
- Inspect facilities regularly.
 - Arrange for regular waste collection.

- Inspection Checklist**
- There are no major limitations to this best management practice other than those that may be imposed by the local sewer authority.

Activity: Vehicle and Equipment Cleaning**GHP-11****Approach
(cont'd)**



- When vehicle/equipment washing/cleaning must occur on-site, and the operation cannot be located within a structure or building equipped with sanitary sewer facilities, the outside cleaning area shall have the following characteristics:
 1. Located away from storm drain inlets, drainage facilities, or watercourses;
 2. Paved with concrete or asphalt, or stabilized with an aggregate base;
 3. Configured wash area with a sump to allow collection and disposal of wash water;
 4. Discharge wash water to a sanitary or process waste sewer (where permitted), or to a dead end sump. Wash waters shall not be discharged to storm drains or watercourses.
- When cleaning vehicles/equipment with water:
 1. Use as little water as possible to avoid having to install erosion and sediment controls for the wash area. High-pressure sprayers may use less water than a hose, and should be considered.
 2. Use positive shutoff valve to minimize water usage.
- DO NOT use solvents to clean vehicles/equipment on site.

Maintenance

- Minimal, some berm repair may be necessary, inspect weekly.
- Service sump regularly.

**Inspection
Checklist**

- No phosphate-free, biodegradable soaps are being used.
- Vehicles and equipment are sent off-site using the stabilized construction entrance and mud tracking removal.
- The local sewer authority has been contacted and is aware of all pretreatment and monitoring of wash water discharges to the sanitary sewer.



TYPICAL VEHICLE & EQUIPMENT CLEANING AREA
NOT TO SCALE

Figure GHP-11
Typical Vehicle and Equipment Cleaning Area

Activity: Vehicle and Equipment Fueling**GHP-12****Approach
(cont'd)**

- Observe Federal and State requirements regarding stationary above-ground storage tanks with special attention given to secondary containment.
- Avoid mobile fueling of mobile construction equipment around the site; rather, transport the equipment to designated fueling areas. With the exception of tracked equipment such as bulldozers and perhaps forklifts, most vehicles should be able to travel to a designated area with little lost time.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
- Locate fueling areas on a paved surface where practical.
- Protect fueling areas with berms and/or dikes to prevent run-on, runoff, and to contain spills.
- Use vapor recovery nozzles to help control drips as well as air pollution where required by Air Quality Management Districts.

Maintenance

- Keep ample supplies of spill cleanup materials on-site.
- Inspect fueling areas and storage tanks on a regular schedule.

**Inspection
Checklist**

- Secondary containment area is properly maintained and preventing petroleum products from runoff to streams and ditches.
- Construction site has proper materials for cleaning spills.
- Fueling tanks are working properly.

Activity: Vehicle and Equipment Maintenance

GHP-13

**Approach
(cont'd)**

- Check for inactive ingredients to see whether it contains chlorinated solvents. The "chlor" term indicates that the solvent is chlorinated.
- Substitute a wire brushes for solvents to clean parts.
- If maintenance must occur on-site, use designated areas, located away from watercourses, to prevent the run-on of stormwater and the runoff of spills.
- Use secondary containment, such as a drain pan or drop cloth, to catch spills or leaks when removing or changing fluids.
- Place a stockpile of spill cleanup materials where it will be readily accessible.
- Place drip pans or absorbent materials under paving equipment when not in use.
- Use adsorbent materials on small spills rather than hosing down or burying the spill. Remove the adsorbent materials promptly and dispose of properly.
- Regularly inspect on-site vehicles and equipment for leaks, and repair immediately.
- Promptly transfer used fluids to the proper waste or recycling drums. Don't leave full drip pans or other open containers lying around.
- Check incoming vehicles and equipment (including delivery trucks, and employee and subcontractor vehicles) for leaking oil and fluids. Do not allow leaking vehicles or equipment on-site.
- Oil filters disposed of in trashcans or dumpsters can leak oil and pollute stormwater. Place the oil filter in a funnel over a waste oil recycling drum to drain excess oil before disposal. Oil filters can also be recycled. Ask your oil supplier or recycler about recycling oil filters.
- Store cracked batteries in a non-leaking secondary container. Do this with all cracked batteries, even if you think all the acid has drained out. If you drop a battery, treat it as if it is cracked. Put it into the containment area until you are sure it is not leaking.
- Segregate and recycle wastes, such as greases, used oil or oil filters, antifreeze, cleaning solutions, automotive batteries, hydraulic, and transmission fluids.
- Train employees and subcontractors in proper maintenance and spill cleanup procedures.
- For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, [Table GHP-14-1](#).
- Perform maintenance activities on paved surfaces where practical.
- Use diversion berms to protect maintenance areas from run-on.
- Provide spill containment dikes or secondary containment around stored oil and chemical drums.
- For long-term projects, consider using portable tents or covers over maintenance areas.
- Do not dump fuels and lubricants onto the ground.
- Do not place used oil in a dumpster or pour into a storm drain or watercourse.
- Do not bury used tires.

**Approach
(cont'd)*****Recycling/Disposal***

- Separating wastes allows for easier recycling and may reduce disposal costs. Keep hazardous and non-hazardous wastes separate, do not mix used oil and solvents, and keep chlorinated solvents (like 1,1,1-trichloroethane) separate from non-chlorinated solvents (like kerosene and mineral spirits).
- Do not dispose of extra paints and coatings by dumping liquid onto the ground or throwing it into dumpsters. Allow coatings to dry or harden before disposal into covered dumpsters.

Maintenance

- Keep ample supplies of spill cleanup materials on-site.
- Inspect maintenance areas on a regular schedule.
- Maintain waste fluid containers in leak proof condition.
- Vehicle and equipment maintenance areas shall be inspected regularly.
- Inspect equipment for damaged hoses and leaky gaskets routinely. Repair or replace as needed.

**Inspection
Checklist**

- On-site maintenance area is cleaned and properly maintained.
- Construction site has proper materials for cleaning spills.
- Watercourses in the vicinity are protected from spills by a diversion berm.
- Sending vehicles/equipment off-site should be done in conjunction with a stabilized construction entrance.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-14

Activity: Employee/Subcontractor Training (EST)



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
Sediment ♦	Heavy Metals ♦	Nutrients ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦
	Oxygen Demanding Substances ♦	Toxic Materials ♦
	Construction Waste ♦	

PLANNING CONSIDERATIONS:
Training: Yes
Inspection Frequency: None
Implementation Cost: Medium
Monthly Maintenance: Low

Description

Employee or subcontractor training will determine the success of the stormwater pollution prevention program. This BMP will focus on approaches to assure that employees and subcontractors are familiar with Madisonville's the Stormwater ordinances and will turn the attention from an individualized source control into a comprehensive training program.

Suitable Applications

Employee/subcontractor training should be based on four objectives:

1. Promote a clear identification and understanding of the problem, including activities with the potential to pollute stormwater;
2. Identify solutions (BMPs);
3. Promote employee/subcontractor ownership of the problems and the solutions; and
4. Integrate employee/subcontractor feedback into training and BMP implementation.

Approach

- Integrate training regarding stormwater quality management with existing training programs that may be required for your business by other regulations such as the 40-hour Hazardous Waste Operations and Emergency Response (HAZWOPER) standard (29 CFR 1910.120); and the Spill Prevention Control and Countermeasure (SPCC) Plan (40 CFR 112).
- Supervisors and inspectors should receive additional annual 8-hour refresher courses.

Activity: Employee/Subcontractor Training

GHP-14

**Approach
(cont'd)**

- Businesses, particularly smaller ones that may not be regulated by Federal, State, or local regulations, may use the information in this BMP Manual to develop a training program to reduce their potential to pollute stormwater.
- Use the quick reference on disposal alternatives ([Table GHP-14-1](#)) to train employee/subcontractors in proper and consistent methods for disposal.
- Consider posting the quick reference table around the job site or in the on-site office trailer to reinforce training.
- Train employee/subcontractors in standard operating procedures and spill cleanup techniques described in the fact sheets. Employee/subcontractors trained in spill containment and cleanup should be present during the loading/unloading and handling of materials.
- Personnel who use pesticides should be trained in their use.
- Proper education of off-site contractors is often overlooked. The conscientious efforts of well trained employee/subcontractors can be lost by unknowing off-site contractors, so make sure they are well informed about what they are expected to do on-site.

TABLE GHP-14-1 QUICK REFERENCE – DISPOSAL ALTERNATIVES

All of the waste products on this chart are prohibited from discharge to the storm drain system. Use this matrix to decide which alternative disposal strategies to use. **ALTERNATIVES ARE LISTED IN PRIORITY ORDER.**

Key: HHW Household hazardous waste MWS Municipal Waste System
 NPDES National Pollutant Discharge Elimination System (NPDES) Office. POTW Publicly Owned Treatment Plant
 "Dispose to sanitary sewer" means dispose into sink, toilet, or sanitary sewer clean-out connection.
 "Dispose as trash" means dispose in dumpsters or trash containers for pickup and/or eventual disposal in landfill.
 "Dispose as hazardous waste" for business/commercial means contract with a hazardous waste hauler to remove and dispose.

DISCHARGE/ACTIVITY	BUSINESS/COMMERCIAL		RESIDENTIAL
	Disposal Priorities	Approval	
General Construction and Painting: Street and Utility Maintenance			
Excess paint (oil based)	<ol style="list-style-type: none"> 1. Recycle/reuse. 2. Solidify and dispose as hazardous waste. 		<ol style="list-style-type: none"> 1. Recycle/reuse. 2. Take to HHW drop-off.
Excess paint (water based)	<ol style="list-style-type: none"> 1. Recycle/reuse 2. Dry residue in cans, dispose as trash. 3. If volume is too much to dry, solidify and dispose as hazardous waste. 		<ol style="list-style-type: none"> 1. Recycle/reuse. 2. Dry residue in cans, dispose as trash. 3. If volume is too much to dry, take to HHW drop-off.
Paint cleanup (oil based)	Wipe paint out of brushes, then: <ol style="list-style-type: none"> 1. Filter & reuse thinners, solvents. 2. Solidify and dispose as hazardous waste. 		Wipe paint out of brushes, then: <ol style="list-style-type: none"> 1. Filter & reuse thinners, solvents. 2. Take to HHW drop-off.
Paint cleanup (water-based)	Wipe paint out of brushes, then <ol style="list-style-type: none"> 1. Rinse to sanitary sewer. 		Wipe paint out of brushes, then <ol style="list-style-type: none"> 1. Rinse to sanitary sewer.
Empty paint cans (dry)	<ol style="list-style-type: none"> 1. Remove lids, dispose as trash. 		<ol style="list-style-type: none"> 1. Remove lids, dispose as trash.
Paint stripping (with solvent)	<ol style="list-style-type: none"> 1. Dispose as hazardous waste. 		<ol style="list-style-type: none"> 1. Take to HHW drop-off.
Building exterior cleaning (high-pressure water)	<ol style="list-style-type: none"> 1. Prevent entry into storm drain and remove offsite. 2. Wash onto dirt area, spade in. 3. Collect (e.g. mop up) and discharge to sanitary sewer. 	POTW-MWS	
Cleaning of building exteriors which have HAZARDOUS MATERIALS (e.g. mercury, lead) in paints	<ol style="list-style-type: none"> 1. Use dry cleaning methods. 2. Contain and dispose washwater as hazardous waste (Suggestion: dry material first to reduce volume). 		



General Construction and Painting: Street and Utility Maintenance (cont'd.)			
Non-hazardous paint scraping/sand blasting	1. Dry sweep, dispose as trash.		1. Dry sweep, dispose as trash.
HAZARDOUS paint scraping/sand blasting (e.g. marine paints or paints containing lead or tributyl tin)	1. Dry sweep, dispose as hazardous waste.		1. Dry sweep, take to HHW drop-off.
Soil from excavations during periods when storms are forecast	1. Should not be placed in street or on paved areas. 2. Remove from site or backfill by end of day. 3. Cover with tarpaulin or surround with silt fences, or use other runoff controls. 4. Place filter mat over storm drain. Note: Thoroughly sweep following removal of dirt in all four alternatives.		
Soil from excavations placed on paved surfaces during periods when storms are not forecast	1. Keep material out of storm conveyance systems and thoroughly remove via sweeping following removal of dirt.		
Cleaning streets in construction areas	1. Dry sweep and minimize tracking of mud. 2. Use silt ponds and/or similar pollutant reduction techniques when flushing pavement.		
Soil erosion, sediments	1. Cover disturbed soils, use erosion controls, block entry to storm drain. 2. Seed or plant immediately.		
Fresh cement, grout, mortar	1. Use/reuse excess 2. Dispose to trash		1. Use/reuse excess 2. Dispose to trash
Washwater from concrete/mortar (etc.) cleanup	1. Wash onto dirt area, spade in. 2. Pump and remove to appropriate disposal facility. 3. Settle, pump water to sanitary sewer.	POTW-MWS	1. Wash onto dirt area, spade in. 2. Pump and remove to appropriate disposal facility. 3. Settle, pump water to sanitary sewer.
Aggregate wash from driveway/patio construction	1. Wash onto dirt area, spade in. 2. Pump and remove to appropriate disposal facility. 3. Settle, pump water to sanitary sewer.	POTW-MWS	1. Wash onto dirt area, spade in. 2. Pump and remove to appropriate disposal facility. 3. Settle, pump water to sanitary sewer.
Rinsewater from concrete mixing trucks	1. Return truck to yard for rinsing into pond or dirt area. 2. At construction site, wash into pond or dirt area.		

General Construction and Painting: Street and Utility Maintenance (cont'd.)			
Non-hazardous construction and demolition debris	<ol style="list-style-type: none"> 1. Recycle/reuse (concrete, wood, etc.). 2. Dispose as trash. 		<ol style="list-style-type: none"> 1. Recycle/reuse (concrete, wood, etc.). 2. Dispose as trash.
Hazardous demolition and construction debris (e.g. asbestos)	<ol style="list-style-type: none"> 1. Dispose as hazardous waste. 		<ol style="list-style-type: none"> 1. Do not attempt to remove yourself. Contact asbestos removal service for safe removal and disposal. 2. Very small amounts (less than 5 lbs.) may be double-wrapped in plastic and taken to HHW drop-off.
Saw-cut slurry	<ol style="list-style-type: none"> 1. Use dry cutting technique and sweep up residue. 2. Vacuum slurry and dispose off-site. 3. Block storm drain or berm with low weir as necessary to allow most solids to settle. Shovel out gutters; dispose residue to dirt area, construction yard or landfill. 		
Construction dewatering (Nonturbid, uncontaminated groundwater)	<ol style="list-style-type: none"> 1. Recycle/reuse. 2. Discharge to storm drain. 		
Construction dewatering (Other than nonturbid, uncontaminated groundwater)	<ol style="list-style-type: none"> 1. Recycle/reuse. 2. Discharge to sanitary sewer. 3. As appropriate, treat prior to discharge to storm drain. 	POTW-MWS MDPW- NPDES	
Portable toilet waste	<ol style="list-style-type: none"> 1. Leasing company shall dispose to sanitary sewer at POTW. 	POTW-MWS	
Leaks from garbage dumpsters	<ol style="list-style-type: none"> 1. Collect, contain leaking material. Eliminate leak, keep covered, return to leasing company for immediate repair. 2. If dumpster is used for liquid waste, use plastic liner. 		
Leaks from construction debris bins	<ol style="list-style-type: none"> 1. Insure that bins are used for dry nonhazardous materials only (Suggestion: Fencing, covering help prevent misuse). 		
Dumpster cleaning water	<ol style="list-style-type: none"> 1. Clean at dumpster owner's facility and discharge waste through grease interceptor to sanitary sewer. 2. Clean on site and discharge through grease interceptor to sanitary sewer. 	POTW-MWS POTW-MWS	

DISCHARGE/ACTIVITY	BUSINESS/COMMERCIAL Disposal Priorities Approval	RESIDENTIAL Disposal Priorities
General Construction and Painting: Street and Utility Maintenance (cont'd.)		
Cleaning driveways, paved areas (Special Focus = Restaurant alleys, grocery dumpster areas)	<ol style="list-style-type: none"> 1. Sweep and dispose as trash (Dry cleaning only). 2. For vehicle leaks, restaurant/grocery alleys, follow this 3-step process: <ol style="list-style-type: none"> a. Clean up leaks with rags or absorbents. b. Sweep, using granular absorbent material (cat litter). c. Mop and dispose of mopwater to sanitary sewer (or collect rinsewater and pump to the sanitary sewer). 3. Same as 2 above, but with rinsewater (2c)(no soap) discharged to storm drain. 	<ol style="list-style-type: none"> 1. Sweep and dispose as trash (Dry cleaning only). 2. For vehicle leaks follow this 3-step process: <ol style="list-style-type: none"> a. Clean up leaks with rags or absorbents; dispose as hazardous waste. b. Sweep, using granular absorbent material (cat litter). c. Mop and dispose of mopwater to sanitary sewer.
Steam cleaning of sidewalks, plazas	<ol style="list-style-type: none"> 1. Collect all water and pump to sanitary sewer. 2. Follow this 3-step process: <ol style="list-style-type: none"> a. Clean oil leaks with rags or adsorbents. b. Sweep (Use dry absorbent as needed). c. Use no soap, discharge to storm drain. 	
Potable water/line flushing Hydrant testing	<ol style="list-style-type: none"> 1. Deactivate chlorine by maximizing time water will travel before reaching creeks. 	
Super-chlorinated (above 1 ppm) water from line flushing	<ol style="list-style-type: none"> 1. Discharge to sanitary sewer. 2. Complete dechlorination required before discharge to storm drain. 	
Landscape/Garden Maintenance		
Pesticides	<ol style="list-style-type: none"> 1. Use up. Rinse containers, use rinsewater as product. Dispose rinsed containers as trash. 2. Dispose unused pesticide as hazardous waste. 	<ol style="list-style-type: none"> 1. Use up. Rinse containers, use rinsewater as pesticide. Dispose rinsed container as trash. 2. Take unused pesticide to HHW drop-off.
Garden clippings	<ol style="list-style-type: none"> 1. Compost. 2. Take to Landfill. 	<ol style="list-style-type: none"> 1. Compost. 2. Dispose as trash.
Tree trimming	<ol style="list-style-type: none"> 1. Chip if necessary, before composting or recycling. 	<ol style="list-style-type: none"> 1. Chip if necessary, before composting or recycling.

DISCHARGE/ACTIVITY	BUSINESS/COMMERCIAL Disposal Priorities	Approval	RESIDENTIAL Disposal Priorities
Landscape/Garden Maintenance (cont'd.)			
Swimming pool, spa, fountain water (emptying)	<ol style="list-style-type: none"> 1. Do not use metal-based algicides (i.e. Copper Sulfate). 2. Recycle/reuse (e.g. irrigation). 3. Determine chlorine residual = 0, wait 24 hours and then discharge to storm drain. 	POTW-MWS	<ol style="list-style-type: none"> 1. Do not use metal-based algicides (i.e. Copper Sulfate). 2. Recycle/reuse (e.g. irrigation). 3. Determine chlorine residual = 0, wait 24 hours and then discharge to storm drain.
Acid or other pool/spa/fountain cleaning	<ol style="list-style-type: none"> 1. Neutralize and discharge to sanitary sewer. 	POTW-MWS	
Swimming pool, spa filter backwash	<ol style="list-style-type: none"> 1. Reuse for irrigation. 2. Dispose on dirt area. 3. Settle, dispose to sanitary sewer. 		<ol style="list-style-type: none"> 1. Use for landscape irrigation. 2. Dispose on dirt area. 3. Settle, dispose to sanitary sewer.
Vehicle Wastes			
Used motor oil	<ol style="list-style-type: none"> 1. Use secondary containment while storing, send to recycler. 		<ol style="list-style-type: none"> 1. Put out for curbside recycling pickup where available. 2. Take to Recycling Facility or auto service facility with recycling program. 3. Take to HHW events accepting motor oil (i.e. car parts store).
Antifreeze	<ol style="list-style-type: none"> 1. Use secondary containment while storing, send to recycler. 		<ol style="list-style-type: none"> 1. Take to Recycling Facility.
Other vehicle fluids and solvents	<ol style="list-style-type: none"> 1. Dispose as hazardous waste. 		<ol style="list-style-type: none"> 1. Take to HHW event.
Automobile batteries	<ol style="list-style-type: none"> 1. Send to auto battery recycler. 2. Take to Recycling Center. 		<ol style="list-style-type: none"> 1. Exchange at retail outlet. 2. Take to Recycling Facility or HHW event where batteries are accepted.
Motor home/construction trailer waste	<ol style="list-style-type: none"> 1. Use holding tank. Dispose to sanitary sewer. 		<ol style="list-style-type: none"> 1. Use holding tank, dispose to sanitary sewer.
Vehicle washing	<ol style="list-style-type: none"> 1. Recycle. 2. Discharge to sanitary sewer, never to storm drain. 	POTW-MWS	<ol style="list-style-type: none"> 1. Take to Commercial Car Wash. 2. Wash over lawn or dirt area. 3. If soap is used, use a bucket for soapy water and discharge remaining soapy water to sanitary sewer.
Mobile vehicle washing	<ol style="list-style-type: none"> 1. Collect washwater & discharge to sanitary sewer. 	POTW-MWS	
Rinsewater from dust removal at new car fleets	<ol style="list-style-type: none"> 1. Discharge to sanitary sewer. 2. If rinsing dust from exterior surfaces for appearance purposes, use no soap (water only); discharge to storm drain. 	POTW-MWS	

DISCHARGE/ACTIVITY	BUSINESS/COMMERCIAL Disposal Priorities	Approval	RESIDENTIAL Disposal Priorities
Vehicle Wastes (cont'd.)			
Vehicle leaks at Vehicle Repair Facilities	Follow this 3-step process: 1. Clean up leaks with rags or absorbents. 2. Sweep, using granular absorbent material (cat litter). 3. Mop and dispose of mopwater to sanitary sewer.		
Other Wastes			
Carpet cleaning solutions & other mobile washing services	1. Dispose to sanitary sewer.	POTW-MWS	1. Dispose to sanitary sewer.
Roof drains	1. If roof is contaminated with industrial waste products, discharge to sanitary sewer. 2. If no contamination is present, discharge to storm drain.		
Cooling water Air conditioning condensate	1. Recycle/reuse. 2. Discharge to sanitary sewer.	POTW-MWS	
Pumped groundwater, infiltration/foundation drainage (contaminated)	1. Recycle/reuse (landscaping, etc.) 2. Treat if necessary; discharge to sanitary sewer. 3. Treat and discharge to storm drain.	MDPW-NPDES POTW-MWS MDPW-NPDES	
Fire fighting flows	If contamination is present, Fire Dept. will attempt to prevent flow to stream or storm drain.		
Kitchen Grease	1. Provide secondary containment, collect, send to recycler. 2. Provide secondary containment, collect, send to POTW via hauler.	POTW-MWS	1. Collect, solidify, dispose as trash.
Restaurant cleaning of floor mats, exhaust filters, etc.	1. Clean inside building with discharge through grease trap to sanitary sewer. 2. Clean outside in container or bermed area with discharge to sanitary sewer.		
Clean-up wastewater from sewer back-up	1. Follow this procedure: a. Block storm drain, contain, collect, and return spilled material to the sanitary sewer. b. Block storm drain, rinse remaining material to collection point and pump to sanitary sewer (no rinsewater may flow to storm drain).		

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Good Housekeeping Practices (GHPs)	GHP-15
	Activity: Pesticides, Herbicides and Fertilizer Use (PHF)	
PLANNING CONSIDERATIONS: Training: No Inspection Frequency: Monthly Implementation Cost: Low Monthly Maintenance: Low		
	Target Pollutants	
	Significant ♦	Partial ♦
	Low or Unknown ◇	
	Sediment ◇ Heavy Metals ◇ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦ Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇	
Description	Fertilizers, herbicides and pesticides are potentially harmful chemicals that require safe and organized practices to assure that pollution does not enter into stormwater.	
Approach	<ul style="list-style-type: none"> ➤ For a quick reference on disposal alternatives for specific wastes, see the table presented in the Employee/Subcontractor Training BMP fact sheet, Table GHP-14-1, and MSDS. ➤ Contractors/subcontractors should develop controls on the application of pesticides, on-site. Controls may include: <ul style="list-style-type: none"> ▪ List of approved pesticides and selected uses ▪ Product and application information for users ▪ Equipment use and maintenance procedures ▪ Record keeping and public notice procedures ▪ MSDS <p>The following discussion provides some general information on good housekeeping:</p> <ul style="list-style-type: none"> ➤ Always use caution when handling any pesticide or fertilizer product. Many products contain toxic chemicals that can cause severe injury or death. ➤ Store pesticide or fertilizer products securely and away from children, pets, and sources of heat, sparks, and flames. ➤ Avoid contact with eyes and skin. Wear gloves and eye protection when using or handling hazardous substances. <u>Do not</u> wear contact lenses, which can absorb hazardous vapors. 	

Activity: Pesticides, Herbicides, and Fertilizer Use

GHP-15

**Approach
(cont'd)**

- Work in only well ventilated areas if handling these materials indoors.
- Use up the entire product before disposing the container.
- Do not dispose of pesticide or fertilizer wastes:
 1. in trash
 2. down storm drains or into creeks
 3. onto the ground
 4. by burning
- Do dispose of hazardous wastes at household hazardous waste collection events or facilities.

Maintenance

- Employee and subcontractor training,
- Contractor and subcontractor employees who handle potentially harmful materials should be trained in good housekeeping practices. Personnel who use pesticides must be trained in their use.
- The primary cost is for staff time as noted above.

**Inspection
Checklist**

- Fertilizers, herbicides and pesticides are properly stored.
- Fertilizers, herbicides and pesticides are clearly marked for easy identification.
- Old or used fertilizers, herbicides and pesticides have been properly disposed.
- Storage unit is properly ventilated.

**Approach
(cont'd)**

- Schedule construction activities to minimize exposed area by clearing only areas where phased construction is to take place.
- Quickly stabilize exposed soils using vegetation, mulching, spray-on adhesives, calcium chloride, sprinkling, and stone/gravel layering.
- Identify and stabilize key access points prior to commencement of construction. See [SMP-02](#) and [-03](#).
- Minimizing the impact of dust by anticipating the direction of prevailing winds.
- Direct most construction traffic to stabilized roadways within the project site.
- Dust control BMP's generally stabilize exposed surfaces and minimize activities that suspend or track dust particles. Table [GHP-16-1](#) shows which Dust Control BMPs apply to site conditions which cause dust. For heavily traveled and disturbed areas, wet suppression (watering), chemical dust suppression, gravel or asphalt surfacing, temporary gravel construction entrances, equipment wash-out areas, and haul truck covers can be employed as dust control applications. Permanent or temporary vegetation and mulching and sand fences can be employed for areas of occasional or no construction traffic.
- Preventive measures would include minimizing surface areas to be disturbed, limiting on-site vehicle traffic to 15 miles per hour, and controlling the number and activity of vehicles on a site at any given time.
- Pave, vegetate, or chemically stabilize access points where unpaved traffic surfaces adjoin paved roads.
- Provide covers for haul trucks transporting materials that contribute to dust.
- Provide for wet suppression or chemical stabilization of exposed soils.
- Provide for rapid clean-up of sediments deposited on paved roads. Furnish stabilized construction road entrances and vehicle wash down areas.
- Stabilize unpaved haul roads, parking and staging areas. Reduce speed and trips on unpaved roads.
- Implement dust control measures for material stockpiles.
- Prevent drainage of sediment-laden stormwater onto paved surfaces.
- Stabilize abandoned construction sites using vegetation or chemical stabilization methods.
- For the chemical stabilization, there are many products available for chemically stabilizing gravel roadways and stockpiles. The types of chemicals available and recommendations for their use are tabulated in [Table GHP-16-2](#), Commonly Used Chemicals for Dust Control.

Selection of Methods

Selection of dust control agents should be based primarily on cost-effectiveness and environmental hazards.

Chemical methods are dust suppressant or binding agents that are used on the soil surface to bind finer particles together. Chemical dust control agents must be environmentally benign, easily applied, easily maintained, economical and not significantly detrimental to traffic ability.

**Approach
(cont'd)**

Approximately three-quarters of chemical dust control agents are inorganic compounds which are compatible with soil and biota. After application, the compounds dampen and penetrate into the soil; a hygroscopic reaction pulls moisture from the atmosphere into the surface and adheres fines to aggregate surface particles. The compounds may not penetrate soil surfaces made up primarily of silt and clay, so soil tests are required.

Key factors in determining the method include the following:

- Soil types and surface materials - both fines and moisture content are key properties of surface materials.
- Properties of the agents - the five most important properties are penetration, evaporation, resistance to leaching, abrasion, and aging.
- Traffic volumes – the effectiveness and life span of dust control agents decreases as traffic increases. For high traffic areas, agents need to have strong penetrating and stabilizing capabilities.
- Climate – some hygroscopic agents lose their moisture-absorbing abilities with lower relative humidity, and some may lose resilience. Under rainy conditions, some agents may become slippery or even leach out of the soil.
- Environmental requirements – the primary environmental concern is the presence and concentration of heavy metals in the agent that may leach into the immediate ecosystem, depending on the soil properties.
- Frequencies of application – rates and frequencies of application are based on the type of agent selected, the degree of dust control required, sub grade conditions, surface type, traffic volumes, types of vehicles and their speeds, climate, and maintenance schedule.

Application of Methods

For dust control agents, once all factors have been considered, the untreated soil surface must first contain sufficient moisture to assist the agent in achieving uniform distribution (except when using a highly resinous adhesive agent). The following steps should be followed in general:

- Ideally, application should begin in late spring, after seasonal rains - not during or just before heavy rainfall- so that sub grade and surface materials will not have dried.
- If the surface has minimal natural moisture, the area to be protected must be pre-wetted so that the chemicals can uniformly penetrate the surface.
- In general, cooler and/or more humid periods result in decreased evaporation, increased surface moisture, and thus significant increase in control efficiency. However, chemical and organic agents should not be applied under frozen conditions, rainy conditions, or when the temperature is below 40° F. Tar and bitumen agents should not be applied in fog or in rain or below 55°F.
- More than one treatment with salts or organic compounds per year is often necessary, although the second treatment should probably be significantly diluted.

Maintenance

- Most dust control measures require frequent, often daily, attention.
- The primary maintenance requirement is the reapplication of the selected dust control agent at intervals appropriate to the agent type. High traffic areas shall be inspected on a daily basis, and lower traffic areas shall be inspected on a weekly basis.

**Inspection
Checklist**

- Water is applied daily to reduce dust.
- Trucks hauling soil or rock have dust covers over materials.
- Material stockpiles have fabric, mulch or ground cover to provide sediment control.

TABLE GHP-16-1 DUST CONTROL BMPs FOR GIVEN SITE CONDITIONS

DUST CONTROL BMPs									
SITE CONDITION	Permanent Vegetation	Mulching	Wet Suppression (Watering)	Chemical Dust Suppression	Gravel or Asphalt Surfacing	Silt or Sand Fences	Temporary Gravel Construction Entrances/ Equipment Wash Down	Haul Truck Covers	Minimize Extent of Area Disturbed
Disturbed Areas not Subject to Traffic	X	X	X	X	X				X
Disturbed Areas Subject to Traffic			X	X	X				X
Material Stock Pile Stabilization			X	X		X			X
Demolition			X				X	X	
Clearing/ Excavation			X	X					X
Truck Traffic on Unpaved Roads			X	X	X			X	
Mud/Dirt Carry-Out					X		X		

TABLE GHP-16-2 COMMONLY USED CHEMICALS FOR DUST CONTROL

	SALTS	ORGANIC, NON PETROLEUM-BASED	PETROLEUM BASED PRODUCTS ¹
CHEMICAL TYPES	<ul style="list-style-type: none"> · Magnesium Chloride · Natural Brines 	<ul style="list-style-type: none"> · Calcium Lignosulfonate · Sodium Lignosulfonate · Ammonium Lignosulfonate 	<ul style="list-style-type: none"> · Bunker Oil · Asphalt Primer · Emulsified Asphalt
LIMITATIONS	<p>Can lose effectiveness in dry periods with low humidity.</p> <p>Leaches from road in heavy rain.</p> <p>Not recommended for gravel road surfaces with low fines.</p> <p>Recommended 10-20% fines.</p>	<p>Not affected by dry weather and low humidity. Leached from road in heavy rain if not sufficiently cured.</p> <p>Best performance on gravel roads with high surface fines (10-30%) and dense compact surface with loose gravel.</p>	<p>Generally effective regardless of climatic conditions may pothole in wet weather.</p> <p>Best performance on gravel roads with 5-10% fines.</p>
COMMENTS	<p>Calcium Chloride is popular. May become slippery when wet on gravel surfaces with high fines.</p>	<p>Ineffective on gravel surfaces low in fines. May become slippery when wet on gravel surfaces with high fines content.</p>	<p>Creates a hardened crust.</p>

1 Motor oils and oil treatments are not recommended due to adverse effects on plant life and groundwater. They should only be applied in areas that will soon be paved.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Good Housekeeping Practices (GHPs)**

GHP-17

Activity: Maintenance of Collection Facilities and Appurtenances (MCF)

PLANNING CONSIDERATIONS:

Training:
Minimal

Inspection Frequency:
Monthly

Implementation Cost:
High

Monthly Maintenance:
High



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ♦ Nutrients ◇ Oxygen Demanding Substances ♦ Toxic Materials ◇
Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ◇

Description

The sediment sump in catch basins are designed to trap sediments below the overflow point or basin outlet. As sediment fills the sump, runoff enters the basin and immediately discharges through the outlet without depositing any sediment in the sump. Proper use of this practice will reduce high pollutant concentration during first flush of storms, prevent clogging of the downstream conveyance system and restore the catch basins' sediment trapping capacity. Proper maintenance and siltation removal is required to have an effective storm water pollutant removal system for both wet and dry detention ponds and infiltration devices.

Approach

- The catch basins must be regularly maintained. Clogged catch basins are not only useless but may act as a source of sediments and pollutants.
- Proper maintenance of detention ponds and infiltration device systems is a source control procedure necessary to ensure effective stormwater pollutant removal efficiency. Proper maintenance of these structures requires periodic silt/sediment and trash removal, as well as timely vegetation control. They should be cleaned out when it is recognized that they have filled from 1/5 to 1/3 of their pollutant (sediment) storage capacity.
- More frequent sediment removal is recommended, especially in areas where roadway drainage provides a significant runoff component. High accumulation rates of heavy metal contaminants (lead, zinc, and copper) have been identified in these BMP structures adjacent to high traffic areas. In order to avoid situations of hazardous waste disposal, sediment dredging and excavation should be given frequent priority.

Activity: Maintenance of Collection Facilities and Appurtenances

GHP-17

**Approach
(cont'd)**



- Clean catch basins in high pollutant load areas just before the wet season to remove sediments and debris accumulated during the summer.
- Catch basins should be inspected weekly and cleaned if necessary to reduce the possibility of sediment and other pollutants from leaving the construction site. This should be checked after all areas have been stabilized and at the end of the project.
- To prevent sediment and pollutant build-up in on-site catch basins, be sure to follow the guidelines set out in Temporary Inlet Protection, [SMP-11](#).
- Maintain a clean work site, free of litter that can build-up and clog catch basins and downstream conveyance systems.
- Discourage dumping into catch basins and stormwater inlets whenever possible.
- Removal of accumulated paper, trash, and debris should occur weekly or as needed to prevent clogging of control devices throughout the construction project.
- Vegetation growth in stormwater quality devices should not be allowed to exceed 24 inches in height.
- Mow the slopes periodically and check for clogging, erosion and tree growth on the embankment.
- Corrective maintenance may require more frequent attention (as required).
- Keep accurate maintenance logs to evaluate materials removed and improvements made.

Maintenance

- Maintenance crews may require access vehicles, dump trucks, bulldozers, and dredging/excavation equipment. Manual use equipment (such as rakes, shovels, sickles, and machetes) may suffice for maintenance of dry detention ponds and infiltration device systems. Staffing will require a minimum crew of two (2) properly trained person for health and safety reasons and effective structural BMP maintenance.
- Crews must be trained in proper maintenance, including record keeping and disposal.
- Appropriate excavation and maintenance procedures.
- Proper waste disposal procedures.
- Channel maintenance and use of heavy equipment.
- Identification and handling of hazardous materials/wastes.
- Application of this technique in "blue line" streams requires permits from the U.S. Army Corps of Engineers, and the Kentucky Division of Water
- Frequent sediment removal is labor and cost intensive.

**Inspection
Checklist**

- Dredged sludge is dried prior to removal to waste management facility. (See [GHP-01: Dewatering Operations](#).)
- All drainage activities are approved by Kentucky Division of Water (KDOW) and the local drainage authority.

	Madisonville, Kentucky Stormwater Best Management Practices (BMPs) Good Housekeeping Practices (GHPs)	GHP-18																		
Activity: Preservation and Maintenance of Existing Vegetation (PMV)																				
<p>PLANNING CONSIDERATIONS:</p> <p>Training: No</p> <p>Inspection Frequency: Prior to construction</p> <p>Implementation Cost: Low</p> <p>Monthly Maintenance: Low</p>																				
	<table border="1"> <thead> <tr> <th colspan="3">Target Pollutants</th> </tr> <tr> <th>Significant ♦</th> <th>Partial ♦</th> <th>Low or Unknown ◇</th> </tr> </thead> <tbody> <tr> <td>Sediment ♦</td> <td>Heavy Metals ◇</td> <td>Nutrients ♦</td> </tr> <tr> <td>Oxygen Demanding Substances ♦</td> <td>Toxic Materials ◇</td> <td></td> </tr> <tr> <td>Oil & Grease ◇</td> <td>Bacteria & Viruses ◇</td> <td>Floatable Materials ♦</td> </tr> <tr> <td></td> <td></td> <td>Construction Waste ◇</td> </tr> </tbody> </table>		Target Pollutants			Significant ♦	Partial ♦	Low or Unknown ◇	Sediment ♦	Heavy Metals ◇	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ◇		Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ♦			Construction Waste ◇
Target Pollutants																				
Significant ♦	Partial ♦	Low or Unknown ◇																		
Sediment ♦	Heavy Metals ◇	Nutrients ♦																		
Oxygen Demanding Substances ♦	Toxic Materials ◇																			
Oil & Grease ◇	Bacteria & Viruses ◇	Floatable Materials ♦																		
		Construction Waste ◇																		
<p>Description</p> <p>Suitable Applications</p> <p>Installation Procedures</p>	<p>The careful preservation of existing vegetation minimizes the potential of removing or injuring existing trees, vines, shrubs and/or grasses that serve as erosion controls or otherwise stabilize or slopes.</p> <p>This technique is applicable to all types of construction sites. Areas where preserving vegetation can be particularly beneficial are floodplain, buffers, wetlands, streambanks, steep slopes, and other areas where erosion control would be difficult to establish, install, and maintain, or areas where there are critical resources downstream.</p> <ul style="list-style-type: none"> ➤ Preservation of existing vegetation should be practiced in the following locations: ➤ Areas within site where construction activity is not permitted (such as buffers) or does not occur or occurs at a later date. ➤ Sensitive areas where natural vegetation exists and should be preserved, such as: steep slopes, watercourses, and building sites in wooded areas. ➤ Areas where local, state and federal government requires preservation, such as: vernal pools, wetlands, marshes, certain oak trees, etc. <ul style="list-style-type: none"> ➤ Preservation of vegetation on a site should be planned before any site disturbance begins. Preservation requires good site management to minimize the impact of construction activities on existing vegetation, which may adversely affect their respiration, food processing, and growth. ➤ During a pre-construction conference, vegetation preservation and protection measures for that project should be reviewed with the contractor and any subcontractors. 																			

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

Installation Procedures (cont'd)

Planning

The following planning steps should be taken to preserve existing vegetation:

- A plan for vegetation preservation should be completed before clearing and construction begins.
- Critical areas, such as floodplains, buffers, steep slopes, and wetlands should be left in their natural condition unless disturbance is unavoidable and permitted by buffer and floodplain/floodway requirements.
- Decisions on which vegetation to save should be based on the following considerations:
 1. Life expectancy and present age
 2. Health and disease susceptibility
 3. Structure
 4. Cleanliness
 5. Aesthetic values
 6. Comfort relative to site temperature variations and wind
 7. Wildlife benefits
 8. Adaptability to the proposed project
 9. Survival needs of the vegetation
 10. Relationship to other vegetation
- Areas for buffers where construction is not permitted should be delineated in the field with flags or colored temporary construction fencing.
- All vegetation to be retained should be delineated and identified (species and size) on the site plan and identified in the field by an easily seen colored flag.
- Plans should include the maintenance of existing grade around vegetation to be preserved. Most vegetation damage due to construction activities is to the root zone, which can result in the vegetation dying within a few years. Raising the grade can suffocate roots, and lowering the grade may expose roots.
- Plans for tree preservation should: avoid compaction of the soil within the drip line of a tree which can block off air and water from the roots and avoid changes in soil chemistry that can result from refuse of chemicals deposited on the soil surface.
- Temporary roadways should be located to minimize damage to shrub and tree stands, following contours to reduce cutting and filling.
- Locate multiple utilities in the same trench to minimize trenching. Excavations should be outside the drip line of trees.
- Construction material storage and crew parking should be noted on the site plan and located where they will not cause root compaction. They can eventually kill a tree.
- For retention of existing trees in paved areas, at least 5 ft. of ungraded ground beyond the drip line should be left to help ensure tree survival.
- Soil stabilization measures should be located at the limits of clearing to prevent sediment deposition within the area where vegetation is being preserved.
- Wind damage can result from exposure of vegetation to increased wind velocities, therefore this must be considered when removing adjacent vegetation.
- Equipment must be kept away from trees to be preserved to avoid trunk damage caused by equipment nicking or scarring the trunk.

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

Installation Procedures (cont'd)

Timing

The following timing considerations should be taken to preserve existing vegetation.

- Preservation of existing vegetation should be planned before any site disturbance begins. Preservation of existing vegetation should be planned during the design stages by the design engineer and the contractor should meet onsite with the design engineer.
- No vegetation should be destroyed or altered until the design of roads, buildings, and utility systems is finalized.

Tree and Vegetation Marking and Protection

- Clearing limits should be outside of the drip line of any retained tree, and at a minimum of 5 ft. from the trunk regardless of the size of the tree. A protective device, such as a colored temporary construction fence, to guard against damage to roots, trunk, and tops of trees, should be placed at these limits.
- Individual trees, stands of trees, and areas of vegetation to be retained should be marked before construction at a height visible to equipment operators. Orange-colored plastic construction fencing or other suitable material should be used. Within 40 ft. of a proposed building or excavation, however, retained trees should be protected by fencing. The following are alternatives for tree and vegetation protection:
 - Board fencing on 4-in. square posts set securely and 6 ft. apart, and protruding at least 4 ft. above the ground, placed at clearing limits.
 - A cord fence with 2 rows of cord at least 3 in. in thickness running between posts. Each post should be at least 2 in. thick set securely and 6 ft. apart, protruding at least 4 ft. above the ground placed at clearing limits. Strips of colored surveyor's flagging should be tied securely to the cord at intervals of no more than 3 ft.
 - Plastic fencing of 40 in. high orange polyethylene webbing, secured to metal "T" or "U" posts driven to a depth of at least 18 in., on 6 ft. minimum centers, placed at the clearing limits. The posts should be chemically inert to most chemicals and acids.
 - An earth berm constructed according to specifications, but only if its presence does not conflict with drainage patterns. The base of the berm on the tree or vegetation side should be located at the clearing limits.
 - Leaving a buffer zone of existing trees between the trunks of retained trees and the clearing limits. Trees in this buffer zone should be a maximum of 6 ft. apart so that equipment and material cannot pass. These trees should be re-examined before construction is completed to check for and ensure survival or be removed.
 - As a last resort, a tree trunk may be armored with burlap wrapping and 2-in. studs wired vertically, no more than 2 in. apart encircling the trunk to a height of 5 ft. No nailing should ever be done to a retained tree. The root zone, however, will still require protection.

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

Installation Procedures (cont'd)

- Employees and subcontractors should be instructed to honor protective devices. No heavy equipment, vehicular traffic, or storage piles of any construction materials should be permitted within the drip line of any tree to be retained. Removed trees should not be felled, pushed, or pulled into any retained trees. Fires should not be permitted within 100 ft. of the drip line of any retained trees. Any fires should be of limited size, and should be kept under continual surveillance. No toxic or construction materials including paint, acid, nails, gypsum board, chemicals, fuels, and lubricants should be stored within 50 ft. of the drip line of any retained trees, nor disposed of in any way which would injure vegetation. This also precludes vehicle fueling or maintenance in these areas.

Grade Protection

- If the ground level must be raised around an existing tree or tree group, a tree well can be constructed. A professional arborist should be consulted if a tree well appears to be warranted or desired. A well may be created around the tree slightly beyond the drip line to retain the natural soil in the area of the feeder roots.
- If the grade is being lowered, trees can be protected by constructing a surrounding tree wall of large stones, brick, or block, filled with topsoil. Fertilizer and water should be applied thoroughly and drainage provided so that water does not accumulate.
- Remove vegetation and organic matter from beneath the retained tree(s) to at least 3 ft. beyond the drip line, loosening the soil to at least 3 in. in depth without damaging roots.
- Apply fertilizer to the loosened soil at rates not to exceed those recommended by the fertilizer manufacturer.
- Construct a dry well to allow for trunk growth. Provide 12 in. between the trunk and the wall for older, slow-growing trees, and at least 24 in. for younger trees.
- The well should be just above the level of the proposed fill, and the wall should taper away from the trunk by 1 in./ft. of wall height.
- The well wall should be constructed of large stone, brick, building tile, concrete blocks, or cinder blocks, with openings left in the wall for the flow of air and water. Mortar should be used only near the top of the well and above the porous fill.
- Drain lines beginning at the lowest point inside the well should be built extending outward from the trunk in a radial pattern with the trunk as the hub. They should be made of 4-in. drain tiles, sloping away from the well at a rate of 0.125 in./ft. A circumferential line of tiles should be located beneath the drip line; vertical tiles or pipes should be placed over the intersections of the two tile systems for fills greater than 24 in. in depth, held in place with stone fill. All tile joints should be tight. Drainage may be improved by extending a few radial tiles beyond each intersection and slope sharply downward. Coarse gravel may be substituted for tile in areas where water drainage is not a problem. Stones, crushed rock, and gravel may be added instead of vertical tiles or pipes, so the upper level of these porous materials slopes toward the surface near the drip line.
- Tar paper or an approved equivalent should be placed over the tile or pipe joint to prevent clogging, and a large stone placed around and over drain tiles or pipes for protection.

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

Installation Procedures (cont'd)

- Layer 2 in. to 6 in. of stone over the entire area under the tree from the well outward at least to the drip line. For fills up to 24 in. deep, a layer 8 in. to 12 in. should be adequate. Deeper fills require thicker layers of stone to be built to a maximum of 30 in.
- A layer of 0.75-in. to 1-in. stone covered by straw, fiberglass mat, or filter fabric should be used to prevent soil clogging between stones. Do not use cinders as fill material.
- Complete filling with porous soil (to sustain vegetation) until the desired grade is reached.
- Crushed stone should be placed inside the dry well over the openings of the radial tiles to prevent clogging of the drain lines. Vertical tiles should also be filled with crushed rock and covered with a screen.
- The area between the trunk and the well wall should be covered by an iron grate or filled with a 1:1 mixture of crushed charcoal and sand to prevent anyone from falling into the well or to prevent leaves, debris, rodents, or mosquitoes from accumulating.
- One-half of these systems may be constructed if the grade is being raised on only one side of the tree(s).

Trenching and Tunneling

- Trenching should be as far away from tree trunks as possible, usually outside of the tree crown. Curve trenches around trees to avoid large roots or root concentrations. If roots are encountered, consider tunneling under them. When trenching and/or tunneling proximate to trees to be retained, tunnels should be at least 18 in. below the ground surface, and not below the tree center to minimize impact on the roots.
- Tree roots should not be left exposed to air; they should be covered with soil as soon as possible, protected, and kept moistened with wet burlap or peat moss until the tunnel and/or trench can be completed.
- The ends of damaged or cut roots should be cut off smoothly and protected by painting them with a tree-wound dressing.
- Trenches and tunnels should be filled as soon as possible. Careful filling and tamping will eliminate air spaces in the soil, which can damage roots. Be careful not to over-compact as this can smother and kill the tree.
- To induce and develop root growth, peat moss should be added to the fill material.
- The tree should be mulched to conserve moisture and fertilized to stimulate new root growth.
- Remove any trees intended for preservation if those trees are damaged seriously enough to affect their survival. If replacement is desired or required, the new tree should be of similar species and of at least 2-in. caliper balled and burlapped nursery stock, unless otherwise required by the contract documents.
- Because protected trees may be destroyed by carelessness during the final cleanup and landscaping, fences and barriers should be removed last, after all other work is complete.

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

Installation Procedures (cont'd)

Vegetation Control

- Mechanical control of vegetation includes mowing, "bush-hogging", and hand cutting. Large scale mowing is typically done by tractor-type mowers similar to farm machinery. "Bush-hogging" usually refers to tractor mounted mowing equipment with hydraulically mounted cutting machinery. On smaller areas, lawn tractors or push mowers may be used. In areas that are inaccessible by machinery, such as steep grades and rocky terrain, hand cutting using gas powered weed trimmers and scythes may be used.
- Clippings and cuttings are the primary waste produced by mowing and trimming. Clippings and cuttings are almost exclusively leaf and woody materials. Minimize transportation of clippings and cuttings into the stormwater conveyance system. Compost piles are encouraged to create mulch and topsoil for landscaping.
- Clippings/cuttings carried into the stormwater system and receiving streams can degrade water quality in several ways. Suspended solids will increase causing turbidity problems. Since most of the constituents are organic, the biological oxygen demand will increase causing a lowering of the available oxygen to animal life. In areas where litter and other solid waste pollution exists, toxic materials may be released into receiving streams with a resulting degradation of water quality.
- Mowing should be performed at optimal times (e.g., when it is dry). Mowing should not be performed if significant rain events are predicted.
- Mulching mowers may be recommended for certain areas. Mulching mowers should be encouraged for homeowners in flat areas. Mulching mowers have the added benefit of reducing the fertilizer demand through reuse of organic material. Other techniques may be employed to minimize mowing such as selective vegetative planting using low maintenance grasses and shrubs. Alternatively, the grass clippings can be bagged and used in composting.

Maintenance

- During construction, the limits of disturbance should remain clearly marked at all times. Irrigation or maintenance of existing vegetation should conform to the requirements in the landscaping plan.
 - If damage to protected trees still occurs, maintenance guidelines described below should be followed:
 - Soil, which has been compacted over a tree's root zone, should be aerated by punching holes 12 in. deep with an iron bar, and moving the bar back and forth until the soil is loosened. Holes should be placed 18 in. apart throughout the area of compacted soil under the tree crown.
- Any damage to the crown, trunk, or root system of a retained tree should be repaired immediately.
- Damaged roots should be immediately cut cleanly inside the exposed area and surfaces painted with approved tree paint, and moist soil or soil amendments should be spread over this area.
 - If bark damage occurs, all loosened bark should be cut back into the undamaged area, with the cut tapered at the top and bottom, and drainage provided at the base of the wound. Cutting of the undamaged area should be as limited as is possible.
 - Serious tree injuries should be attended to by an arborist, forester or tree specialist.
 - Stressed or damaged broadleaf trees should be fertilized to aid recovery.

Activity: Preservation and Maintenance of Existing Vegetation

GHP-18

**Maintenance
(cont'd)**

- Trees should be fertilized in the late fall or early spring.
- Fertilizer should be applied to the soil over the roots and in accordance with label instructions, but never closer than 3 ft. to the trunk. The fertilized area should be increased by one-fourth of the crown area for conifers that have extended root systems.

**Inspection
Checklist**

- Protecting existing vegetation requires detailed planning, and may constrict the area available for construction activities.
- It is appropriate to evaluate the existing vegetation for species type for use in landscaping plans. Natural vegetation and invasive or "alien" species should be delineated. The use of natural vegetation is preferred.

**Approach
(cont'd)**

The following list of non-stormwater discharges are allowable:

1. Water line flushing.
2. Landscape irrigation.
3. Diversion of stream flows or rising groundwater.
4. Infiltration of uncontaminated groundwater, as defined at 40 CFR 35.2005(20), to separate storm drains.
5. Pumping of uncontaminated groundwater.
6. Discharges from potable water sources, foundation drains, air conditioning condensate, irrigation waters, springs, water from crawl space pumps, or footing drains.
7. Lawn watering.
8. Individual noncommercial car washing on residential property; or car washing of less than two consecutive days in duration for a charity, nonprofit fund raising or similar noncommercial purpose.
9. Flows from riparian habitats and wetlands.
10. Dechlorinated swimming pool discharges.
11. Incidental street washing water from street cleaning equipment designed for cleaning paved surfaces and limiting waste discharges.
12. Street deicing for public safety.
13. Any flows that result from firefighting.
14. Any activity authorized by a valid NPDES permit.

The following non-stormwater discharges are explicitly prohibited by the Madisonville Stormwater Ordinance. The list of prohibited discharges is not all-inclusive, as any type of discharge not specifically exempted (see list of items above) is prohibited. In other words, these are only the more commonly observed violations.

- Raw sewage discharges or overflows, including sanitary sewer overflows (SSOs).
- Discharges of wash water from the hosing or cleaning of gasoline stations, auto repair garages, or other types of automotive service facilities.
- Discharges resulting from the cleaning, repair, or maintenance of any type of equipment, machinery, or facility (includes motor vehicles, cement-related construction equipment, portable toilet servicing, etc.)
- Discharges of wash water from mobile operations such as steam cleaning, power washing, pressure washing, carpet cleaning, and mobile carwash facilities.
- Discharges of wash water from the cleaning or hosing of impervious surfaces in industrial and commercial areas including parking lots, streets, sidewalks, driveways, patios, plazas, work yards, and outdoor eating or drinking areas.
- Discharges of runoff from material storage areas containing chemicals, fuels, grease, oil or hazardous materials.
- Discharges of pool or fountain water containing chlorine, biocides or other chemicals, and also discharges of pool or fountain filter backwash water.
- Discharges of water containing sediment or construction-related wastes.
- Discharges of food-related wastes such as grease, oil, fish processing water, kitchen mat wash water, trash bin wash water, pouring liquids into dumpsters, etc. This includes disposing unwanted food or liquid into ditches, creeks or streams.

Activity: Vehicle Washing

RHP-02

Prohibition to Discharge

Due to federal mandates, the City of Madisonville has adopted a Stormwater Ordinance to prohibit discharge of chemicals and manmade materials into creeks, streams, ditches, swales, pipes, storm drains, and parts of the city drainage system. See the BMP entitled [RHP-01](#), Non-Stormwater Discharges to Storm Drains, for a complete list of allowable discharges; anything else is strictly prohibited. This prohibition includes all types of automotive fluids, whether discharged directly into a stream or storm drain, or discharged indirectly upon the ground surface. In addition to fines and legal action from the City of Madisonville, the state government Kentucky Division of Water (KDOW) can also assess penalties for polluting waters of the state (defined as any blue-line stream on a USGS quadrangle topographic map) or any storm drainage system that leads to waters of the state.

Vehicle Washing

It is legal to discharge water when washing individual cars on residential property. This is one of the allowable discharges listed in [RHP-01](#) (Non-Stormwater Discharges to Storm Drains) and in the City of Madisonville Stormwater Ordinance. It is also legal to discharge water when holding a carwash event over a period of two days or less, for the purpose of charity, nonprofit fundraising, or similar noncommercial purpose. However, it is illegal to discharge washwater or rinsewater that adversely affects the water quality of a creek or stream, even if otherwise allowable according to ordinance.

Residents should attempt to minimize the amount of detergents that are used in washwater. Extremely dirty or grimy vehicles should generally be cleaned at a commercial carwash, which is required to treat all washwater and rinsewater to certain standards.

A carwash or commercial vehicle washing facility is strictly prohibited from discharging water into streams, creeks, ditches, pipes, culverts or storm drains. This includes, but is not limited to: automobile dealers, automotive repair shops, industrial or commercial plants with vehicle washing stations, construction sites, or any location that is not a personal residence.

City and County residents may want to wash vehicles on lawns or other pervious ground surfaces, or at least direct the discharge of washwater and rinsewater into grassy areas. Avoid discharging large amounts of chlorinated city water directly to storm drains or streams. Reduce the amount of chlorinated water by turning off the hose when not needed. Relatively small amounts of chlorinated water can be toxic to the fish and other aquatic organisms, especially during dry weather.

Detergents affect the gill membranes of fish and adversely affect other aquatic life. Minimize the use of detergents, and dispose of soapy water indoors in a sink or drain. Even phosphate-free, biodegradable soaps have been shown to be toxic to fish before the soap degrades. Avoid the use of solvents and other toxic chemicals.

Do not wash engines, undercarriages, transmissions or automotive parts near streams, creeks, storm drains, ditches, or impervious surfaces such as driveways and streets. Carefully control and dispose of engine washwater in a manner that does not pollute Madisonville and Hopkins County streams or the environment. Dirty engines and undercarriages should generally be cleaned at well-equipped commercial facilities to prevent pollution.

Related BMPs

Consult the following list of related BMPs for disposal options and other guidance:

- [GHP-11](#) Vehicle and Equipment Washing
- [RHP-01](#) Non-Stormwater Discharges to Storm Drains
- [RHP-03](#) Vehicle Maintenance and Repair



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Residential and Homeowners (RHPs)**

RHP-03

Activity: Vehicle Maintenance and Repairs



Target Pollutants

Significant ♦

Partial ♦

Low or Unknown ♦

Sediment ♦ Heavy Metals ♦ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦
Oil & Grease ♦ Bacteria & Viruses ♦ Floatable Materials ♦ Construction Waste ♦

Description

Pollutants and automotive fluids should be prevented from accumulating on impervious surfaces in order to improve stormwater quality and protect natural streams and creeks.

Approach

Personal vehicles (cars, trucks, vans, motorcycles) have a high potential for polluting streets, grassy areas, streams, creeks, and the air that we breathe.

- Vehicles contain large amounts of fluids that could leak slowly from the engine, or may escape from a ruptured hose. Fluids such as engine oil, transmission fluid, radiator coolant, battery acids, and brake fluid all have special properties due to their chemical formulation. All of these fluids are poisonous to plants, trees, insects, wildlife, fish, etc. and must be reduced or eliminated as much as possible. Repair automotive leaks immediately.
- Incomplete combustion of gasoline and diesel fuels is a major contributor to air pollution. There is a high level of concern in state and federal governments for air quality and ozone levels throughout the country. Please keep personal vehicles in good condition to reduce air pollution. The Commonwealth of Kentucky currently does not require statewide vehicle inspections or emission testing.
- Vehicles contain moving parts that wear down, such as tires and brake pads. Brakes and brake pads are designed purposely to erode and grind in a way to minimize vehicle maintenance. Small pieces of tires and brake pads (containing asbestos and metals) are continually being deposited on streets and roadways.

Activity: Vehicle Maintenance and Repairs**RHP-03****Installation Procedures**

- Due to federal mandates, the City of Madisonville has adopted a Stormwater Ordinance to prohibit discharge of chemicals and manmade materials into creeks, streams, ditches, swales, pipes, storm drains, and any surface which drains into these waterways. See the BMP entitled [RHP-01](#) (Non-Stormwater Discharges to Storm Drains) for a list of allowable discharges; anything else is strictly prohibited.
- One category of prohibited discharges included all automotive fluids, whether discharged directly into a stream or storm drain, or discharged indirectly upon the ground so that the automotive fluid could wash away as stormwater runoff at a later time. In addition to fines and legal action from the City of Madisonville, the Kentucky Division of Water (KDOW) can also assess severe penalties for polluting waters of the state (defined as any blue-line stream on a USGS quadrangle topographic map) or any storm drainage system.
- It is also illegal to discharge automotive fluids into a sinkhole, or to allow these fluids to soak into the ground. Sinkholes and known areas of groundwater recharge are also included as waters of the state, for which the KDOW, the City of Madisonville will assess penalties and take legal actions.

Disposal Options

- Automotive parts stores and repair shops will typically accept engine oil and other fluids for recycling. Ask about recycling when you purchase automotive parts and fluids.

Vehicle Repairs

- It is recommended that most city residents should take advantage of commercial repair shops and oil-change facilities. Home repair and maintenance may be performed if the homeowner/resident has adequate knowledge of materials to control spills and leaks, and proper safeguards to properly protect natural streams, storm drains, drainage ditches and the environment in general.
- Purchase the correct automobile parts when making repairs or performing regular vehicle maintenance. Consult automotive repair manuals in order to perform the work quickly and efficiently. Use a funnel whenever pouring liquids such as motor oil, brake fluid or coolant. Drain hoses prior to removing or adjusting them; in most cases the liquid can be reused. Drain pans and drop cloths are essential items when changing oil or other automotive fluids. In general, use dry methods such as rags and absorbent material (kitty litter) to clean spills and leaks. Do not wash spills onto the ground or any surface that drains to the city stormwater drainage system or to natural creeks and streams. Sweep or mop any spills or leaks promptly. Keep spill containment materials nearby.
- Use non-toxic materials when possible. For instance, baking soda is used for cleaning battery terminals and clamps. Do not mix used motor oil with solvents. Do not mix chlorinated solvents with non-chlorinated solvents such as kerosene or mineral spirits.

Maintenance

The following GHP (Good Housekeeping Practices) BMPs are applicable to everyone who operates or maintains a vehicle such as businesses, industries, homeowners, automotive dealers, repair shops and garages, etc. They contain many specific requirements and guidelines for care and maintenance of vehicles.


- [GHP-05](#) Spill Prevention and Control
- [GHP-12](#) Vehicle and Equipment Fueling
- [GHP-13](#) Vehicle and Equipment Maintenance



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Residential and Homeowners (RHPs)**

RHP-04

Activity: Landscape Irrigation and Lawn Watering



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ◇ Heavy Metals ◇ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ♦
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ◇ Construction Waste ◇

Description

Prevent or reduce the discharge of pollutants from sprinklers and landscaping water in order to protect natural streams and creeks. Runoff is reduced by decreasing the flow rate, applying water in a more controlled manner, and by closely monitoring sprinklers.

Approach

During dry summer months in the City of Madisonville area, it is not unusual to go a few weeks without rainfall. Many homes and businesses determine that watering lawns and other vegetation is a necessity. In addition to lawns and trees, water is needed for golf courses, flower and vegetable gardens, nurseries and landscaped parking lot islands.

Pollution occurs when landscaping water produces runoff to the storm drainage system. Typical pollutants include herbicides, pesticides, fertilizers, pet/animal waste and mulch. In addition, most watering is done with chlorinated utility water. Chlorinated water must not be discharged to Madisonville natural creeks, streams, because it kills aquatic life. Runoff from several over watered lawns will kill fish and other aquatic organisms in a small creek. Over watering is more likely to occur during the dry summer periods, which is when streams have lower flows and the chlorine dosages have more effect.

Due to federal mandates, the City of Madisonville adopted the Stormwater Ordinance to prohibit all discharges of chemicals, manmade materials and soils (see [RHP-01](#), Non-Stormwater Discharges to Storm Drains) into streets, ditches, storm drains, and natural streams. This prohibition includes chlorinated water, any soil or mulch, chemicals such as fertilizers and pesticides, and nutrients such as fertilizer and lime. In addition to being toxic, these substances also change the pH and turbidity of natural streams and creeks. Damage from toxic materials is not necessarily immediate but can take months or years to accumulate.

Activity: Landscape Irrigation and Lawn Watering

RHP-04

- | | |
|---------------------|---|
| Guidelines | <ul style="list-style-type: none">➤ Avoid discharging water onto impermeable surfaces such as paved driveways, roads and parking lots. Direct water onto soil and lawns by using a correctly sized sprinkler with the right spray pattern.➤ Lower the flow rate and increase watering time as necessary to avoid discharging water to the stormwater drainage system. Excess water damages the lawn or landscaped area by washing away the nutrients and soil.➤ Monitor watering activities and correct as necessary. Stop watering as soon as runoff leaves the landscaped area, which indicates saturated conditions.➤ Do not leave watering sprinkling activities unattended. Watering will be effective for a few hours, but the ground usually becomes saturated by nightfall. Afterwards, the sprinklers become ineffective and most of the chlorinated water goes directly to the stormwater drainage system.➤ Use herbicides, pesticides and fertilizers in accordance with manufacturer's instructions. Excessive use of these hazardous materials can be toxic to vegetation and wildlife in and near natural streams and creeks. Herbicides and pesticides should be applied after rainfall or watering occurs, and a dry period of a few days is expected. Fertilizer and lime may be applied prior to light watering.➤ Construct a small berm, depression area or curb on the lower side of landscaped areas. Minor grading modifications will allow excess water to collect and soak into the soil, instead of being wasted in the storm drains. Use native trees and shrubs when possible; native vegetation is usually more resistant to drought than ornamental trees.➤ If possible, avoid using chlorinated water for landscaping. Use rain barrels, cisterns, ponds or other methods for capturing stormwater. Or, allow chlorinated water to stand in an open container for a day or so, prior to being used for landscaping irrigation. Chlorine naturally escapes from chlorinated water as a gas, at a rate that is subject to temperature, sunshine and wind conditions. A simple swimming pool test kit can be used to detect chlorine. Once the dechlorination time has been established, further use of the chlorine test kit is usually not needed. |
| Maintenance | <ul style="list-style-type: none">➤ Monitor watering operations closely. Adjust watering rates and patterns to avoid runoff to storm drainage systems, curb inlets, ditches, natural creeks and streams, ponds, wetlands, etc. Repair damaged or incorrectly installed sprinklers. Repair leaking hoses and valves. |
| Limitations | <ul style="list-style-type: none">➤ Extra effort and attention is required to monitor landscape watering. Sprinklers and other equipment should have the correct size and configuration to accomplish the intended purpose without excessive watering.➤ Berms, curbs or other grading modifications will require additional space for ponding water. Berms and grading modifications may affect the symmetry of landscape designs in very minor ways. |
| Related BMPs | <p>Other topics and aspects of landscape irrigation and lawn watering are included in these related BMPs:</p> <ul style="list-style-type: none">➤ GHP-14 Employee / Subcontractor Training➤ GHP-15 Pesticides, Herbicides, and Fertilizer Use➤ EPP-10 Mulching➤ RHP-01 Non-Stormwater Discharges to Storm Drains |

**Approach
(cont'd)****Fertilizers**

- Do not apply fertilizer when immediate rainfall is expected. Apply fertilizer only when there is already adequate soil moisture and little likelihood of immediate heavy rainfall. After applying fertilizer, lightly sprinkle the lawn or garden. A soil test is recommended to determine the optimum lime and fertilizer application rates.

Pesticides and Herbicides

- Excessive application and misuse of pesticides and herbicides results in heavily polluted stormwater runoff. Avoid using pesticides and herbicides when immediate rainfall is expected. Apply pesticides and herbicides in a narrow rather than wide band; do not broadcast them over the entire lawn area. Spot-spray infested areas. Never apply pesticides and herbicides near streams, creeks, ditches, storm drains or on impervious surfaces.
- Examine all alternatives to pesticides and herbicides that, in the long term, may be much less costly than the use of a particular chemical. Use the least toxic chemical pesticide or herbicide that will accomplish the purpose. Pesticides and herbicides that degrade rapidly are less likely to become stormwater runoff pollutants. Use pesticides and herbicides with low water solubility. Granular formulations are generally preferable to liquids because application losses are lower.
- Pesticides and herbicides should be sprayed only when wind speeds are less than 7 mph. Spray in the early morning or at dusk when wind speeds are usually lowest. Air temperature should range between 40° – 80° F.

Pesticide and Herbicide Types

- Dusts: This type is highly susceptible to wind drift, not only when being applied but also after reaching target. The application should be performed during the early morning or late evening hours when there is little or no air movement. The distance between the application equipment and the target should be minimized.
- Sprays: This type may be in the form of solutions, emulsions, or suspensions. Droplet size is an important factor in determining susceptibility to wind drift. Large droplets fall faster and are less likely to contaminate non-target areas. Sprays should be applied during periods of low air movement. Ground sprays followed by soil incorporation are not likely to be sources of water pollution unless excessive erosion occurs.
- Granular formulations: This type is applied to either the ground surface or below the soil surface. Surface applications may or may not be followed by soil incorporation. Pollution of surface waters from granular formulations is unlikely unless heavy runoff or erosion occurs soon after treatment. However, groundwater pollution may result from excessive leaching due to rainfall after application, depending on the pesticide composition. Loss of granular formulations can be controlled for the most part with adequate soil conservation practices.
- Fumigants: This type must be kept in place for specific lengths of time in order to be effective. Containment methods include soil compaction, water seal, and sealing of the area with a plastic cover. Most fumigants act rapidly and degrade quickly. Consequently, water pollution is usually not a problem.

**Approach
(cont'd)**

- Antimicrobial paints and other surface coatings: This type is designed to resist weathering and is therefore not a likely source of pollution. Empty containers should be disposed in accordance with rules for all pesticide containers. Use extreme care when sanding or scraping surfaces that have been previously treated with these substances. Treat sanded and scraped residue as hazardous waste.
- Pre-plant treatments: Seed, roots, tubers, etc., are frequently treated with pesticides prior to planting. Treatment is usually by dust, slurry, or liquids. Little pollution hazard exists from this application. Care must be taken, however, in disposing of residual treatment materials and with unused plants.
- Organic pesticides: A wide variety of organic pesticides, produced from plants, bacteria, and other naturally-occurring substances, are available in quantities for both commercial and residential use. These substances usually present much less risk for contamination of groundwater and surface water, and much fewer problems for disposal of leftover product or containers.
- Beneficial insects: This management method involves the use of insects in bulk or in amounts suitable for residential use. It can be used alone or in combination with other pesticides to eliminate or minimize the use of toxic substances.

Good Housekeeping and Safety

- Always use caution when handling any pesticide, herbicide, or fertilizer product. Many products contain toxic chemicals that cause severe injury or death. Keep pesticide or fertilizer products securely in containers protected from stormwater and away from children, pets, and sources of heat, sparks, and flames. Store products in their original containers and keep well-labeled. Do not store chemicals in food containers.
- Read and follow use instructions provided on packaging, and in material safety data sheets (MSDS) if available. Periodically review for handling pesticides, herbicides, or fertilizers. Work only in well-ventilated areas. Avoid contact with eyes and skin. Wear gloves and eye protection when using or handling hazardous substances. Do not wear contact lenses, which can absorb hazardous vapors.

**Disposal
Options**

- Hazardous wastes accepted by the Sanitation Department's Recycling Center include vehicle batteries and used motor oil. The City does not have a separate disposal site for pesticides, fertilizers, or other hazardous wastes. Contact the City of Madisonville Sanitation Department for more information at (270) 824-2117 or visit their website at www.madisonvillegov.com/sanitation.
- In general, use the entire product according to package directions before disposing the container. However, do not overapply the product if it is not needed. Do not dispose of pesticide or fertilizer wastes in any of the following methods:
 - Into trash or waste containers
 - Into storm drains or into creeks
 - Onto the ground
 - By burning

Maintenance

These related BMPs also provide guidance on the correct use and disposal of fertilizers and pesticides:

- [GHP-06](#) Waste Management
- [GHP-15](#) Pesticides, Herbicides, and Fertilizer Use

Activity: Household Hazardous Wastes**RHP-06****Prohibition to Discharge**

Due to federal mandates, the City of Madisonville has adopted a Stormwater Ordinance to prohibit discharge of all chemicals and manmade materials into creeks, streams, ditches, swales, pipes, storm drains, and any surface that drains into these waterways. See BMP [RHP-01](#) (Non-Stormwater Discharges to Storm Drains) for a list of allowable discharges; anything else is strictly prohibited. This prohibition includes all types of fluids, whether discharged directly into a stream or storm drain, or discharged indirectly upon the ground. In addition to fines and legal action from the City of Madisonville, the state government Kentucky Division of Water (KDOW) can also assess severe penalties for polluting waters of the state (defined as any blue-line stream on a United States Geological Survey (USGS) quadrangle topographic map), which also includes sinkholes and known areas of groundwater recharge.

Disposal Options

A household hazardous waste is any substance that is toxic, poisonous, corrosive, chemically reactive, flammable or combustible. The typical home contains many hazardous chemicals commonly used for cleaning, repairs, construction, automobile maintenance, lawn care, or hobbies. Oftentimes, household hazardous waste will accumulate on shelves in the garage or basement. The following items are not accepted at the Madisonville Sanitation Department and Recycling Center:

- Ammunition and explosives
- Medical waste
- Radioactive waste
- Unidentified materials

Whenever possible, purchase nontoxic, biodegradable products. Alternatively, use natural cleaning solutions such as vinegar or lye soap. Always follow the directions on the product label, and clean up any spills immediately. In general, do not purchase more of a hazardous product than can be reasonably used.

Recycling

The City of Madisonville Recycling Program, initiated in 1993, provides a municipally owned and operated drop-off recycling center for City residents. The Recycling Center accepts glass, cans, plastics, paper, and household hazardous wastes: vehicle batteries and used motor oil. Participation in the recycling program is encouraged by the City. The Recycling Center is located at 900 McCoy Avenue. Additional information about recyclable items, hours of operation, location, and drop-off are available on the Sanitation Department website: www.madisonvillegov.com/sanitation.htm. To receive more information about recycling, please contact the Madisonville Sanitation Department at (270) 824-2117 or fax, (270) 824-2174.

Related BMPs

These BMPs have additional information about waste disposal and alternatives:

- [GHP-05](#) Spill Prevention and Control
- [RHP-01](#) Non-Stormwater Discharges to Storm Drains

References

- www.madisonvillegov.com
- www.madisonvillegov.com/sanitation.htm
- www.amlegal.com/madisonville_ky/

**Sanitary
Laterals**

At a minimum, property owners should be aware of where sanitary sewer laterals are found on the property. Do not allow heavy vehicles or construction equipment to drive on top of sanitary sewer laterals. Do not plant large trees directly over or near to sanitary sewer laterals. Large tree roots can infiltrate and eventually break a sanitary sewer lateral so that it will not function.

Inspection and Investigation


- The following guidelines are helpful for inspecting and maintaining sanitary sewer laterals. These guidelines will help the property owner to protect a valuable utility asset, and will help to improve water quality in Madisonville creeks and streams.
 - Find location of sanitary sewer laterals on the property.
 - Find location of sanitary sewer lateral connection to the main sewer.
 - Determine approximate date of construction and materials used.
 - Inspect lateral locations regularly for unusual odor or ground wetness.
 - Inspect lateral locations regularly for subsidence or unusual soil color.
- A leaking sanitary sewer lateral may be contributing flow to a nearby storm drain, ditch or creek. Inspect the nearest storm drain or ditch during dry weather to determine if there is a suspicious flow. Contact the Madisonville Wastewater Collection Department at (270) 821-3717 to report illicit discharges, spills, leaks, or suspicious sanitary sewer discharges that need to be investigated. Anonymous calls are also handled. Calls after hours will be automatically transferred to the City Emergency and After Hours line for assistance. More information about the Wastewater Collection Department can be found on their website, www.madisonvillegov.com/wwcollection.htm.

Other Considerations

- All temporary and permanent connections to the municipal sanitary sewer system must be inspected and approved by a MMU plumbing inspector prior to installation. Contact the Inspections Office for construction procedures and testing requirements. Only use licensed plumbing contractors with adequate experience and equipment for each project.
- Older houses throughout the City of Madisonville may have illicit connections, where a sanitary sewer line discharges into a storm drain. There are many reasons that this may have occurred, including:
 - Standard practice 50 to 100 years ago, where sanitary sewers did not exist.
 - A building contractor may have misidentified the connection pipe honestly.
 - A building contractor may have taken a shortcut to save time & money.
 - The storm drain contractor may have misidentified the sanitary sewer pipe.

Sanitary Laterals (cont'd)

- When found, cross connections must be replaced and repaired to function correctly. See [RHP-01 \(Non-Stormwater Discharges to Storm Drains\)](#) for additional information on locating illicit discharges and cross connections. Smoke testing and dye testing are two common methods for MMU Wastewater Department to locate leaks in the main sanitary sewer system. More information about smoke testing can be found on the Wastewater Collection website, at: www.madisonvillegov.com/wwcoll/smoke_testing.htm
- Roof drains for older houses typically are connected to the sanitary sewer system (standard practice 50 years ago). Current standard procedures for roof drainage call for roof drains and gutters to be disconnected from the sanitary sewer system. Roof drainage is relatively clean water that is discharged directly onto the ground.



Septic Tank Systems

- Existing privately-owned septic systems must be maintained in good working order. If a private septic system fails to function properly, then the owner may be required to hook into the municipal sanitary sewer system at their cost. Typically a septic tank needs to be inspected every year and pumped out every three years.
- Septic systems are not designed to process large volumes of water in short time periods. Do not wash several loads of clothes consecutively, and do not use excessive amounts of detergents that contain phosphorus. Do not pour household chemicals down the drain into a septic system; chemicals can kill the good microbes within the septic tank. Garbage disposals contribute to an overloading of solids in the septic tank, requiring more frequent cleanouts.
- Keep heavy equipment and vehicles away from septic tank and septic drain field. Do not compact soils in the septic field. Do not pave over the septic drain field. Adequate aeration and evaporation in drain field must occur for proper treatment.
- Inspect the septic tank and septic drainfield regularly to verify that sanitary and septic waste is not being discharged inadvertently. Inspection is normally done during dry weather to determine whether a discharge occurs. See [RHP-01 \(Non-Stormwater Discharges to Storm Drains\)](#) for methods to detect illicit discharges and leaks. Look for unusual odors, wet ground, discolored soil, subsidence or unusual settlement.

Activity: Sanitary Sewer Laterals & Septic Tanks

RHP-07

**Safety
Concerns**

- Be careful investigating sanitary sewer lines or other confined spaces where sewer gases may exist. Sanitary sewer gases can render a person unconscious before being detected by normal senses. There are many instances of people being killed by falling unconscious into an open manhole due to sewer gases.
- Methane gas, along with other sewer gases, is very explosive. Keep sparks and open flames away from sewers, manholes and septic tanks. Do not smoke near open manholes.

Related BMPs

- [GHP-10](#) Sanitary and Septic Waste Management
- [RHP-01](#) Non-Stormwater Discharges to Storm Drains

Guidelines**Pets**

- Pets can be a very significant source of fecal coliform. A 1982 study of urban watersheds in Baltimore MD found that dog feces were the single greatest contributor of fecal coliform and fecal strep bacteria (reference 190). A single gram of dog feces can contain 23 million fecal coliform bacteria (reference 199). Dogs can also be hosts for Giardia and Salmonella, two common types of harmful bacteria (reference 191).
- Provide a buffer zone and/or a fence to prevent animals from urinating or defecating into a creek, stream, or other stormwater drainage feature. Do not keep pets immediately adjacent to ditches, swales, storm drains, pipes or culverts.
- Clean up yards or fields that contain pet wastes on a regular basis. Animal waste can be sent to the sanitary landfill as part of the regular weekly garbage pickup. Burying animal waste in the ground is also an acceptable option, away from ditches or stormwater channels.
- Cat litter can be sent to the sanitary landfill as part of the regular weekly garbage pickup. Burying cat litter in the ground is also an acceptable option, away from ditches or stormwater channels. Dumping used cat litter in piles on the ground surface is not an environmentally approved practice.
- When walking dogs, properly dispose of dog feces. Walk dogs in vegetated areas away from streams, creeks, ditches and drainage channels. Disposal options are:
 - Scoop up pet waste and flush down the toilet.
 - Seal pet waste in a plastic bag and throw it in the garbage.
 - Bury pet waste in the yard (at least 6 inches deep) so it decomposes.
 - Add small quantities of pet waste to a compost pile; mix well. Make sure that pet waste is completely decomposed before using compost for gardens.

Pastures / Farm Animals / Wildlife


- Provide a buffer zone and/or a fence to prevent livestock from urinating or defecating into a creek, stream, or other stormwater drainage feature. Do not keep animals immediately adjacent to ditches, swales, storm drains, pipes or culverts.
- If it is necessary for pasture animals to cross a stream or creek, limit the access as much as possible. Discourage livestock from standing in a stream or creek by limiting shade.
- Clean up pastures, fields, yards and other open areas that contain animal wastes on a regular basis. Keep compost piles and manure piles as far away from ditches or stormwater channels as possible. Burying animal waste in the ground is an acceptable alternative.
- Do not encourage ducks, geese and other wild birds by feeding birds next to creeks, streams and ponds. Duck and geese waste products are particularly harmful to water quality for creeks and streams. Ponds with regular populations of ducks and geese may need additional water quality treatment, such as sand filtration units.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Residential and Homeowners (RHPs)**

RHP-09

Activity: Slope and Streambank Stabilization



Target Pollutants

Significant ♦ Partial ♦ Low or Unknown ◇

Sediment ♦ Heavy Metals ◇ Nutrients ♦ Oxygen Demanding Substances ♦ Toxic Materials ◇
Oil & Grease ◇ Bacteria & Viruses ◇ Floatable Materials ♦ Construction Waste ◇

Description

Property owners who stabilize eroding slopes and streambanks in order to protect ditches, swales, storm drains, creeks, lakes and natural waterways will not only improve the appearance of private property but will also substantially reduce sedimentation and flood damage. Streambank stabilization may require a permit from the Kentucky Division of Water (KDOW) prior to grading.

See the KDOW website for more information at www.water.ky.gov.

Approach

Homeowners and private property owners can make a big difference in controlling erosion and sediment. The benefits of controlling erosion substantially outweigh the costs involved. Contrary to popular opinion, vegetation does not just grow by itself on disturbed areas and steep slopes. There is a large potential for eroding slopes wherever land is developed or landscaped in Madisonville and Hopkins County due to hilly topography and native clay soils.

“Green” methods (with permanent vegetation) are the preferable means to fix steep slopes and erosion problems. Green methods help to capture rainfall, thus reducing the amount of runoff and flooding. Green methods are more attractive (and usually more durable) than structure stabilization methods such as gabion walls and riprap.

Overview of Slope Stabilization

First, determine the reason that a slope is unstable. If the slope tends to slide, collapse or slough, then the soil itself is unstable and typically needs a permanent solution. Possible remedies may include:

- Planting hardier and more durable types of vegetation (native trees and vines)
- Regrading the slope so that it is less steep.
- Constructing a retaining wall, crib wall or other structural feature.
- Divert surface water (and possibly groundwater) that tends to saturate soils and makes them heavier.

Overview of Slope Stabilization (cont'd)

If a slope tends to erode or washout in certain spots then the problem may be a combination of inadequate ground cover, poor drainage, no topsoil, wrong plant or some other problem.

- Divert surface water around the slope if possible.
- Improve ground surface by adding topsoil, lime, fertilizer, or mulch.
- Plant long grass, trees, shrubs, vines or another type of ground cover. Select plants that meet sunlight, drainage, and maintenance requirements.

Green methods involving permanent vegetation are preferable to non-green solutions. A common misconception is that gabions and riprap need to be inspected frequently for loose and misplaced stones, vegetation trimming and removal, settlement, etc. Green methods are more likely to be stable and self-maintaining. Specific aspects of slope stabilization are addressed in the following related BMPs:

- [EPP-13](#) Terracing
- [EPP-08](#) Surface Roughening
- [SMP-06](#) Bank Stabilization
- [SMP-07](#) Riprap
- [EPP-09](#) Topsoil
- [EPP-10](#) Mulching
- [EPP-05](#) Temporary Seeding

Retaining walls, crib walls and prefabricated structural walls must be designed by a professional or other qualified expert for specific site conditions. Walls which have a maximum height of at least 4 feet must be reviewed as part of a site development permit issued by either the Madisonville City Engineer or the Zoning Administration Office.

Overview of Streambank Stabilization

KDOW will require a property owner to obtain a Water Quality Certificate and/or a Floodplain Construction Permit for any grading in or near waters of the State. Here are two quick definitions used to specify waters of the State:

- The City of Madisonville Engineering Department defines this as a blue-line stream on a USGS quadrangle map, or any point downstream from where a blue-line stream begins.
- The KDOW typically defines a channel as carrying water for longer than one week after a heavy rainfall. The local KDOW office can send a field inspector to make difficult judgments when requested.

The KDOW allows a property owner to clear downed trees and brush from a stream. The property owner should also unblock any culverts or pipes to prevent flooding. Live trees, shrubs, brush and other vegetation (when adjacent to channel) are usually necessary to anchor and protect streambanks. To complete this type of construction a property owner may be required to get a Floodplain Construction Permit and a Water Quality Certificate to ensure that Kentucky's water quality standards will not be violated. See the KDOW website for further information on permits, channelization, streambank protection, and allowable activities.

It is important not to alter the hydraulic stream cross sections. Changing the channel hydraulics at one location (flow width, flow depth, velocity, channel roughness) will affect the channel hydraulics elsewhere. Specific aspects of streambank stabilization are addressed in these related BMPs:

- [SMP-06](#) Bank Stabilization
- [SMP-08](#) Channel Linings

**Approach
(cont'd)****Reducing or Eliminating Discharges**

- Before buying chemicals, select a method of pool treatment that has been successfully used in the Madisonville area. Investigate and compare products to ensure that a proven method is selected. Select a method with the least toxic chemicals or chemicals that can be easily neutralized and removed from water.
- Retailers and manufacturers must make information readily available to customers, such as material safety data sheets (MSDS), with each chemical product to cover proper use of chemicals, safety issues, and safe disposal methods. All users of pool and spa chemicals should verify that the discharge and disposal process for any water treated with chemical products will be able to comply with federal and state regulations in addition to the manufacturer's recommendation.
- Do not overfill swimming pools and spas so that water is discharged with every splash and wave. Allow adequate freeboard for rainfall and storms. Splashes and waves should drain to a grassy area for ground infiltration.

Recommended Disposal Alternatives

- Any swimming pool or spa water that has been treated by chlorine only and dechlorinated may be discharged to grassy yards, streets or stormwater systems at a controlled rate. Before discharging dechlorinated pool or spa water, check the water with pool test kit to verify that it is completely dechlorinated. Dechlorinated discharges to streets and driveways should occur in dry weather when it will not contribute to flooding neighbors who live downstream. Do not discharge water during winter months for safety reasons if there is a potential for water freezing in the streets, curbs and gutters.
- Any swimming pool or spa water that has been treated by chemicals other than chlorine is expressly prohibited from discharge to the storm drain system, even if the chemical has been neutralized. Disposal options include:
 1. Discharge to the sanitary sewer system.
 2. Drain pool and spa water at a very slow rate to grassy yards where the water will soak into the ground, and
 3. Construct an infiltration well or trench to allow water to soak into ground.
- The connection to sanitary sewer system must be approved by Madisonville Municipal Utilities (MMU) sewer department prior to discharging. Do not discharge water onto or through neighbor's yard or property. Infiltration rates in some soils can be slow. A percolation test may be necessary. An infiltration system may dissolve underlying natural limestone rock; geological information and advice should be consulted.
- Backwash water cannot be discharged directly to the stormwater system unless it is completely dechlorinated and not treated with any other chemicals. Typical disposal method for backwash is to connect backwash hose from swimming pool or spa to the sanitary sewer system using a licensed plumbing contractor to install backflow prevention devices.
- Note that any connections to the sanitary system must be approved by the Wastewater Collection Department prior to installation. Call the Wastewater Collection office for more information at (270) 821-3717.

Limitations

Disposal methods that comply with the City of Madisonville Stormwater Ordinance may not necessarily comply with federal, state, and county regulations. Resolve compliance issues prior to discharging water from swimming pool or spa.



**Madisonville, Kentucky
Stormwater Best Management Practices (BMPs)
Residential and Homeowners (RHPs)**

RHP-11

Activity: Boating



Target Pollutants

Significant ♦	Partial ♦	Low or Unknown ♦
---------------	-----------	------------------

Sediment ♦	Heavy Metals ♦	Nutrients ♦	Oxygen Demanding Substances ♦	Toxic Materials ♦
Oil & Grease ♦	Bacteria & Viruses ♦	Floatable Materials ♦	Construction Waste ♦	

Description

Prevent or reduce the discharge of pollutants to rivers, lakes and streams by proper disposal of wastes, minimizing repairs and maintenance, cleaning up spills and wastes immediately, and improved boating equipment and methods. Protect our natural resources and environment by following guidelines from the National Clean Boating Campaign. Use common sense to protect water quality of Madisonville lakes and rivers.

Approach

Federal, state and municipal regulations prohibit the discharge of any waste or litter into Madisonville or Hopkins County creeks and streams such as Middle Creek, Flat Creek, Elk Creek, Otter Creek, and Sugar Creek or any of the various tributaries. Therefore, polluters may be penalized or arrested by any government entity authorized to enforce federal, state or municipal laws. It is illegal to discharge raw sewage from a vessel within U.S. territorial waters.

In addition to government agencies and authorities, fishing organizations and tournaments promote responsible boating and care for the environment. Brochures and fact sheets from the National Clean Boating Campaign for sewage pumpout, fueling, bilge water, litter and boat maintenance are available at www.cleanboating.com/research/boatingpublic.html.

Boating Activities

Boat Sewage and Pumpouts

- Properly dispose of domestic and sanitary wastewater by using holding tanks. Empty holding tanks at approved wastewater collection facilities at marinas and boatyards. Verify ballast water is clean before discharging to natural body of water. Remove or permanently lock Y-valve on holding tanks to prevent accidental discharge of untreated sewage to lakes, rivers and streams. Comply with all laws regarding use and maintenance of a marine sanitation device (MSD). Guidelines and regulations are summarized on a Coast Guard website (<http://www.uscg.mil/hq/g-m/mse/msd.htm>).

Boating Activities (cont'd)

- In general, the use of onshore restrooms is preferable to using restrooms on a boat. Minimize the use of onboard facilities by using onshore restrooms when docked. Make restroom stops every few hours as needed. Plan for restroom stops at marinas, fueling stations, waterfront restaurants and public parks.
- Comply with all federal and state laws for MSD equipment. MSD equipment is regulated and certified by the U.S. Coast Guard to meet certain treatment standards. Type I and Type II MSD equipment is usually a combination of physical treatment (grinder) and chemical treatment (chlorinator) prior to discharge. Post operating instructions near the MSD, and keep MSD maintenance guide and user's manual on the boat.

<u>MSD</u>	<u>Fecal coliform limits</u>	<u>Discharge criteria</u>
Type I	< 1000 / 100 ml	No visible floating solids
Type II	< 200 / 100 ml	Suspended solids < 150 mg/l
Type III	-----	No discharge (holding tank)

- Do not use boat toilets for disposal of fats, solvents, oil, emulsifiers, paint, poison, disposable diapers or sanitary napkins. As a general rule, keep a supply of bags and containers ready for disposal of any conceivable item. Whenever possible, buy fast-dissolving marine toilet tissue for use in MSD equipment.
- Portable toilets shall not be discharged into U.S. territorial waters, which includes all lakes, rivers and streams within Kentucky. Empty portable toilets at shoreside dump stations or at home.
- Use a pumpout station to empty holding tanks (and also MSD Type III equipment). Encourage marina owners to construct more pumpouts and dump stations by thanking marina owners and supporting their businesses.

Fuel and Oil

- Prevent fuel and oil from being discharged into the water or into the bilge by every means available. Use oil-absorbent pads and booms to contain any spilled fuel or oil. Boats with inboard engines should have oil absorption pads in bilge areas. The pads should be changed at least once a year or as needed. Do not pump bilge water if it is oily or has a sheen.
- Fuel, fluids and oil should be kept in secure containers. Recycle used fuels in properly labeled containers. Inspect and repair engine valves, pipes, hoses as necessary. Use drip pans when conducting maintenance and repair.
- Keep engine and other equipment in good operating condition. Inspect engine prior to each use. Follow manufacturer's recommendations for maintenance and tuneups. Use drip pans and funnels when performing minor engine repairs.
- Avoid filling the fuel tank to the top. Watch and listen when filling the fuel tank. Use fuel stations with automatic shut-off nozzles whenever possible.
- Notify KDOW and the City of Madisonville in the event of major leaks and spills (as described in [GHP-05](#), Spill Prevention and Control). Use oil-absorbent pads and booms to contain the spill. Do not use any detergent, soap, cleaner or emulsifier on a fuel spill, oil spill or bilge water. These substances temporarily dissolve oil and grease, but does not actually remove the pollution from the water.

Litter and Fish Waste

- Do not discharge anything into the water, including excess food. Place all litter and waste into trash bags for disposal onshore. Retrieve any trash which falls overboard.

Boating Activities (cont'd)

- In general, reduce the amount of unnecessary wrapping and packaging used on the boat. Reusable containers, cups and dishes will reduce the amount of trash generated. Recycle whenever possible (aluminum cans, plastics, glass).
- Do not throw cigarettes (or other smoking materials) overboard. Use an ashtray when smoking. Do not spit chewing tobacco overboard.
- Do not discharge fish waste overboard. Place fish waste into trash bags for disposal onshore, or use a fish cleaning station onshore. Small amounts of fish parts may be used for bait or chum. Fish wastes should not be recycled in any dead-end lagoons or other poorly flushed areas. Restaurants are specifically prohibited from discharging fish wastes into the water.
- People participating in fishing tournaments and other authorized events should follow guidelines presented by the sponsors. Follow all rules and regulations issued by the Kentucky Department of Fish and Wildlife.

Boat Cleaning and Maintenance

- Plan all cleaning and maintenance activities beforehand. Use the proper equipment to perform the activity efficiently and swiftly, while minimizing pollution. Use phosphate-free and biodegradable detergents for hull washing. Limit the amount of detergents used by first scrubbing and cleaning with water.
- Perform all hull scraping, sanding, chemical stripping and painting onshore. Place boat over a drop cloth, and prevent the discharge of any chemicals or particles. Properly dispose of surface chips, used blasting sand, residual paints, and other materials. Use temporary storage containment that is not exposed to rain. Sweep dry-docks each day or after maintenance is completed.
- Limit over-water hull surface maintenance to minor sanding and minor painting using hand tools and a small can of paint or other surface agent. In general, conduct most boat repair and maintenance items by removing the boat from the water into an organized maintenance area.
- Painting should be limited to spot work. Paint mixing should not occur on the dock. Use secondary containment on paint cans. Have available spill containment and cleanup materials. Use tarps, ground cloths or plastic sheeting when sandblasting or painting boats on land. Spray applicators may be used when painting on land.
- Immediately clean up spills on docks or boats using absorbent materials. Keep ample supply of spill cleanup materials on hand and conspicuously marked.
- Dispose of cleanup materials properly. Consult [GHP-05](#) (Spill Prevention and Control) for emergency telephone numbers.

Limitations

- Private tenants at marinas may resist restrictions on shipboard painting and maintenance. Existing contracts with tenants should be updated to require that tenants abide by new rules that benefit water quality.
- Even small amounts of biodegradable cleaning agents have been found to be toxic to fish. Disposal of small amounts of cleaning agents should be done through the sanitary sewer system.

Links

- National Clean Boating Campaign <http://www.cleanboating.com/research/boatingpublic.html>
- National Clean Boating Campaign <http://cleanboating.org/bibliography/index.html>

Cause of Wet Basements and Crawl Spaces

Most wet basements or crawl spaces are caused by surface water that is not adequately drained away from the foundation wall. Sources of this water may include the following:

- Roof water, if no guttering is present or if the guttering leaks and overflows due to leaves and obstructions. Concentrated roof water, when falling from a height of one or two stories, can cause erosion along the foundation wall and exacerbate the problem of stormwater infiltration.
- Roof water, if the downspouts are clogged or do not have sufficient means to drain water away from the foundation wall. Frequently, a downspout ends at the corner of the house without a splash pad (splash block) or shoe (sometimes called an elbow), leaving roof water to concentrate at that point and seep into the soil next to the foundation wall. A typical 2000 square foot roof can produce almost 1250 gallons of water during just 1 inch of rainfall. If rainfall is steady and prolonged, roof water is even more likely to soak into the ground next to the foundation wall.
- Excessive watering of flower beds and shrubbery around the foundation wall. Once the upper soil layer or mulch bed is filled with water, the excess water either runs off or seeps into the ground next to the wall. Prolonged watering can contribute large amounts of water to crawl spaces or basements.
- Rainwater runoff from the adjacent lawn, walks, or driveway areas if the landscaping slopes water to drain toward the house instead of away. If surface runoff is directed toward foundation wall, water will pond and then soak into the soil, thus becoming a potential source of basement or crawl space water. Downspout splash pads are not very effective if the lawn drains back to the foundation wall.

Water or dampness problems in basements or crawl spaces are sometimes caused by other factors:

- Subsurface or groundwater may be intercepted or dammed up by a basement or foundation wall. Houses which are built on a hillside are particularly vulnerable. Foundation walls act like dams to intercept and trap this subsurface water, causing pressure to build up on the outside of the wall, which forces water through joints and cracks in basement walls or as seepage under the footer.
- Nearby springs may have been filled in or covered up by the others. Unless the springs were properly drained away from the lot or subdivision, such water will eventually seep into the surrounding fill, become a pool of groundwater, and eventually force itself laterally and upwardly into basements and crawl spaces.
- Nearby creeks may overflow during storm runoff and either directly flood basement or crawl space areas, or contribute to the groundwater, which may become sufficiently high to cause seepage into the basement or crawl space area. Homeowners may not experience the effects of groundwater seepage or overflowing creeks for months or years after purchasing a house because of drought or infrequent out-of-bank flooding. However, when such conditions do occur, they may come suddenly without warning and cause serious problems after the warranty period has expired.
- Improperly installed, clogged, collapsed, or leaky drains may not allow water to escape. Perimeter, footer, or foundation drains are installed around the exterior of a house below basement floor level to intercept groundwater build-up and seepage under the house. If drains are improperly installed or become clogged with silt or roots, they will not operate as intended. Sometimes an otherwise good perimeter drain gets covered up or crushed during the final backfilling or landscaping stages of construction, and the intercepted water will backup into a foundation wall and eventually to seep into the basement or crawl space.




Figure 1. Typical paths of water and moisture entering into a crawl space area.

Cause of Wet Basements and Crawl Spaces (cont'd)

- Soil continuously draws water up from subsurface groundwater sources in a crawl space by capillary attraction. The finer the soil (e.g. clays), the more aggressive the capillary pumping action. As the water rises to the surface, it evaporates into the crawl space. This ground moisture is a significant source of dampness and humidity under a house, even without standing water. The presence of capillary water is often indicated by a whitish residue, left on the ground surface of the crawl spaces, resulting from evaporation of water containing minerals and salts. Lack of a moisture barrier, such as a plastic sheet, will allow capillary action and evaporation to contribute unlimited moisture to crawl space areas. Figure 1 illustrates how surface water and moisture can enter a crawl space area.
- Closed, inadequate, ineffective, or no crawl space venting around foundation walls will force the buildup of humidity in the space beneath a house. Given the combination of high humidity and low temperature, condensation can form on heating/AC ducts, joists, underflooring, and insulation. This environment, together with likely darkness, encourages mildew and other fungi to form.
- Damp or wet basements and crawl spaces may be caused by ruptured water or sanitary lines either just outside the wall or under the house. If a crawl space is unusually wet and muddy, inside leaks may be difficult to find and repair. Outside pipe leaks may be even more difficult to find, since water may appear several feet away from the actual leak. Old field drains under a house may also be a source of unwanted water.

Preventing Wet Basements and Crawl Spaces

Many construction complaints about new homes arise from inadequate site drainage and water problems. Proper drainage of surface water is a primary element in preventing wet basements, damp crawl spaces, eroded banks, muddy yards, and possible failure of a foundation system. The City of Madisonville requires that new construction or alteration of houses must conform to the requirements of the Southern Building Code Congress International, Inc. (SBCCI). Generally, surface water drainage should be directed from all sides of the house and off the lot in a manner that will:

- Minimize possibility of dampness in basements and crawl spaces.
- Prevent standing or ponding water on the site.
- Prevent soil erosion.
- Not adversely affect the supporting foundation soil behavior.

Preventing Wet Basements and Crawl Spaces (cont'd)

Walks, driveways, retaining walls and other landscape improvements should be constructed so as not to interfere with drainage. Walks should not be used as drainage channels. Site grading plans should specify minimum slopes from the house (usually 2 to 5%), depending on location, type of soils, frost depth, and soil moisture, to ensure water drainage for some specified distance (usually 6 to 25 feet) away from supporting foundations. In cases where minimum slopes or distances cannot be attained, paved gutters or other drainage structures acceptable to the Building Inspector may need to be installed. Maximum slopes are specified to prevent erosion or unstable banks around the house and yard.

Roof water should be directed to a downspout and away from the foundation wall toward a suitable ditch, swale, or drainage pipe to prevent ponding or backflow as shown in Figure 2. All drainage structures should be properly connected to adequate outlets that are protected, where necessary, by recorded permanent easement. House plans and landscaping should be developed to prevent "dead" drainage areas around the foundation wall -- areas where rainfall has no place to flow away except by ponding and soaking into the soil near the foundation wall. Areas bounded by the front entrance / sidewalk/garage / driveway are especially vulnerable to trapped pockets of surface water.




Figure 2. Correct installation of downspout shoe and splash block at foundation wall.

(Note that the ground surface slopes away from house.)

Another vital step in preventing water in basements and crawl spaces is to intercept outside subsurface or groundwater with a perimeter drain at the footer base level around all sides of the house where the exterior ground surface is higher than the inside floor or crawl space level. While foundation drains are clearly necessary for houses with basements or potentially habitable living space below exterior ground surface, they may also be used in crawl spaces where water, soil, and/or earth floor elevation conditions warrant. The drains should discharge by gravity to a positive outfall such as an approved drainage ditch, swale or storm system. In some cases, sump pits and pumping with automatic float actuation may be required.

Specifications for waterproofing and damp-proofing foundation walls are found in SBCCI. Building codes specify the materials, maximum vapor transmission rate, venting, etc., appropriate for construction. Excessive moisture vapor can be prevented from entering a crawl space area with the use of an effective and correctly installed vapor barrier (typically polyethylene sheeting) over the ground surface. Torn pieces, poor or non-overlapping joints, missing sections, or improperly sealed corners and edges at the walls, fireplaces, and interior piers must be avoided to produce an effective vapor barrier.




Figure 3. Correction of typical slope drainage problem using swale or ditch.

Preventing Wet Basements and Crawl Spaces (cont'd)

Crawl space areas should have adequate wall ventilation openings around the foundation walls to provide cross ventilation for preventing the buildup of water vapor inside the crawl space. Building codes specify minimum vent opening areas (usually 1 square foot of net opening for each 150 square feet of crawl space), opening location or arrangement, corrosion-resistant wire mesh screen, and any reduction in ventilation opening area allowance if an approved vapor barrier is used.

In older houses where any of the above moisture control methods are missing, measures should be taken to install appropriate drainage facilities, vapor barriers, or ventilation openings. Installing any of these elements after a house has been built will be more costly than while the house is constructed. A combination of remedial measures is often necessary. If the yard area slopes toward the house and surface water collects or ponds near the foundation wall, a V-ditch or swale should be constructed around the house to allow surface drainage from both the foundation wall and the other yard areas to an adequate ditch or storm drain. Such cases often exist where the front street is higher than the first floor of the house, or when the house is built on the side of a hill. Figure 3 illustrates how this problem can be solved.

If a flower bed or garden is next to the foundation wall, it may be a significant source of water for the basement or crawl space. Consider relocating the flower bed or shrubbery, or install heavy plastic sheets with drains beneath the flower bed. Then any water which soaks deeply into the soil is intercepted and carried safely away by gravity at least six to eight feet from the house to a gravel collection drain or swale.

Tips for Homeowners and Homebuilders

"A teaspoon of prevention is worth a gallon of cure" certainly applies to new homebuilders – at least in avoiding water problems in basements or crawl spaces. Buyers of new or older houses should be cautious about drainage. The best time to sign a contract is on a rainy day!"

Tips for buying or building a new house

The following tips are suggested to avoid water problems when building or buying a new house:

Work with a professional to help locate the new house on the lot and at an elevation which minimizes the potential for surface or groundwater drainage problems. If a flowing stream or creek is nearby (especially if bordering the lot), check with local planning agency authorities or a hydrologic engineer for potential flooding, whether in a designated 500-year flood hazard zone or in an area where that may be affected by nuisance flooding.

Activity: Tips for Wet Basements and Crawlspace

RHP-12

Tips for Homeowners and Homebuilders (cont'd)

Work with a reputable homebuilder that can supply reference names and projects for houses that he has built. Visit these sites and check for patterns of any drainage problems. Contact the Better Business Bureau and other organizations to see if there are complaints and outstanding issues.

It may be beneficial to hire an engineer or architect to check slopes, foundation wall waterproofing and dam-proofing, underground drains, general surface and roof water drainage, and general quality of construction. If you suspect a potential problem, ask the local building inspector for advice.

Check to make sure that the perimeter foundation drain, basement drain, or crawl space drain has an unobstructed outlet to a ditch or swale leading away from the house. Pay special attention around the outside and the basement or crawl space for: (1) back sloping lawns and landscaping toward foundation walls; (2) back sloping driveways toward garage, stoops, walks or patios which force surface water toward the foundation wall; (3) very flat property; (4) standing water inside of crawl space next to foundation wall; (5) pattern of wet concrete blocks inside basement walls, particularly with whitish salt deposits on inside foundation walls as a result of leaching from moisture seepage and evaporation; (6) downspouts which drain to the foundation wall without any clear path for water to escape; and (7) depressions or settlement near the foundation. If necessary, use a level to check the slope direction.



Section 4

LIST OF RELATED WEBSITES / TECHNICAL RESOURCES

National Menu of Best Management Practices for Stormwater Phase II,

<http://cfpub.epa.gov/npdes/stormwater/menuofbmps/menu.cfm>

United States Environmental Protection Agency, NPDES Site, <http://cfpub.epa.gov/npdes/index.cfm>

United States Environmental Protection Agency, www.epa.gov

Tennessee Department of Environment and Conservation, www.state.tn.us/environment/

Louisville and Jefferson County Metropolitan Sewer District, www.msdlouky.org

Kentucky Division of Water, www.water.ky.gov

Occupational Safety and Health Administration, www.osha.gov

United States Coast Guard, www.uscg.mil

National Clean Boating Campaign, www.cleanboating.com

Tennessee Valley Authority Clean Marina Guidebook, www.tva.com/environment/water/boating.htm

United States Army Corp of Engineers, www.usace.army.mil

United States Geological Survey, www.usgs.gov

City of Knoxville, TN – Best Management Practices Manual

Center for Watershed Protection, <http://www.cwp.org/>

Fuller, Mossbarger, Scott and May Engineers, Inc., www.fmsm.com

City of Madisonville, www.madisonvillegov.com